



AirPrime RC76xx

AT Command Reference



SIERRA
WIRELESS®

41113566
Rev. 4.0

Important Notice

Due to the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (i.e., have errors) or be totally lost. Although significant delays or losses of data are rare when wireless devices such as the Sierra Wireless modem are used in a normal manner with a well-constructed network, the Sierra Wireless modem should not be used in situations where failure to transmit or receive data could result in damage of any kind to the user or any other party, including but not limited to personal injury, death, or loss of property. Sierra Wireless accepts no responsibility for damages of any kind resulting from delays or errors in data transmitted or received using the Sierra Wireless modem, or for failure of the Sierra Wireless modem to transmit or receive such data.

Safety and Hazards

Do not operate the Sierra Wireless modem in areas where blasting is in progress, where explosive atmospheres may be present, near medical equipment, near life support equipment, or any equipment which may be susceptible to any form of radio interference. In such areas, the Sierra Wireless modem **MUST BE POWERED OFF**. The Sierra Wireless modem can transmit signals that could interfere with this equipment.

Do not operate the Sierra Wireless modem in any aircraft, whether the aircraft is on the ground or in flight. In aircraft, the Sierra Wireless modem **MUST BE POWERED OFF**. When operating, the Sierra Wireless modem can transmit signals that could interfere with various onboard systems.

Note: Some airlines may permit the use of cellular phones while the aircraft is on the ground and the door is open. Sierra Wireless modems may be used at this time.

The driver or operator of any vehicle should not operate the Sierra Wireless modem while in control of a vehicle. Doing so will detract from the driver or operator's control and operation of that vehicle. In some states and provinces, operating such communications devices while in control of a vehicle is an offence.

Limitation of Liability

The information in this manual is subject to change without notice and does not represent a commitment on the part of Sierra Wireless. SIERRA WIRELESS AND ITS AFFILIATES SPECIFICALLY DISCLAIM LIABILITY FOR ANY AND ALL DIRECT, INDIRECT, SPECIAL, GENERAL, INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR EXEMPLARY DAMAGES INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS OR REVENUE OR ANTICIPATED PROFITS OR REVENUE ARISING OUT OF THE USE OR INABILITY TO USE ANY SIERRA WIRELESS PRODUCT, EVEN IF SIERRA WIRELESS AND/OR ITS AFFILIATES HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR THEY ARE FORESEEABLE OR FOR CLAIMS BY ANY THIRD PARTY.

Notwithstanding the foregoing, in no event shall Sierra Wireless and/or its affiliates aggregate liability arising under or in connection with the Sierra Wireless product, regardless of the number of events, occurrences, or claims giving rise to liability, be in excess of the price paid by the purchaser for the Sierra Wireless product.

Patents

This product may contain technology developed by or for Sierra Wireless Inc. This product includes technology licensed from QUALCOMM®. This product is manufactured or sold by Sierra Wireless Inc. or its affiliates under one or more patents licensed from InterDigital Group and MMP Portfolio Licensing.

Copyright

©2020 Sierra Wireless. All rights reserved.

Trademarks

Sierra Wireless®, AirPrime®, AirLink®, AirVantage® and the Sierra Wireless logo are registered trademarks of Sierra Wireless, Inc.

Windows® and Windows Vista® are registered trademarks of Microsoft Corporation.

QUALCOMM® is a registered trademark of QUALCOMM Incorporated. Used under license.

Other trademarks are the property of their respective owners.

Contact Information

Sales information and technical support, including warranty and returns	Web: sierrawireless.com/company/contact-us/ Global toll-free number: 1-877-687-7795 6:00 am to 6:00 pm PST
Corporate and product information	Web: sierrawireless.com

Revision History

Revision number	Release date	Changes
1.0	Dec 2019	<ul style="list-style-type: none"> Created, internal
2.0	Jan 2019	<ul style="list-style-type: none"> General release

Revision number	Release date	Changes
3.0	Feb 2019	<p>Updated Modem Status Commands</p> <ul style="list-style-type: none"> • Updated +CMUX, +KSIMDET, !MAPUART, !POWERWAKE, !SCACT, !USBCOMP • Updated !CUSTOM customizations: <ul style="list-style-type: none"> • Added OSAENABLE • Removed HSICENABLE <p>Updated Diagnostic Commands</p> <ul style="list-style-type: none"> • Added !BCRESETTYPE <p>Updated Test Commands</p> <ul style="list-style-type: none"> • Updated !DAWSCONFIGRX <p>Updated GPS Commands</p> <ul style="list-style-type: none"> • Added !GPSMOMETHOD, !GPSNMEACONFIG <p>Updated SIM Commands</p> <ul style="list-style-type: none"> • Updated +KSIMSEL <p>Updated OMA-DM Commands</p> <ul style="list-style-type: none"> • Updated !DSDEBUGPRINT <p>Updated SAR Backoff and Thermal Control Commands</p> <ul style="list-style-type: none"> • Added !SARGPIO <p>Updated Audio Commands</p> <ul style="list-style-type: none"> • Updated !AVCFG, !AVRXG, !AVTXG • Removed !AVCODECMICTXG <p>Updated I/O Commands</p> <ul style="list-style-type: none"> • Added +WEXTCLK • Updated +WIOCFG <p>Updated Protocol Commands</p> <ul style="list-style-type: none"> • Added Usage Notes • Updated +KCNXCFG, +KCNXUP, +KHTTPCFG, +KHTTPGET, +KIPOPT, +KPATTERN, +KTCP_DATA (notification), +KTCP_SRVREQ (notification), +KTCPCFG, +KTCPCLOSE, +KTCPCNX, +KTCPCRV, +KTCPSPND, +KUPD_DATA (notification), +KUDPCFG, +KUDPCRV, +KUDPSND, +KURCCFG • Removed +KTCP_ACK (notification), +KTCPACKINFO
4.0	Mar 2020	<p>Updated Protocol Commands:</p> <ul style="list-style-type: none"> • Added +KSSLCRYPTO • Added +KSSLCFG <p>Updated Modem Status Commands</p> <ul style="list-style-type: none"> • Updated !BAND, +CMUX, !POWERWAKE, I <p>Updated Supported GSM / WCDMAAT Commands</p> <ul style="list-style-type: none"> • +CALA

>> Contents

About This Guide	9
Introduction	9
Command access	9
Command timing	9
Interval timing	9
Escape sequence guard time	9
Result codes	10
Response formats	10
References	10
Terminology and acronyms	10
Current firmware versions	11
Version	11
Upgrading	11
Document structure	11
Conventions	20
AT Password Commands	21
Introduction	21
Command summary	21
Command reference	22
Modem Status, Customization, and Reset Commands	24
Introduction	24
Command summary	24
Command reference	27
SIM Toolkit Commands	115
Introduction	115
Command summary	115
Command reference	116

Diagnostic Commands	141
Introduction	141
Command summary.....	141
Command reference	142
Test Commands	146
Introduction	146
Command summary.....	147
Command reference	149
Memory Management Commands	171
Introduction	171
Command summary.....	171
Command reference	171
GNSS Commands	172
Introduction	172
Command summary.....	172
Command reference	174
Error codes	197
SIM Commands	200
Introduction	200
Command summary.....	200
Command reference	201
SD Commands	205
Introduction	205
Command summary.....	205
Command reference	206

OMA-DM Commands	207
Introduction	207
Command summary.....	207
Command reference	207
SAR Backoff Commands	209
Introduction	209
Command summary.....	209
Command reference	210
Audio Commands	220
Introduction	220
Command summary.....	220
Command reference	221
I/O Commands	227
Introduction	227
Command summary.....	227
Command reference	228
AirVantage Commands	233
Introduction	233
Command summary.....	233
Command reference	234
Protocol Commands	243
Introduction	243
Command summary.....	243
Command reference	245

Supported GSM/WCDMA AT Commands	279
Band Definitions	289
ASCII Table	291
Index (AT commands)	292
Index	297

>> 1: About This Guide

Introduction

This document describes supported standard and proprietary AT commands available for Sierra Wireless AirPrime® RC76xx products, and provides details where commands vary from the standards.

These commands are intended for use by OEMs, and are supplemental to the standard AT commands for GSM devices defined by the 3GPP (3rd Generation Partnership Project) in *TS 27.007 AT command set for User Equipment (UE)* and *TS 27.005 Use of Data Terminal Equipment—Data Circuit terminating Equipment (DTE-DCE) interface for Short Message Service (SMS) and Cell Broadcast Service (BSE)*.

Note: For questions or concerns relating to command implementation, please contact your Sierra Wireless account representative.

Command access

Some commands in this reference are password-protected. To use these commands, enter the correct password using `AT!ENTERCND` on page 22. Once the password is entered, all commands are available and remain available until the modem is reset or powered off and on.

The password assigned to `!ENTERCND` is unique to each customer and is configured onto the modem during manufacture. If you do not know your password, contact your Sierra Wireless Account Manager or Sierra Wireless distributor.

Command timing

Interval timing

Some commands require time to process before additional commands are entered. For example, the modem returns OK when it receives `AT!DAFTMACT`. If `AT!DASBAND` is received too soon after this, the modem returns an error.

When building automated test scripts, ensure that sufficient delays are embedded, where necessary, to avoid these errors.

Escape sequence guard time

The AT escape sequence “+++” requires a guard time of 1.0 seconds before and after it is used.

Result codes

Result codes are not shown in the command tables unless special conditions apply. Generally the result code OK is returned when the command has been executed. ERROR may be returned if parameters are out of range, and is returned if the command is not recognized or is not permitted in the current state or condition of the modem.

Response formats

Response formats shown in this document are intended to accurately describe the non-whitespace content of responses. For display purposes within this document, extraneous whitespace content (blank lines between lines of text) may not be displayed, and whitespace (blank spaces) between text segments within lines may be shorter or longer than what is received in actual responses.

For example:

AT!THISEXAMPLE? THISEXAMPLE: TestVal1=7 TestVal2=Hello OK	could be shown in this document without extra blank lines and with less space between TestVal1 and TestVal2	AT!THISEXAMPLE? THISEXAMPLE: TestVal1=7 TestVa2=Hello OK
---	---	---

If automated scripts are used to parse command responses, make sure to parse whitespace appropriately.

References

This guide covers the command sets used by OEMs, designers and testers of Sierra Wireless AirPrime products, plus general operational use commands.

For additional product-specific documentation, refer to source.sierrawireless.com.

Terminology and acronyms

This document makes wide use of acronyms that are in common use in data communications and cellular technology.

Current firmware versions

Version

To determine your firmware revision, enter the identification command **AT+GMR**.

Upgrading

To check for newer modem firmware, go to the device page at source.sierrawireless.com and select the Firmware option.

Document structure

This document describes the proprietary commands listed in the tables below — each table corresponds to a specific chapter.

AT Password Commands — Commands used to enable access to password-protected AT commands and to set the AT command password.

Table 1-1: AT Password Commands

Command	Description	Page
!ENTERCND	Enable access to password-protected commands	22
!SETCND	Set AT command password	23

Modem Status, Customization, and Reset Commands — Commands used to determine modem status, adjust customization settings, and reset the modem.

Table 1-2: Modem Status Commands

Command	Description	Page
+++	Switch from Data Mode to Command Mode	27
!ADC	Read ADC value	28
!ANTSEL	Set/query external antenna select configuration	29
!BAND	Select/return frequency band set	31
!BOOTHOLD	Reset modem and wait in bootloader for firmware download	33
!BSGPIO	Query/Set GPIO signal level/direction	34
+CBST	Select Circuit-Switched Bearer	36
+CESQ	Extended Signal Quality	37
+CGACT	Activate/deactivate PDP context	39
+CGAUTH	Set/Report PDP connection authentication parameters	40
+CGDCONT	Define PDP context	41
+CMEE	Report mobile termination error	42

Table 1-2: Modem Status Commands (Continued)

Command	Description	Page
+CMUX	Configure Multiplexing Control Channel	43
+CPSMS	Configure Power Saving Mode (PSM)	45
+CPWROFF	Power Off	46
+CSQ	Display signal quality	46
+CSQ (notification)	RSSI change across threshold—Unsolicited notification	47
!CUSTOM	Set/return customization settings	48
!GCFEN	Enable/disable GCF testing mode	54
!GSTATUS	Return operational status	55
!HWID	Read hardware ID	63
I	Display product identification information	64
!IMAGE	Manage Firmware Images	66
!IMPREF	Query/set Image Management preferences	68
&K	Flow Control	68
+KCCINFO	Enable/disable camped cell information notifications	69
+KCCINFO (notification)	Camped cell parameter change—Unsolicited notification	70
+KCELL	Display Detected Cell Details	71
+KGSN	Request Product Serial Number Identification and Software Version	74
+KMCLASS	Set 2G multislot class	75
+KSIMDET	Enable/Disable SIM Detection notifications	76
+KSLEEP	Configure UART1 power management (sleep mode entry conditions)	77
+KSRAT	Set the current RAT	78
+KSREP	Enable/disable startup reporting	79
+KSUP (notification)	Startup notification (unsolicited notification)	79
!MAPUART	Map services to UART	80
!MUXMODE	Enable/disable CMUX mode	81
!NETNUM	Set/report number of supported network interfaces	81
!NVBACKUP	Backup NV data	82
!PACKAGE	Return package version string	82
!PATEMP	Return PA temperature information	83
!PATEMP (notification)	PA temperature state change—Unsolicited notification	83
!PCINFO	Return power control status information	84

Table 1-2: Modem Status Commands (Continued)

Command	Description	Page
!PCTEMP	Return Power control temperature information	85
!PCTEMP (notification)	PMIC temperature state change—Unsolicited notification	85
!PCTEMPLIMITS	Set/report temperature state limit values	86
!PCVOLT	Return current power supply voltage information	87
!PCVOLT (notification)	PMIC voltage state change—Unsolicited notification	87
!PCVOLTLIMITS	Set/report power supply voltage state limit values	88
!POWERDOWN	Power down system	88
!POWERMODE	Enable/disable PSM	89
!POWERWAKE	Configure PSM wakeup sources	90
!PRIID	Report module PRI part number and revision	91
*PSRDBS	Select operating bands	92
!RESET	Reset modem	93
+RSCP	Display RSCP value(s) (WCDMA only)	94
S11	Query/set DTMF dialing speed	95
!SCACT	Activate/deactivate data connection	96
!SCUMMTU	Set/Report MTU Size	97
!SELACQ	Select RAT acquisition order	98
!SELCIOT	Set/report Cellular IoT preferences	99
!SELMODE	Set/return current service domain	100
!SELRAT	Set preferred RAT	101
!SELSNR	Set/report LTE-NB1 band scan configuration	103
+SIM (notification)	SIM inserted/removed—Unsolicited notification	103
!SKU	Read Module SKU	104
!USBCOMP	Set/report USB interface configuration	105
!USBINFO	Return information from active USB descriptor	106
!USBPID	Set/report product ID in USB descriptor	107
+WFWUPD	Download/install firmware package	108
+WFWUPD (notification)	Firmware package install notification	109
+WJAM (notification)	Jamming events—Unsolicited notification	110
+WJAMTHRESH	Set/Report Jamming Detection Threshold Value	111
+WUSLMSK	Enable/disable unsolicited notifications	112

[SIM Toolkit Commands](#) — Commands and notifications used to enable the AT Interface's SIM toolkit support, and receive and respond to unsolicited SIM command notifications.

Table 1-3: SIM Toolkit Commands

Command	Description	Page
*PSSTKI	Configure AT interface's SIM toolkit support	116
!STKC	Report last unsolicited proactive SIM command notification	117
!STKC (notification)	Unsolicited proactive SIM command notification	118
!STKCR	Respond to proactive SIM command	119
!STKGC	Get (retrieve) data for last unsolicited proactive SIM command notification	124
!STKMS	Inform SIM of menu item selection or provide help information	136
!STKN (notification)	Response to mobile-originated Call or SMS control request (notification)	137
!STKPD	Select host-supported STK features	139

[Diagnostic Commands](#) — Commands used to select frequency bands and diagnose problems.

Table 1-4: Diagnostic Commands

Command	Description	Page
!BCFWUPDATESTATUS	Report status of most recent firmware update attempt	142
!BCRESETTYPE	Report module reset type and cause	143
!ERR	Display/clear diagnostic information	144
!GCCLR	Clear crash dump data	144
!GCDUMP	Display crash dump data	144
!RXDEN	Enable/disable WCDMA/LTE receive diversity	145

[Test Commands](#) — Commands required to place the modem in particular modes of operation, test host connectivity, and to configure the transmitters and receivers for test measurements.

Table 1-5: Test Commands

Command	Description	Page
!DACGPSCTON	Return CGPS C/N and frequency	149
!DACGPSMASKON	Set CGPS log mask	149
!DACGPSSTANDALONE	Enter/exit Stand Alone RF mode	150
!DACGPSTESTMODE	Start/stop CGPS diagnostic task	150
!DAFTMACT	Put modem into Factory Test Mode	151

Table 1-5: Test Commands (Continued)

Command	Description	Page
!DAFTMDEACT	Put modem into Online Mode from Factory Test Mode	151
!DAGGAVGRSSI	Return averaged RSSI value in dBm (GSM only)	152
!DAGSRXBURST	Set GSM receiver to burst mode (GSM only)	152
!DAGSTXFRAME	Set GSM Tx frame structure (GSM only)	153
!DALGAVGAGC	Return averaged Rx AGC value (LTE only)	154
!DALSNSVAL	Configure LTE Net Sig value (LTE only)	155
!DALSPARANGE	Set LTE PA range (LTE only)	155
!DALSRXBW	Set LTE Rx bandwidth (LTE only)	156
!DALSTXBW	Set LTE Tx bandwidth (LTE only)	156
!DALSTXMOD	Set LTE Tx modulation type (LTE only)	157
!DALSTXPWR	Set LTE Tx power level (LTE only)	158
!DALSWAVEFORM	Set LTE TX waveform (LTE only)	159
!DASBAND	Set frequency band	160
!DASCALSTATE	Enter/exit modem calibration state	161
!DASCHAN	Set modem channel (frequency)	162
!DASLNAGAIN	Set LNA gain state	163
!DASPDM	Set PDM value (WCDMA and GSM only)	164
!DASTXOFF	Turn Tx PA off	164
!DASTXON	Turn Tx PA on	165
!DAWGAVGAGC	Return averaged Rx AGC value (WCDMA only)	165
!DAWGRXAGC	Return Rx AGC value (WCDMA only)	166
!DAWSCONFIGRX	Configure receiver (WCDMA only)	167
!DAWSPARANGE	Set PA range state machine (WCDMA only)	168
!DAWSSCHAIN	Enable secondary receive chain (WCDMA only)	168
!DAWSTXCW	Set waveform used by the transmitter (WCDMA only)	169
!DAWSTXPWR	Set desired Tx power level (WCDMA mode only)	169
!LEDTEST	Test LED	170

Memory Management Commands — Commands that control the data stored in non-volatile memory of the modem.

Table 1-6: Memory Management Commands

Command	Description	Page
!RMARESET	Restore device	171

GNSS Commands — Supported on GPS-enabled modems only.

Table 1-7: GPS Commands

Command	Description	Page
!GNSSCONFIG	Configure GNSS satellite constellation support	174
!GPSAUTOSTART	Configure GPS auto-start features	175
!GPSCLRASSIST	Clear specific GPS assistance data	176
!GPSCOLDSTART	Clear all GNSS assistance data	177
!GPSEND	End an active session	177
!GPSFIX	Initiate GPS position fix	178
!GPSIDREN	Enable/disable "Info for DR" feature	179
!GPSLOC	Return last known location of the modem	180
!GPSMOMETHOD	Set/report GPS MO method	181
!GPSMTLRSETTINGS	Set/report MT location request settings	182
!GPSNMEACONFIG	Enable/disable NMEA reporting	183
!GPSNMEASENTECE	Set/report NMEA sentence type	184
!GPSSATINFO	Request satellite information	186
!GPSSTATUS	Request current status of a position fix session	187
!GPSSUPLURL	Set/report SUPL server URL	188
!GPSSUPLVER	Set/report SUPL server version	189
!GPSTRACK	Initiate local tracking (multiple fix) session	190
!GPSTRANSSEC	Control GPS transport security	191
!GPSXTRADATAENABLE	Set/report GPS XTRA settings	192
!GPSXTRADATAURL	Set/report GPS XTRA data server URLs	193
!GPSXTRASTATUS	Return current status of XTRA	194
!GPSXTRATIME	Inject GPS or UTC time into XTRA system	195
!GPSXTRATIMEENABLE	Set/report GPS XTRA time settings	196
!GPSXTRATIMEURL	Set/report GPS XTRA SNTP server URLs	197

[SIM Commands](#)— Commands used to communicate with an installed SIM.

Table 1-8: SIM Commands

Command	Description	Page
+CCID	Return SIM/eUICC ICCID and EID	201
+CCID (notification)	eUICC profile switch—Unsolicited notification	201
+CSPN	Display SIM card service provider's name (SPN)	202
!ICCID	Return SIM card's ICCID	202
+KSIMSEL	Select External SIM interface	203
!UIMS	Select active UIM interface	204

[SD Commands](#)— Commands used to communicate with an installed SD card.

Table 1-9: SD Commands

Command	Description	Page
!SDINFO	Display SD card status	206

[OMA-DM Commands](#)— Commands used to configure DM (Device Management) accounts, sessions, and host–device–server interactions.

Table 1-10: OMA-DM Commands

Command	Description	Page
!IDSDEBUGPRINT	Enable/disable debug (detailed message) printing	207
!IMSTESTMODE	Enable/disable IMS test mode	208

[SAR Backoff Commands](#)— Commands used to configure SAR options.

Table 1-11: SAR Backoff and Thermal Control Commands

Command	Description	Page
+KRFMUTE	Enable/disable RAT-specific Tx muting	210
+KRFMUTE (notification)	RAT Tx mute mode status change (unsolicited notification)	211
!MAXPWR	Set/report maximum Tx power	212
!SARBACKOFF	Set/report offset from maximum Tx power	214
!SARGPIO	Set/report External GPIO controlling SAR	217
!SARINTGPIOMODE	Set/report default pull mode for SAR interrupt GPIOs	218
!SARSTATE	Set/report SAR backoff state	218
!SARSTATEDFLT	Set/report default SAR backoff state	219

[Audio Commands](#) – Commands used to configure and manage audio-capable devices.

Table 1-12: Audio Commands

Command	Description	Page
!AVCFG	Bind audio profile to device/physical interface	221
!AVDEF	Reset configurable audio parameters to default settings	223
!AVRXG	Query/Set audio profile decoder gain	223
!AVSETPROFILE	Select/configure audio profile for CS call	224
!AVSTG	Configure AFE side tone gain	224
!AVTXG	Query/Set audio profile encoder gain	225
+CLVL	Set active audio profile's Rx volume	225
+VTS	Send DTMF tone	226

[I/O Commands](#) – Commands used to configure and manage GPIOs, ADCs and other IOs.

Table 1-13: I/O Commands

Command	Description	Page
+WEXTCLK	Enable/Disable user clock mode	228
+WIOCFG	GPIO Configuration	229
+WRID	Set/query Ring Indicator Duration	231
+WWAKESET	Set/query Wake Up Event Mask	232

[AirVantage Commands](#) – Commands used to work with AirVantage.

Table 1-14: AirVantage Device Services Commands

Command	Description	Page
+WDSC	Configure AirVantage Management Services	234
+WDSE	Display most recent AirVantage Management Services error	236
+WDSG	Display AirVantage Management Services status information	237
+WDSI	Activate/deactivate AirVantage Management Services unsolicited notifications	238
+WDSR	Reply to AirVantage server request	241
+WDSS	Configure/connect AirVantage Management Services session	242

 Protocol Commands — Internet Protocol-related Commands.

Table 1-15: Protocol Commands

Command	Description	Page
+KCGPADDR	Display module's PDP context addresses	245
+KCNX_IND (notification)	Connection Status Notification—Unsolicited notification	246
+KCNXCFG	Configure GPRS Connection	247
+KCNXDOWN	Bring down PDP connection	249
+KCNXPROFILE	Query/Set default PDP context	249
+KCNXTIMER	Configure TCP/UDP Connection Timer	250
+KCNXUP	Bring up PDP connection	251
+KHTTPCFG	Configure HTTP connection	252
+KHTTPCLOSE	Close HTTP connection	253
+KHTTPDEL	Delete configured HTTP session	254
+KHTTPGET	Get HTTP server information	255
+KIPOPT	Configure general protocol options	256
+KPATTERN	Set/query the custom end of data/file pattern	258
+KSSLCRYPTO	Cipher suite configuration	259
+KSSLCFG	SSL Configuration	2614.0
+KTCP_DATA (notification)	Incoming Data through TCP connection—Unsolicited notification	262
+KTCP_IND (notification)	TCP status—Unsolicited notification	262
+KTCP_SRVREQ (notification)	Incoming client connection request—Unsolicited notification	263
+KTCPCFG	Configure TCP connection	265
+KTCPCLOSE	Close current TCP connection	267
+KTCPCNX	Start TCP connection	268
+KTCPDEL	Delete configured TCP session	269
+KTCPRCV	Receive data through TCP connection	270
+KTCPSEND	Send data through TCP connection	271
+KTCPSTART	Start TCP connection in Direct Data Flow	272
+KTCPSTAT	Get TCP socket status	273
+KUDP_DATA (notification)	Incoming Data through UDP connection—Unsolicited notification	274
+KUDP_IND (notification)	UDP status—Unsolicited notification	274
+KUDPCFG	Configure UDP connection	275
+KUDPCLOSE	Close current UDP connection	277

Table 1-15: Protocol Commands (Continued)

Command	Description	Page
+KUDPDEL	Delete configured UDP session	277
+KUDPRCV	Receive data through UDP connection	278
+KUDPSND	Send data through UDP connection	279
+KURCCFG	Enable/Disable Protocol Notifications (URCs)	280

Conventions

The following format conventions are used in this reference:

Character codes or keystrokes that are described with words or standard abbreviations are shown within angle brackets using a different font, such as <CR> for Carriage Return and <space> for a blank space character.

Numeric values are decimal unless prefixed as noted below.

Hexadecimal values are shown with a prefix of 0x, i.e. in the form 0x3D.

Binary values are shown with a prefix of 0b, i.e. in the form 0b00111101.

Command and register syntax is noted using an alternate font: **!CHAN=<c>[,b]**. The leading “AT” characters are not shown but must be included before all commands except as noted in the reference tables.

Characters that are required are shown in uppercase; parameters are noted in lowercase. Required parameters are enclosed in angle brackets (<n>) while optional parameters are enclosed within square brackets ([x]). The brackets are not to be included in the command string.

Commands are presented in table format. Each chapter covers the commands related to that subject and presents a summary table to help locate needed commands. Commands are in ASCII alphabetical order in the body of each chapter.

Any default settings are noted in the command tables. Note that these are the factory default settings and *not* the default parameter value assumed if no parameter is specified.

Result Code This is a numeric or text code that is returned after all commands (except resets) — text codes are returned if verbose responses are enabled. Only one result code is returned for a command line regardless of the number of individual commands contained on the line.

Response This term indicates a response from the modem that is issued prior to a result code. Reading registers or issuing commands that report information will provide a response followed by a result code unless the command generates an error.

Responses and result codes from the modem, or host system software prompts, are shown in this font:

```
CONNECT 14400
```

>> 2: AT Password Commands

Introduction

AT commands described in this document are password-protected. This chapter describes how to enter and change the password.

Command summary

[Table 2-1](#) on page 21 lists the commands described in this chapter.

Table 2-1: AT Password Commands

Command	Description	Page
!ENTERCND	Enable access to password-protected commands	22
!SETCND	Set AT command password	23

Command reference

Table 2-2: AT Password Command Details

Command	Description
!ENTERCND	<p>Enable access to password-protected commands</p> <p>Before any password-protected AT commands can be used, !ENTERCND must be used to enter the password to gain access. The initial password is configured onto the modem during manufacture. You can change the password using !SETCND. If you do not know the password, contact your Sierra Wireless account manager.</p> <p>Once the password has been entered correctly, the password-protected AT commands are available until the modem is reset or powered off and on.</p> <p>Password required: Yes—Query format only. Reset required to apply changes: No Persistent across power cycles: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!ENTERCND=<"key"> Response: OK Purpose: Unlock password-protected commands. • Query: AT!ENTERCND? Response: <key> (if unlocked) Purpose: This command is password-protected. After entering the password correctly using the execution operation ("="), you can use this command to display the password as a reminder. <p>Parameters:</p> <p><"key"> (Password stored in NV memory)</p> <ul style="list-style-type: none"> • Password must be entered with quotation marks. (For example, AT!ENTERCND="ExamplePW".) • Length: 4–15 characters • Supported characters: '0'–'9', 'A'–'Z', 'a'–'z', special characters (e.g. "!#\$%&'()*+,-./:;<>=?@") Note: Double quotes (") are not allowed. • Characters may be entered in ASCII format, or in Hex format. (For example: "myPass3" or "ABCDEF01234".)

Table 2-2: AT Password Command Details (Continued)

Command	Description
!SETCND	<p>Set AT command password</p> <p>Change the password used for the !ENTERCND command. (Before you can change the password using !SETCND, you must enable access to this command using !ENTERCND.)</p> <p>Password required: Yes (see !ENTERCND for details)</p> <p>Reset required to apply changes: No</p> <p>Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!SETCND=<"key"> Response: OK Purpose: Sets <"Key"> as the new password for accessing protected commands. <p>Parameters:</p> <p><"key"> (New password)</p> <ul style="list-style-type: none"> • Password must be entered with quotation marks (for example, AT!SETCND="NewPW"). • Length: 4–15 characters • Supported characters: '0'–'9', 'A'–'Z', 'a'–'z', special characters (e.g. "!#\$%&'()*+,-./:;<>=?@") <p>Note: Double quotes (") are not allowed.</p> <ul style="list-style-type: none"> • Characters may be entered in ASCII format, or in Hex format. (For example: "myPass3" or "ABCDEF01234".) <hr style="border: 1px solid red;"/> <p>Warning: Do NOT enter a null password (that is, the <"Key"> cannot be "") — you will NOT be able to use password-protected commands, and will have to contact Sierra Wireless for help to reset the password.</p> <hr style="border: 1px solid red;"/>

>> 3: Modem Status, Customization, and Reset Commands

Introduction

This chapter describes commands used to reset the modem, adjust customization settings, retrieve the hardware version, and monitor the temperature, voltage, and modem status.

Command summary

Table 3-1 lists the commands described in this chapter.

Table 3-1: Modem Status Commands

Command	Description	Page
+++	Switch from Data Mode to Command Mode	27
!ADC	Read ADC value	28
!ANTSEL	Set/query external antenna select configuration	29
!BAND	Select/return frequency band set	31
!BOOTHOLD	Reset modem and wait in bootloader for firmware download	33
!BSGPIO	Query/Set GPIO signal level/direction	34
+CBST	Select Circuit-Switched Bearer	36
+CESQ	Extended Signal Quality	37
+CGACT	Activate/deactivate PDP context	39
+CGAUTH	Set/Report PDP connection authentication parameters	40
+CGDCONT	Define PDP context	41
+CMEE	Report mobile termination error	42
+CMUX	Configure Multiplexing Control Channel	43
+CPSMS	Configure Power Saving Mode (PSM)	45
+CPWROFF	Power Off	46
+CSQ	Display signal quality	46
+CSQ (notification)	RSSI change across threshold—Unsolicited notification	47
!CUSTOM	Set/return customization settings	48
!GCFEN	Enable/disable GCF testing mode	54
!GSTATUS	Return operational status	55
!HWID	Read hardware ID	63

Table 3-1: Modem Status Commands (Continued)

Command	Description	Page
!IMAGE	Manage Firmware Images	66
I	Display product identification information	64
!IMPREF	Query/set Image Management preferences	68
&K	Flow Control	68
+KCCINFO	Enable/disable camped cell information notifications	69
+KCCINFO (notification)	Camped cell parameter change—Unsolicited notification	70
+KCELL	Display Detected Cell Details	71
+KGSN	Request Product Serial Number Identification and Software Version	74
+KMCLASS	Set 2G multislot class	75
+KSIMDET	Enable/Disable SIM Detection notifications	76
+KSLEEP	Configure UART1 power management (sleep mode entry conditions)	77
+KSRAT	Set the current RAT	78
+KSREP	Enable/disable startup reporting	79
+KSUP (notification)	Startup notification (unsolicited notification)	79
!MAPUART	Map services to UART	80
!MUXMODE	Enable/disable CMUX mode	81
!NETNUM	Set/report number of supported network interfaces	81
!NVBACKUP	Backup NV data	82
!PACKAGE	Return package version string	82
!PATEMP	Return PA temperature information	83
!PATEMP (notification)	PA temperature state change—Unsolicited notification	83
!PCINFO	Return power control status information	84
!PCTEMP	Return Power control temperature information	85
!PCTEMP (notification)	PMIC temperature state change—Unsolicited notification	85
!PCTEMPLIMITS	Set/report temperature state limit values	86
!PCVOLT	Return current power supply voltage information	87
!PCVOLT (notification)	PMIC voltage state change—Unsolicited notification	87
!PCVOLTLIMITS	Set/report power supply voltage state limit values	88
!POWERDOWN	Power down system	88
!POWERMODE	Enable/disable PSM	89
!POWERWAKE	Configure PSM wakeup sources	90

Table 3-1: Modem Status Commands (Continued)

Command	Description	Page
!PRIID	Report module PRI part number and revision	91
*PSRDBS	Select operating bands	92
!RESET	Reset modem	93
+RSCP	Display RSCP value(s) (WCDMA only)	94
S11	Query/set DTMF dialing speed	95
!SCACT	Activate/deactivate data connection	96
!SCUMMTU	Set/Report MTU Size	97
!SELACQ	Select RAT acquisition order	98
!SELCIOT	Set/report Cellular IoT preferences	99
!SELMODE	Set/return current service domain	100
!SELRAT	Set preferred RAT	101
!SELSNR	Set/report LTE-NB1 band scan configuration	103
+SIM (notification)	SIM inserted/removed—Unsolicited notification	103
!SKU	Read Module SKU	104
!USBCOMP	Set/report USB interface configuration	105
!USBINFO	Return information from active USB descriptor	106
!USBPID	Set/report product ID in USB descriptor	107
+WFWUPD	Download/install firmware package	108
+WFWUPD (notification)	Firmware package install notification	109
+WJAM (notification)	Jamming events—Unsolicited notification	110
+WJAMTHRESH	Set/Report Jamming Detection Threshold Value	111
+WUSLMSK	Enable/disable unsolicited notifications	112

Command reference

Table 3-2: Modem Status Command Details

Command	Description
+++	<p>Switch from Data Mode to Command Mode</p> <p>Notes:</p> <ul style="list-style-type: none">• This command is only available during data mode. The +++ character sequence suspends the data flow over the AT interface and switches to command mode. This allows entering AT commands while maintaining the data connection to the remote device.• To return to data mode, use ATO[n].• Line needs one second silence before and one second after (do not end with terminating character).• The "+" character may be changed with ATS2.• The +++ characters are not transmitted in the data flow. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none">• Execution: +++• Response: OK <p>Parameters:</p> <p>None</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!ADC	<p>Read ADC value Return the reading for a specified ADC channel. Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Query: ATIADC?<input_string> Response: !ADC: <adc_reading> [(mV)] OK or ADC error = 3 <i>(This indicates an invalid <input_string> channel was used.)</i> OK or ERROR <p>Purpose: Display the reading from the specified input source.</p> <ul style="list-style-type: none"> • Query List: ATIADC=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><input_string> (Input source)</p> <ul style="list-style-type: none"> • ASCII string • Valid options: <ul style="list-style-type: none"> • VBATT • PA_THERM • PMIC_THERM • XO_THERM • ADC0 • ADC1 <p><adc_reading> (Value read from input source)</p> <ul style="list-style-type: none"> • Unsigned integer

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!ANTSEL	<p>Set/query external antenna select configuration</p> <p>Configure the modem to use GPIOs (GPIO28–31) to select the antenna to use for each specified frequency band. (Any of the available GPIOs that are not needed for a specific band should be configured as not required.)</p> <p>When the modem switches to a frequency band that has been configured using this command, the GPIOs are driven as specified and the host uses them to tune the external antenna appropriately.</p> <p>If the modem switches to a band that has not been configured, the host uses the default antenna.</p> <hr/> <p><i>Note: Frequency bands are RAT-independent. For example, Band 5 corresponds to any 850-band technology (CDMA, WCDMA, LTE, GSM).</i></p> <hr/> <p>Requirements: Before this command can be used:</p> <ul style="list-style-type: none"> Antenna selection is the secondary configuration for GPIO28–GPIO31. To use these GPIOs for antenna selection, use +WIOCFG to deallocate them from their current purpose(s). <p>Notes: When designing the system, and configuring the device:</p> <ul style="list-style-type: none"> Perform system level testing to ensure that the antenna switching feature does not introduce any handover issues. The tunable antenna should be designed to ensure that it can retune in < 5 μs (recommended) and < 10 μs (maximum). <p>Password required: Yes (see !ENTERCND for details)</p> <p>Reset required to apply changes: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT!ANTSEL=<band>, <gpio1>, <gpio2>, <gpio3>[, <gpio4>] Response: OK Purpose: Configure the GPIOs for the specified <band>. Query: AT!ANTSEL? Response: BAND <band a>: <gpio1>, <gpio2>, <gpio3>[, <gpio4>] BAND <band b>: <gpio1>, <gpio2>, <gpio3>[, <gpio4>] ... Conflict: <i>(Note: No details displayed for RC76xx devices.)</i> OK <p>Example: BAND 2: 1, 0, 1, 1 BAND 5: 1, 1, 2, 2</p> <p>Conflict: OK</p> <p>Purpose: Display the current external antenna select configuration.</p> <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!ANTSEL (continued)	<p>Set/query external antenna select configuration (continued)</p> <ul style="list-style-type: none"> Query List: ATIANTSEL=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><band> (RF band)</p> <ul style="list-style-type: none"> 3GPP band number. For a full listing of 3GPP band numbers, see Table 18-2 on page 290. Valid range: 1–71. Band support is product specific—see the device’s Product Specification or Product Technical Specification document for details. <p><gpio1>, <gpio2>, <gpio3>, <gpio4> (GPIO configurations)</p> <ul style="list-style-type: none"> 0=Logic low 1=Logic high 2=Not used for antenna selection (Default value for <gpio4>). Notes: <gpio4> availability is device-specific—see the module’s Product Technical Specification for details.

Table 3-2: Modem Status Command Details (Continued)

Command	Description
<p>!BAND</p> <hr/> <p><i>Note: The 'Basic' command and response versions are used if you haven't entered the required password. (See Command access on page 9.)</i></p> <hr/>	<p>Select/return frequency band set</p> <p>Configure the modem to operate on a set of frequency bands, look up available sets, create new sets, or return the current selection.</p> <hr/> <p>Important: To avoid issues with incompatible RAT/band combinations:</p> <ul style="list-style-type: none"> • If !BAND is used, +KSRAT must be set to 'All RATS, automatic'. • If !BAND and !SELRAT are used, either !BAND must be set to 'All Bands' or !SELRAT must be set to 'Automatic'. • If +KSRAT is used, !BAND must be set to 'All Bands' and !SELRAT must not be used. <hr/> <p><i>Note: The "02 User bands" set can also be changed using AT*PSRDBS on page 92 by selecting a set of bands that does not match any of the existing band sets.</i></p> <hr/> <p>Password required: Yes—Execution (Extended) format (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution (Basic): <ul style="list-style-type: none"> AT!BAND=<Index> Response: OK Purpose: Select an existing set of bands. • Execution (Extended): <ul style="list-style-type: none"> AT!BAND=<Index>,"<Name>",<GWmask>[,<Lmask>[,<Lmask2>]] Response: OK Purpose: Create a new set of bands for the specified <index> position and assign a descriptive <Name> to the set. • Query (Basic): <ul style="list-style-type: none"> AT!BAND? Response: Index, Name <Index>, <Name> OK or (If the current band mask doesn't match a band set) Unknown band mask. Use AT!BAND to set band. <bandmask> OK Purpose: Report the current band selection. • Query (Extended): <ul style="list-style-type: none"> AT!BAND? Response: Index, Name, GW Band Mask L Band Mask 1 L Band Mask 2 <Index>, <Name>, <GWmask> <Lmask> <Lmask2> OK or (If the current band mask doesn't match a band set) Unknown band mask. Use AT!BAND to set band. <Index> OK Purpose: Report the current band selection. (<GWmask>, <Lmask>, and <Lmask2> will appear only in Extended responses, and only if applicable.) <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!BAND (continued)	<p>Select/return frequency band set (continued)</p> <ul style="list-style-type: none"> Query List (Basic): <p>ATIBAND=?</p> <p>Response: Index, Name <Index1>, <Name1> ... <IndexN>, <NameN> OK</p> <p>Purpose: Display allowed <Index> values and descriptions of the associated band sets.</p> Query List (Extended): <p>ATIBAND=?</p> <p>Response: Index, Name, GW Band Mask L Band Mask 1 L Band Mask 2 <Index1>, <Name1>, <GWmask1> <Lmask1(1)> <Lmask2(2)> ... <IndexN>, <NameN>, <GWmaskN> <LmaskN(1)> <LmaskN(2)></p> <p style="text-align: center;"><LBand> ... <LBandN></p> <p style="text-align: center;"><GWBand> ... <GWBand></p> <p>OK</p> <p>Purpose: Display allowed <Index> values and descriptions of the associated band sets. (<GWmask...> and <Lmask...> will appear only in Extended responses, and only if applicable.) After the masks, lists of each bands comprising the masks are also shown.</p> <p>Parameters:</p> <p><Index> (Index of a band set. Use the Query List command to display all supported sets)</p> <ul style="list-style-type: none"> Valid range: 0–13 (Hexadecimal—there are 20 possible values. By default, '0' indicates 'All bands'.) Example values: 00 01 02 <p><Name> (Name of the band set)</p> <ul style="list-style-type: none"> ASCII string—Up to 30 characters Example values: All bands Europe 3G GSM ALL WCDMAALL <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
<p>!BAND (continued)</p>	<p>Select/return frequency band set (continued)</p> <p><GWmask> (GSM/WCDMA bands included in the set)</p> <ul style="list-style-type: none"> • Format: 64-bit bitmask • Example values (Available bands are device-dependent. Use the extended query command to display the list of bands available for your device): <pre>0000000000000001—BC0-A 0000000000000002—BC0-B ... 0000000080000000—BC15 0002000000000000—W9001000000000000—B19 (850)</pre> <p><Lmask>, <Lmask2> (LTE bands included in the set)</p> <ul style="list-style-type: none"> • Format: 64-bit bitmask • Example values (Available bands are device-dependent. Use the extended query command to display the list of bands available for your device.): <pre>0000000000000001—Band 1 0000000000000002—Band 2 ... 0000008000000000—Band 40 0000010000000000—Band 41</pre> <p><LBand> (List of individual LTE bands forming the <Lmask>)</p> <ul style="list-style-type: none"> • Format: <mask> - <description>. See <GWBand> for a GSM/WCDMA example. <p><GWBand> (List of individual GSM/WCDMA bands forming the <GWmask>)</p> <ul style="list-style-type: none"> • Format: <mask> - <description>. • Example: <pre>1000000000000000 - B19 (800) 0002000000000000 - B8 (900) 0000000080000000 - B6 (800) 0000000040000000 - B5 (850) 0000000008000000 - B2 (1900) 0000000004000000 - B1 (2100) 0000000002000000 - G1900 0000000000800000 - G850 00000000000200 - G900P 000000000000100 - G900E 000000000000080 - G1800</pre>
<p>!BOOTHOLD</p>	<p>Reset modem and wait in bootloader for firmware download</p> <p>Prepare for a firmware download by resetting the modem and waiting in 'boot and hold' mode. Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!BOOTHOLD • Response: OK • Purpose: Force the modem to backup user NV options, reset, and then wait in boot and hold mode for a firmware download.

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!BSGPIO	<p>Query/Set GPIO signal level/direction</p> <p>Query or set the level or direction of a GPIO signal. If changing the level or direction, reset the modem to have the change take effect. To ensure the command is used safely, the following usage procedure is recommended:</p> <ol style="list-style-type: none"> 1. Before modifying the GPIO, check the schematic of the hardware being tested and determine if the GPIO is an input or output. 2. Use this command to query the GPIO (to check its current functionality) or set the GPIO line (to provide the functionality required for the hardware). 3. Reset the modem to make the change take effect. <p>Caution(s):</p> <ul style="list-style-type: none"> • When setting the level or direction, make sure the selected option will properly function on the GPIO. If an invalid setting is selected for a specific GPIO (e.g. changing an input to an output, or vice-versa), the circuit could be damaged depending on the hardware configuration. • Some GPIOs have alternate functions. If this command is used to query or set a different level or direction, the alternate function is no longer programmed and the modem will likely not function as expected. • Sometimes the alternate function is persistent because the QCOM stack reprograms it periodically while the stack is running. Thus, you can see some unexpected results when using this command. For example, GPIO12 has an alternate function (GRFC9) which is an RF control signal used by QCOM. If you change this line to be an output (for instance), your chosen level will only persist on the output until the next QCOM stack refresh happens. In this specific case, you can disable the stack with the AT+CFUN=0 command and the problem goes away. • This command changes the programming of the selected GPIO (e.g. from an input to an output, etc.). If the wrong setting is selected, the circuit could be damaged (e.g. if an input GPIO is changed to output, the connected device may not be able to tolerate an input from the module.) <p>Password required: Yes (see IINTERCND for details) Reset required to apply changes: Yes</p> <p>Notes:</p> <ul style="list-style-type: none"> • Command is used to configure the bearer to be used for future IP services. <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!BSGPIO=<gpionumber>,<level> Response: OK Purpose: Set the signal level for the specified GPIO. • Query: AT!BSGPIO?<gpionumber> Response: Number: <gpionumber> Function: <gpiofunction> Direction: <gpiodir> Pull: <gpiopull> Drive: <gpiodrive> State: <gpiostate> <p>OK Purpose: Display the current settings for the specified GPIO.</p> <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!BSGPIO (continued)	<p>Query/Set GPIO signal level (continued)</p> <ul style="list-style-type: none"> • Query List: AT!BSGPIO=? • Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><gpionumber> (RF band)</p> <ul style="list-style-type: none"> • Valid range: 0–max (Note: Max value is chipset-dependent) <p><level> (level/direction)</p> <ul style="list-style-type: none"> • 0—Set output to low voltage level • 1—Set output to high voltage level • 2—Set GPIO pin as input <p><gpiofunction> (GPIO pin functionality)</p> <ul style="list-style-type: none"> • 0—GPIO • 1–max—Alternate function. (Note: Alternate function(s) are GPIO pin-dependent.) <p><gpiodir> (GPIO direction)</p> <ul style="list-style-type: none"> • 0—Input • 1—Output <p><gpiopull> (Pull type on GPIO)</p> <ul style="list-style-type: none"> • 0—No pull • 1—Pull-down • 2—Keeper • 3—Pull-up <p><gpiodrive> (GPIO drive strength)</p> <ul style="list-style-type: none"> • 0—2 mA • 1—4 mA • 2—6 mA • 3—8 mA • 4—10 mA • 5—12 mA • 6—14 mA • 7—16 mA <p><gpiostate> (GPIO low/high state)</p> <ul style="list-style-type: none"> • 0—Low • 1—High

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+CBST	<p>Select Circuit-Switched Bearer</p> <p>Select the circuit-switched bearer to use for data calls (mobile-originated or mobile-terminated).</p> <p>Notes: Only the following combinations are supported—If other combinations of valid parameter values are specified, ERROR will be returned:</p> <ul style="list-style-type: none"> • <speed>=valid values up to 83; <name>=0; <ce>=1 • <speed>=83; <name>=4; <ce>=1 • <speed>=116 or 134; <name>=1; <ce>=0 <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+CBST=[<speed>],[<name>],[<ce>] Response: OK Purpose: Configure the circuit-switched bearer. • Query: AT+CBST? Response: +CBST: <speed>,<name>,<ce> OK Purpose: Report current settings. • Query List: AT+CBST=? Purpose: Return the execution command format and the supported parameter values. <p>Parameters:</p> <p><speed> (Data call connection speed)</p> <ul style="list-style-type: none"> • 0—(Default) Autobaud (automatic speed selection) • 7—9600 bps (V.32) • 12—9600 bps (V.34) • 14—14400 bps (V.34) • 16—28800 bps (V.34) • 17—33600 bps (V.34) • 39—9600 bps (V.120) • 43—14400 bps (V.120) • 48—28800 bps (V.120) • 51—56000 bps (V.120) • 71—9600 bps (V.110) • 75—14400 bps (V.110) • 80—28800 bps (V1.110) • 81—38400 bps (V.110) • 83—56000 bps (X.31 flag stuffing, UDI/RDI) • 116—64000 bps (bit transparent) • 134—64000 bps (multimedia) <p><name> (Bearer Service)</p> <ul style="list-style-type: none"> • 0—(Default) Data circuit asynchronous (UDI or 3.1 kHz modem) • 1—UI Data circuit synchronous (UDI or 3.1 kHz modem) • 4—Data circuit asynchronous (RDI) <p><ce> (Connection element)</p> <ul style="list-style-type: none"> • 0—Data transparent • 1—Data non-transparent

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+CESQ	<p>Extended Signal Quality</p> <p>Notes:</p> <ul style="list-style-type: none"> • If the current serving cell is not a GERAN cell, <rxlev> and <ber> are set to value 99. • If the current serving cell is not a UTRA FDD or UTRA TDD cell, <rscp> is set to 255. • If the current serving cell is not a UTRA FDD cell, <ecno> is set to 255. • If the current serving cell is not an E-UTRA cell, <rsrq> and <rsrp> are set to 255 • Therefore, the RC76xx returns 99 for rxlev/ber, and 255 for rscp/ecno. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+CESQ Response: +CESQ: <rxlev>, <ber>, <rscp>, <ecno>, <rsrq>, <rsrp> OK Purpose: Display signal quality parameters. • Query List: AT+CESQ=? Purpose: Display valid parameter values. <p>Parameters:</p> <p><rxlev> (Received signal strength level (see 3GPP TS 45.008 [20] subclause 8.1.4))</p> <ul style="list-style-type: none"> • 0—rssi < -110 dBm • 1—-110 dBm ≤ rssi < -109 dBm • 2—-109 dBm ≤ rssi < -108 dBm • ... • 61—-50 dBm ≤ rssi < -49 dBm • 62—-49 dBm ≤ rssi < -48 dBm • 63—-48 dBm ≤ rssi • 99—Not known or not detectable <p><ber> (Channel bit error rate, in percent)</p> <ul style="list-style-type: none"> • 0–7—As RXQUAL values in the table in 3GPP TS 45.008 [20] subclause 8.2.4 • 99—Not known or not detectable <p><rscp> (Received signal code power (see 3GPP TS 25.133 [95] subclause 9.1.1.3 and 3GPP TS 25.123 [96] subclause 9.1.1.1.3))</p> <ul style="list-style-type: none"> • 0—rscp < -120 dBm • 1—-120 dBm ≤ rscp < -119 dBm • 2—-119 dBm ≤ rscp < -118 dBm • ... • 94—-27 dBm ≤ rscp < -26 dBm • 95—-26 dBm ≤ rscp < -25 dBm • 96—-25 dBm ≤ rscp • 255—Not known or not detectable <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+CESQ (continued)	<p>Extended signal quality (continued)</p> <p><ecno> (Ratio of the received energy per PN chip to the total received power spectral density (see 3GPP TS 25.133 [95] subclause))</p> <ul style="list-style-type: none"> • 0—$Ec/I_0 < -24$ dBm • 1—-24 dBm $\leq Ec/I_0 < -23.5$ dBm • 2—-23.5 dBm $\leq Ec/I_0 < -23$ dBm • ... • 47—-1 dBm $\leq Ec/I_0 < -0.5$ dBm • 48—-0.5 dBm $\leq Ec/I_0 < 0$ dBm • 49—0 dBm $\leq Ec/I_0$ • 255—Not known or not detectable <p><rsrq> (Reference signal received quality (see 3GPP TS 36.133 [96] subclause 9.1.7))</p> <ul style="list-style-type: none"> • 0—rsrq < -19.5 dBm • 1—-19.5 dBm \leq rsrq < -19 dBm • 2—-19 dBm \leq rsrq < -18.5 dBm • ... • 32—-4 dBm \leq rsrq < -3.5 dBm • 33—-3.5 dBm \leq rsrq < -3 dBm • 34—-3 dBm \leq rsrq • 255—Not known or not detectable <p><rsrp> (Reference signal received power (see 3GPP TS 36.133 [96] subclause 9.1.4))</p> <ul style="list-style-type: none"> • 0—rsrp < -140 dBm • 1—-140 dBm \leq rsrp < -139 dBm • 2—-139 dBm \leq rsrp < -18 dBm • ... • 95—-46 dBm \leq rsrp < -45 dBm • 96—-45 dBm \leq rsrp < -44 dBm • 97—-44 dBm \leq rsrp • 255—Not known or not detectable

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+CGACT	<p>Activate/deactivate PDP context Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+CGACT=[<state>[, <cid>[, <cid>[, ...]]]] Response: OK or CME ERROR: <err> • Purpose: Activate or deactivate the specified PDP contexts. • Query: AT+CGACT? Response: [+CGACT: <cid>, <state>] [+CGACT: <cid>, <state>]... OK • Purpose: Display the activation states of all defined PDP contexts. • Query List: AT+CGACT=? Purpose: Return the supported <state> values. <p>Parameters:</p> <p><cid> (PDP context identifier)</p> <ul style="list-style-type: none"> • Valid range: 1–24. • Maximum # of usable PDP contexts: 16 <p><state> (PDP context activation state)</p> <ul style="list-style-type: none"> • 0—Deactivated • 1—Activated

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+CGAUTH	<p>Set/Report PDP connection authentication parameters</p> <p>Set or report the authentication parameters for a PDP context. The context is identified by the supported profile that was used during the PDP context activation and PDP context modification procedures.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+CGAUTH=<cid>,<auth_prot>[, <userid>,<password>] Response: OK or ERROR Purpose: Set the required authentication type and related values for the specified PDP profile (<cid>). • Query: AT+CGAUTH? Response: +CGAUTH: <cid>, <auth_prot>[,<userid>] ... OK Purpose: Display the authentication type and (if required) the username required for each profile. (Note: The <password> does not appear, for security reasons.) • Query List: AT+CGAUTH=? Purpose: Return the execution command format and the supported parameter values. <p>Parameters:</p> <p><cid> (PDP context identifier)</p> <ul style="list-style-type: none"> • Valid range: 1–24. • Maximum # of usable PDP contexts: 16 <p><auth_prot> (Required authentication type)</p> <ul style="list-style-type: none"> • 0—None. Username and password are not required. • 1—PAP. Username and password accepted • 2—CHAP. Username and password (secret) accepted <p><userid> (Username for PAP/CHAP authentication)</p> <ul style="list-style-type: none"> • ASCII string within quotes (e.g. "userid") • Required for <auth_type> 1 (PAP) and 2 (CHAP) <p><password> (Password for PAP/CHAP authentication)</p> <ul style="list-style-type: none"> • ASCII string within quotes (e.g. "123456") • Required for <auth_type> 1 (PAP) and 2 (CHAP)

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+CGDCONT	<p>Define PDP context Define PDP (Packet Data Protocol) parameter values for a specific PDP context.</p> <p><i>Note: This implementation of +CGDCONT is derived from the 3GPP TS 27.007 version 13.2.0 specification, but does not support the full set of parameters from the specification and has extended usage rules.</i></p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+CGDCONT=<cid>[, <PDP_type> [, <apn> [, <PDP_addr> [, <d_comp> [, <h_comp> [, <pd1> [... [, <pdN>]]]]]]]]] Response: OK Purpose: Set the specified parameter values for the PDP context identified by <cid>. If only <cid> is specified, all parameter values are stored as undefined. • Query: AT+CGDCONT? Response: +CGDCONT: <cid>, <PDP_type>, <apn>, <PDP_addr>, <d_comp>, <h_comp>[, <pd1>[, ...[, <pdN>]]] ... OK Purpose: Report the current settings for each defined PDP context. • Query List: AT+CGDCONT=? Purpose: Return the execution command format and the supported parameter values. If multiple PDP types (<PDP_type>) are supported, the parameters for each <PDP_type> are returned on a separate line. <p>Parameters:</p> <p><cid> (PDP context identifier)</p> <ul style="list-style-type: none"> • Valid range: 1–24. • Maximum # of usable PDP contexts: 16 <p><PDP_type> (Packet Data Protocol type)</p> <ul style="list-style-type: none"> • "IP"—Internet Protocol, version 4 (IETF STD 5) • "IPV6"—Internet Protocol, version 6 (IETF RFC 2460) • "IPV4V6"—Virtual type that handles dual IP stack UE capability (3GPP TS 24.301[83]) Note: IPv4v6 is compliant up to 3GPP Release 7. <p><APN> (Access Point Name)</p> <ul style="list-style-type: none"> • ASCII string within quotes • Logical name used to select GGSN or external packet data network • If null or omitted, subscription value will be requested <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+CGDCONT (continued)	<p>Define PDP context (continued)</p> <p><PDP_addr> (Access Point Name)</p> <ul style="list-style-type: none"> • ASCII string within quotes • Identifies the MT in the address space applicable to the PDP. • If the value is null or omitted then a value may be provided by the TE during the PDP startup procedure or, failing that, a dynamic address will be requested. The READ command will continue to return the null string even if an address has been allocated during the PDP startup procedure. The allocated address may be read using the +CGPADDR command. • When +CGPIAF is supported, its settings can influence the format of this parameter returned with the read form of +CGDCONT. • Note: The value of this parameter is ignored with the set command. The parameter is included in the set command for backwards compatibility reasons only. <p><d_comp> (Data compression)</p> <ul style="list-style-type: none"> • Applies to SNDTCP (Sub Network Dependent Convergence Protocol) only • 0—(Default) Off. • 1—On (Manufacturer preferred compression) • 2—V.42 bis <p><h_comp> (PDP header compression)</p> <ul style="list-style-type: none"> • 0—(Default) Off. • 1—On (Manufacturer preferred compression) • 2—RFC1144 (applies to SNDTCP only) • 3—RFC2507 • 4—RFC3095 (applies to PDCP only) <p><pd1>, ... <pdN> (<PDP_type>-specific values))</p> <ul style="list-style-type: none"> • Zero to N string parameters • Parameter meanings are specific to <PDP_type>
+CMEE	<p>Report mobile termination error</p> <p>Select the method for reporting errors—+CME ERROR with result code, or ERROR.</p> <p>Notes:</p> <ul style="list-style-type: none"> • Session must be closed using +KHTTPCLOSE before using this command. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+CMEE=[<n>] Response: OK Purpose: Select the error reporting method. • Query: AT+CMEE? Response: +CMEE: <n> OK Purpose: Display the current error reporting method. • Query List: AT+CMEE=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><n> (CME error reporting state)</p> <ul style="list-style-type: none"> • 0—Disabled. Use "ERROR." • 1—Enabled. Use "+CME ERROR: <err>" with numeric <err> result codes.

Table 3-2: Modem Status Command Details (Continued)

Command	Description
<p>+CMUX</p>	<p>Configure Multiplexing Control Channel Enable/disable multiplexing protocol control channel over the UART or USB modem port (selected via !MUXMODE).</p> <hr/> <p><i>Note: When entering cmux mode, the RC76xx can access only DLC ports.</i></p> <hr/> <p>Password required: No</p> <p>Requirements:</p> <ul style="list-style-type: none"> AT!MUXMODE must be used to select either the UART or USB port before this command can be used. (The command returns ERROR if a port has not been selected.) <p>Usage:</p> <ul style="list-style-type: none"> Execution: <p>AT+CMUX=<mode>[,<subset>[,<port_speed>[,N1>[,<T1>[,<N2>[,<T2>[,<T3>[,<k>]]]]]]]]]</p> <p>Response: OK</p> <p>Purpose: Configure the multiplexing control channel.</p> Query: <p>AT+CMUX?</p> <p>Response: +CMUX: <mode>,<subset>,<port_speed>,<N1>,<T1>,<N2>,<T2>,<T3>,<k></p> <p>OK</p> <p>Purpose: Report current settings.</p> Query List: <p>AT+CMUX=?</p> <p>Purpose: Return the execution command format and the supported parameter values.</p> <p>Parameters:</p> <p><mode> (Multiplexer transparency mechanism (mux mode))</p> <ul style="list-style-type: none"> 0—(Default) Basic option <p><subset> (Multiplexer control channel setup)</p> <ul style="list-style-type: none"> 0—(Default) UIH frames 1—UI frames 2—I frames (Note: Not supported in Basic mux mode (<mode>=0)) <p><port_speed> (Transmission rate)</p> <ul style="list-style-type: none"> Note: Not supported. Valid value must be specified, but has no effect. 1—9600 bps 2—19200 bps 3—38400 bps 4—57600 bps 5—115200 bps 6—230400 bps <p><N1> (Frame size, in bytes)</p> <ul style="list-style-type: none"> Valid range: 1–32786 Default: 31 Note—Selected size should be large enough to contain a complete protocol frame. The default value is recommended. <p>Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+CMUX (continued)	<p>Configure Multiplexing Control Channel (continued)</p> <p><T1> (Acknowledgement Timer, in 0.01 second increments)</p> <ul style="list-style-type: none"> • Note: Not supported. Valid value must be specified, but has no effect. • Valid range: 1–255 • Default: 10 <p><N2> (Number of re-transmissions)</p> <ul style="list-style-type: none"> • Valid range: 0–100 • Default: 3 <p><T2> (Response timer for multiplexer control channel, in 0.01 second increments)</p> <ul style="list-style-type: none"> • Valid range: 2–255 • Default: 30 <p><T3> (Wake-up timer, in seconds)</p> <ul style="list-style-type: none"> • Valid range: 1–255 • Default: 10 <p><k> (Window size)</p> <ul style="list-style-type: none"> • Note: Not supported. Valid value must be specified, but has no effect. • Valid range 1—7 • Default: 2

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+CPSMS	<p>Configure Power Saving Mode (PSM) Enable/disable and configure the UE's Power Saving Mode parameters.</p> <hr/> <p><i>Note: This implementation of +CPSMS follows 3GPP TS 27.007, with exceptions as noted in the parameter descriptions.</i></p> <hr/> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+CPSMS=<mode>[, <Requested_Periodic-RAU>], [<Requested_GPRS-READY-timer>], [<Requested_Periodic-TAU>], [<Requested_Active-Time>] Response: OK or +CME ERROR: <err> Purpose: Enable/disable PSM, and configure PSM settings. • Query: AT+CPSMS? Response: +CPSMS: <mode>, [<Requested_Periodic-RAU>], [<Requested_GPRS-READY-timer>], [<Requested_Periodic-TAU>], [<Requested_Active-Time>] OK Purpose: Report current PSM status and settings. • Query List: AT+CPSMS=? Purpose: Return the execution command format and the supported parameter values. <p>Parameters:</p> <p><mode> (Enable/Disable PSM)</p> <ul style="list-style-type: none"> • 0—Disable PSM • 1—Enable PSM <p><Requested_Periodic-RAU> (3G Routing Area Update timer)</p> <ul style="list-style-type: none"> • Leave blank, not used. <p><Requested_GPRS-READY-timer> (2G timer)</p> <ul style="list-style-type: none"> • Leave blank, not used. <p><Requested_Periodic-TAU> (TAU timer—Amount of time UE will be dormant before timer wakes it)</p> <ul style="list-style-type: none"> • One byte (8 bits) represented as a string. For coding and value range details, refer to the +CPSMS description in 3GPP TS 27.007. • Default—"00011000"=4 hours • e.g. "01000111" = 70 hours <p><Requested_Active-Time> (Amount of time UE will remain active (idle) before re-entering PSM)</p> <ul style="list-style-type: none"> • One byte (8 bits) represented as a string. For coding and value range details, refer to the +CPSMS description in 3GPP TS 27.007. • Default—"00001010"=20 seconds • e.g. "00100100" = 4 minutes

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+CPWROFF	<p>Power Off</p> <p>Notes:</p> <ul style="list-style-type: none"> If no <mode> is specified for the execution command, the module sends an IMSI detach request to the network before powering down. If <mode>=1 is specified for the execution command, the module performs a fast power down (~1s faster than not specifying the <mode>) without sending an IMSI detach request to the network. The module can be woken by setting POWER_ON_N low to turn on the system. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT+CPWROFF [=<mode>] Response: OK or ERROR Purpose: Power off the module using selected mode. Query List: AT+CPWROFF=? Purpose: Display currently selected power off mode. <p>Parameters:</p> <p><mode> (Power off mode)</p> <ul style="list-style-type: none"> 1—Fast power down mode
+CSQ	<p>Display signal quality</p> <p>Display the current signal strength and BER. Unsolicited notifications indicating changes in these values can also be received via +CSQ (notification).</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT+CSQ Response: +CSQ: <rsqi>,<ber> OK or +CME ERROR: <err> Purpose: Display the current signal strength and BER. Query List: AT+CSQ=? Purpose: Display the range of possible values for signal strength and BER. <p>Parameters:</p> <p><rsqi> (Received Signal Strength Indication offset value)</p> <ul style="list-style-type: none"> Integer value. Each step represents 2 dBm increase from base value 0: -113 dBm or less 1–30: -111 to -53 dBm 31: -51 dBm or greater 99: Not known, or not detectable <p><ber> (Channel Bit Error Rate, in percent)</p> <ul style="list-style-type: none"> Integer value. 0–7: As RXQUAL values in the table in 3GPP TS 45.008 subclause 8.2.4 99: Not known, or not detectable

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+CSQ (notification)	<p>RSSI change across threshold—Unsolicited notification</p> <p>Unsolicited notification indicating the signal strength (<rsssi>) has changed. To enable +CSQ (and other notifications), use AT+WUSLMSK.</p> <p>Notification format: +CSQ: <rsssi>,<ber></p> <p>Examples:</p> <ul style="list-style-type: none"> • Notification received: +CSQ: 20,99 Signal strength (RSSI) -33 dBm, with bit error ration (BER) not known/not detectable <p>Parameters:</p> <p><rsssi> (Received Signal Strength Indication offset value)</p> <ul style="list-style-type: none"> • As defined in +CSQ. <p><ber> (Channel Bit Error Rate, in percent)</p> <ul style="list-style-type: none"> • As defined in +CSQ.

Table 3-2: Modem Status Command Details (Continued)

Command	Description
<p>!CUSTOM</p> <hr/> <p><i>Note: Some customizations may not be available for certain chipsets, firmware revisions, or devices.</i></p> <hr/>	<p>Set/return customization settings Set or return several customization values. Password required: Yes (Execution only) (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!CUSTOM=<customization>, <value> Response: OK Purpose: Assign <value> to a specific <customization> setting. • Query: AT!CUSTOM? Response: (list of enabled <customization>s) OK Purpose: Display customizations that are currently enabled. • Query list: AT!CUSTOM=? Purpose: Return a list of valid <customization> values. <p>Parameters:</p> <p><value> (Value being assigned to a specific <customization> setting)</p> <ul style="list-style-type: none"> • Descriptions are included in each of the customizations described below. • Numeric value. Valid range depends on the <customization> type. <p><customization> (String identifying customization setting. The default value for all customizations is 0.)</p> <hr/> <p><i>Note: Use quotation marks around the customization string. For example, AT!CUSTOM="CSDOFF",0.</i></p> <hr/> <ul style="list-style-type: none"> • "BANDSELEN"—Select GPIO28–31 usage type. <value>: <ul style="list-style-type: none"> • 0—General purpose GPIO • 1—Antenna select (with !ANTSEL) • "BOOTQUIETDISABLE"—Enable/disable Linux kernel console messages. Disabling non-critical Linux kernel console logging improves the boot time. <value>: <ul style="list-style-type: none"> • 0—Disable Linux kernel console messages during boot (Default) • 1—Enable all Linux kernel console messages during boot • "BOOTUARTDLOADEN"—Enable/disable firmware download over UART on bootloader. <value>: <ul style="list-style-type: none"> • 0—Disable UART download. F/W download over USB only (Default) • 1—Enable UART download. F/W download over USB and UART. Bootloader download mode falls back to UART after USB mode timeout. • If the "UAUDLOADDISABLE" customization has been used to disable firmware download, this customization is ignored. <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
<p>!CUSTOM (continued)</p>	<p>Set—query customization settings (continued)</p> <ul style="list-style-type: none"> • "CFUNPERSISTEN"—Enable/disable persistence (across power cycles) of AT+CFUN setting. <value>: <ul style="list-style-type: none"> • 0—Disable (+CFUN setting does not persist across power cycle) Note: If the modem is in P-LPM (persistent low power mode—AT+CFUN mode 0) when this option is used, persistence remains enabled until the modem is put into online mode using an AT or QMI command. • 1—Enable (+CFUN setting persists across power cycle) • Note: This customization does not affect operating mode persistence set using other interfaces. For example, the QMI interface can still be used to set the operating mode to LPM or P-LPM, even if this customization is disabled. • "CSDDISABLE"—Disable/enable CSD call <value>: <ul style="list-style-type: none"> • 0—Enable (Default) • 1—Disable • "CSVOICEREJECT"—Enable/disable CS voice rejection <value>: <ul style="list-style-type: none"> • 0—No voice rejection (Default) • 1—Reject paging type 1 and 2 for voice calls • 2—Reject MT voice and MT CSD/UDI calls (cause #88) • 3—Accept MT voice and reject MT CSD/UDI calls (cause #88) • 4—Reject MT voice (cause #65) and MT CSD (cause #88) • "DHCPRELAYENABLE"—Enable/disable DHCP relay feature. <value>: <ul style="list-style-type: none"> • 0—Disable (Default). Modem filters DHCP requests into internal DHCP server. • 1—Enable. DHCP requests (packets for port 67 with target IP address of DHCP server) go out over the network. • "DGENABLE"—Enable/disable Dying Gasp feature <value>: <ul style="list-style-type: none"> • 0—Disable (Default) • 1—Enable sending SMS for Dying Gasp • 2—Enable sending detach for Dying Gasp • "EXITSPYMODEENABLE"—Enable/disable "exit spymode". <value>: <ul style="list-style-type: none"> • 0—Disable (Default) • 1—Enable • "EXTGPSLNAEN"—Enable/disable EXT_GPS_LNA_EN pin <value>: <ul style="list-style-type: none"> • 0—Disable • 1—(Default) Enable • "EXTUIMSWITCHEN"—Enable/disable control of fast SIM switching feature (see +KSIMSEL on page 203 for details) <value>: <ul style="list-style-type: none"> • 0—Disable (Default) • 1—Enable <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
<p>!CUSTOM (continued)</p>	<p>Set/query customization settings (continued)</p> <ul style="list-style-type: none"> • "FASTBOOTEN"—Enable/disable fast boot. <value>: <ul style="list-style-type: none"> • 0—Disable (Default) • 1—Enable • "FASTENUMEN"—Enable/disable fast enumeration for warm/cold boot. <value>: <ul style="list-style-type: none"> • 0—Disable fast enumeration (Default) • 1—Enable fast enumeration for cold boot and disable for warm boot • 2—Enable fast enumeration for warm boot and disable for cold boot • 3—Enable fast enumeration for warm and cold boot • "FLOWNOTIDISABLE"—Enable/disable QoS QMI notification events. <value>: <ul style="list-style-type: none"> • 0–255 (Default value = 0—all events enabled) • Bit 0: Flow activated event (0=Enable, 1=Disable) • Bit 1: Flow modified event (0=Enable, 1=Disable) • Bit 2: n/a • Bit 3: Flow deleted event (0=Enable, 1=Disable) • Bit 4: Flow suspended event (0=Enable, 1=Disable) • Bit 5: Flow enabled event (0=Enable, 1=Disable) • Bit 6: Flow disabled event (0=Enable, 1=Disable) • Bit 7: n/a • "GPIOSARENABLE"—Indicate whether SAR backoff is controlled by GPIOs or by AT commands. <value>: <ul style="list-style-type: none"> • 0—Controlled by AT commands (default) • 1—Controlled by GPIOs • "GPSENABLE"—Enable/disable the GPS feature. <value>: <ul style="list-style-type: none"> • 0—GPS disabled • 1—MO & MT enabled regardless of GPS_DISABLE setting • 2—MO enabled regardless of GPS_DISABLE setting • 3—MT enabled regardless of GPS_DISABLE setting • 4—MO & MT enabled but are gated by GPS_DISABLE setting • 5—MO enabled but is gated by GPS_DISABLE setting • 6—MT enabled but is gated by GPS_DISABLE setting • <value> + 80—Disable GLONASS (For example, 84 = MO & MT narrow-band GPS enabled, but gated by GPS_DISABLE setting.) • "GPSLPM"—Enable/disable GPS in Low Power Mode. <value>: <ul style="list-style-type: none"> • 0—Enable (Default). GPS engine remains enabled when modem enters LPM. • 1—Disable. GPS engine is disabled when modem enters LPM. • "GPSREFLOC"—Enable/disable reference GPS location reporting. <value>: <ul style="list-style-type: none"> • 0—Enable (Default) • 1—Disable <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!CUSTOM (continued)	<p>Set/query customization settings (continued)</p> <ul style="list-style-type: none"> • "GPSSEL"—Select antenna to use for GPS. <value>: <ul style="list-style-type: none"> • 0—Use dedicated GPS antenna (Default) • 1—Use RxD antenna • "ICMPINTSRVDIS"—Enable/disable internal ICMP service. (When enabled, modem can reply to Ping requests in an LTE attached state, without a host or embedded data connection.) <value>: <ul style="list-style-type: none"> • 0—Enable IPv4/IPv6 ICMP service • 1—Disable IPv4 ICMP service • 2—Reserved for future use • 3—Disable IPv4/IPv6 ICMP service • "IMCONFIG"—Image switching configuration <value>: <ul style="list-style-type: none"> • 0—On device (Default) • 1—On host • 255—Disable all IM features • "IMSWITCHHIDE"—Show/hide Multi-Image Management <value>: <ul style="list-style-type: none"> • 0—Show (Default) • 1—Hide • "IPCHANNELRATEEN"—Enable/disable calculation of IP channel rates (Rx and Tx) <value>: <ul style="list-style-type: none"> • 0—Disable (Default) • 1—Enable • "IPV6ENABLE"—Enable/disable IPv6 support <value>: <ul style="list-style-type: none"> • 0—Disable • 1—Enable • "JAMENABLE"—Enable/disable JAM detection. <value>: <ul style="list-style-type: none"> • 0—Disable (Default) • 1—Enable • "LTECOEXUARTENABLE"—Enable/disable Wi-Fi/LTE Coexistence <value>: <ul style="list-style-type: none"> • 0—Disable (Default) • 1—Enable feature (used on GPIO35 if configured using +WIOCFG) • NOTE: This feature cannot be used with UART1 DSR pin. <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
<p>!CUSTOM (continued)</p>	<p>Set/query customization settings (continued)</p> <ul style="list-style-type: none"> • "NETWORKNAMEFMT"—Display format for MBIM network provider name when device is roaming <value>: <ul style="list-style-type: none"> • 0—SPN, LongName, or ShortName in order of priority (default QCT behavior) • 1—LongName or ShortName • 2—[SPN] - [LongName/ShortName] (possibly truncated) • 3—[LongName/ShortName] - [SPN] (possibly truncated) • "OSAENABLE"—Enable/disable OSA (Open SIM Access). <value>: <ul style="list-style-type: none"> • 0—Disable (Default) • 1—Enable • "PCSCDISABLE"—Determine functionality of PCSC, GSM Algorithm and Authenticate commands, and +CIMI command. <value>: <ul style="list-style-type: none"> • 0–7 (Default value: 0—all functions enabled) • Bit 0: PCSC (0—Enable, 1—Disable) • Bit 1: GSM Algorithm and Authenticate commands (0—Enable, 1—Disable) • Bit 2: AT+CIMI outputs IMSI (0=Enable, 1=Disable) • "POWERFAULTENABLE"—Enable/disable power fault. <value>: <ul style="list-style-type: none"> • 0—Disable (Default) • 1—Enable • "QMIDETACHEN"—Enable/disable QMI NAS Detach <value>: <ul style="list-style-type: none"> • 0—QMI detach request returns NO_EFFECT response, and no action taken • 1—QMI detach request is acted on, and appropriate response is returned based on detach result • "SIMHOTSWAPDIS"—Configure SIM hotswap feature. <value>: <ul style="list-style-type: none"> • 0—Enable UIM1 and UIM2 • 1—Disable UIM1, enable UIM2 • 2—(Default) Enable UIM1, disable UIM2 • 3—Disable UIM1 and UIM2 • Note: 'UIM2' refers to eSIM (embedded SIM) • "SIMLPM"—Indicate default SIM power state during Low Power Mode. <value>: <ul style="list-style-type: none"> • 0—QCT default behavior (same as <value>=2) (Default) Note—The default behavior could change in future revisions. Use <value>=2 if you need to guarantee the described behavior. • 1—SIM remains powered in LPM • 2—Power down SIM with AT+CFUN=0; Power up SIM with AT+CFUN=1 • "SINGLEAPNSWITCH"—Indicate device behavior when changing APN name, username, or password. <value>: <ul style="list-style-type: none"> • 0—Do nothing • 1—Device detaches and re-attaches after changing APN information • 2—Power-cycle the UE • Note: No action is taken if APN is changed in non-LTE service. <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
<p>!CUSTOM (continued)</p>	<p>Set/query customization settings (continued)</p> <ul style="list-style-type: none"> • "SNTPEN"—Enable/disable SNTP system time support when NITZ is unavailable. <value>: <ul style="list-style-type: none"> • 0–7 (Default value: 0—all functions enabled) <ul style="list-style-type: none"> • Bit 0: Modem SNTP (0—Disable, 1—Enable) • Bit 1: SNTP autoconnect (0—Enable, 1—Disable). Allows SNTP client to initiate data connection instead of waiting for user-initiated connection. • Bit 2: Retry on SNTP failure (0=Enable, 1=Disable). Allows SNTP client to retry connection. Maximum number of retries is module-dependent. • Note: If enabled, data usage charges may be incurred if NITZ time is not provided by the network. • "STKUIEN"—Enable/disable SIM toolkit UI. <value>: <ul style="list-style-type: none"> • 0—Enable for QMI interface • 1—Reserved • 2—Enable for AT interface • "TXONINDICATION"—Enable/disable TX_ON indication. <value>: <ul style="list-style-type: none"> • 0—Disable (Default) • 1—Enable • "UAUDLOADDISABLE"—Enable/disable firmware download via unauthenticated channels such as local UART, USB, and X-MODEM interfaces. <value>: <ul style="list-style-type: none"> • 0—(Default) Unauthenticated download enabled • 1—Unauthenticated download disabled, excluding firmware launch failure • 2—Unauthenticated download disabled, including firmware launch failure • Important notes: <ul style="list-style-type: none"> • This customization can be used only to disable firmware download. Once disabled, it cannot be re-enabled. • If disabled, BOOTUARTDLOADEN customization cannot be used and existing values are ignored. • If option 2 is selected, the device may be unrecoverable if a firmware launch failure occurs, since there is no way to update the firmware. • "UIMAUTOSWITCH"—Enable/disable Automatic SIM switching ("Auto-SIM-Switch mode"). <value>: <ul style="list-style-type: none"> • 0—Disable automatic SIM switching • 1—Enable, UIM Slot 1 preferred (external SIM) • 2—Enable, UIM Slot 2 preferred (eSIM) • Note—If enabled (1 or 2), the !UIMS setting is updated to reflect the preferred slot. • "UIM2ENABLE"—Enable/disable UIM2 slot (eSIM) support. <value>: <ul style="list-style-type: none"> • 0—Disable • 1—Enable (Default) <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!CUSTOM (continued)	<p>Set/query customization settings (continued)</p> <ul style="list-style-type: none"> • "USBSERIALENABLE"—Use serial number in USB Descriptor <value>: <ul style="list-style-type: none"> • 0—Default (same as 1) • 1—Use IMEI as serial number in USBD • 2—Do not use any serial number in USBD • "WAKEHOSTEN"—Enable/disable host wake-up via SMS or incoming data packet. <value>: <ul style="list-style-type: none"> • 0—Disable—Host will not wake when SMS or incoming data packet is received. (Default) • 1—Wake host when simple SMS is received. • 2—Wake host when incoming data packet is received. • 3—Wake host when simple SMS or incoming data packet is received.
!GCFEN	<p>Enable/disable GCF testing mode</p> <p>Password required: Yes (Execution)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!GCFEN=<mode> Response: OK Purpose: Set GCF testing mode state. • Query: AT!GCFEN? Response: !GCFEN: <mode> OK Purpose: Display current GCF testing mode state. • Query List: AT!GCFEN=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><mode> (GCF testing mode state)</p> <ul style="list-style-type: none"> • 0—GCF mode disabled (Default) • 1—GCF mode enabled

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!GSTATUS	<p>Return operational status Return specific details about the current operational status of the modem.</p> <hr/> <p>Important: <i>Response details vary depending on the current RAT, and may evolve from release to release. Parameter descriptions show all possible values—actual supported values vary depending on module type and current RAT. Contact Sierra Wireless for further details if required.</i></p> <hr/> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> Query: ATIGSTATUS? Response (As noted above, details vary depending on RAT and module type.): !GSTATUS: <param_label>: <param> [[<param_label>:]<param>] ... OK <p>Purpose: Display details about the modem’s current operational state. Details shown will vary depending on the current RAT, module type, and firmware release.</p> <p>Example: !GSTATUS: Current Time: <ctime> Temperature: <temp> Reset Counter: <rstcount> Mode: <mode> System mode: <smode> PS state: <PSstate> IMS Reg State: <imsstate> IMS mode: <ims mode> IMS Service: <imssrvstatus> WCDMA band: <wband> WCDMA channel: <wchan> GMM (PS) state: <gmmstate> <gmmsubstate> MM (CS) state: <mmstate> <mmsubstate></p> <p> WCDMA L1 State: <wrstate> LAC: <LAC></p> <p> RRC State: <wrstate> Cell ID: <Cell ID> RxMRSSI C0: <wrxlev> RxDRSSI C0: <wrxlev> RxMRSSI C1: <wrxlev> RxDRSSI C1: <wrxlev></p> <p> OK</p> <p>Parameters: <param_label> • Parameter description. e.g. "WCDMA channel" <param> • Parameter value. Refer to the parameter descriptions listed below.</p> <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!GSTATUS (continued)	<p>Return operational status (continued)</p> <p><cband> ("CDMA band")</p> <ul style="list-style-type: none"> • ASCII string (quotation marks do not appear): <ul style="list-style-type: none"> • "US Cellular" • "US PCS" • "JTACS" • "JCDMA" • "Korean PCS" • "NMT" • "IMT" • "No band" <p><cchan> ("CDMA channel"—CDMA Rx channel)</p> <ul style="list-style-type: none"> • decimal <p><Cell ID> ("Cell ID")</p> <ul style="list-style-type: none"> • Hex (decimal) <p><cnid> ("NID"—CDMA Network ID)</p> <ul style="list-style-type: none"> • decimal <p><csid> ("SID"—CDMA System ID)</p> <ul style="list-style-type: none"> • decimal <p><ctime> ("Current Time"—Number of seconds since the system booted/rebooted)</p> <ul style="list-style-type: none"> • 32-bit decimal <p><ecio> ("ECIO (db)"—Ratio of received pilot energy (Ec) to total received energy)</p> <ul style="list-style-type: none"> • -31.5 to 0 <p><emmcon> ("EMM connection"—Current EMM connection state)</p> <ul style="list-style-type: none"> • ASCII string (quotation marks do not appear): <ul style="list-style-type: none"> • "RRC Idle" • "Waiting RRC Cfm" • "RRC Connecting" • "RRC Releasing" <p><emmstate> ("EMM state" first field—Current EMM state)</p> <ul style="list-style-type: none"> • ASCII string (quotation marks do not appear): <ul style="list-style-type: none"> • "Deregistered" • "Reg Initiated" • "Registered" • "TAU Initiated" • "SR Initiated" • "Dereg Initiated" • "Invalid" • "NULL" <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!GSTATUS (continued)	<p>Return operational status (continued)</p> <p><emmsubstate> ("EMM state" second field—Current EMM sub-state)</p> <ul style="list-style-type: none"> • ASCII string (quotation marks do not appear): <ul style="list-style-type: none"> • For <emmstate> = "Deregistered": <ul style="list-style-type: none"> • "No IMSI" • "PLMN Search" • "Attach Needed" • "No Cell" • "Attaching" • "Normal Service" • "Limited Service" • "Waiting for PDN" • For <emmstate> = "Reg Initiated": <ul style="list-style-type: none"> • "Waiting for NW" • "Waiting for ESM" • For <emmstate> = "Registered": <ul style="list-style-type: none"> • "Normal Service" • "Update Needed" • "Attempt Update" • "No Cell" • "PLMN Search" • "Limited Service" • "MM Update" • "IMSI Detach" • "Waiting for ESM" • For all other <emmstate>s: <ul style="list-style-type: none"> • "___" <p><gband> ("GSM band"—Current GSM band being accessed (TCH or BCCH))</p> <ul style="list-style-type: none"> • ASCII string (quotation marks do not appear): <ul style="list-style-type: none"> • "GSM850" • "GSM900" • "DCS1800" • "PCS1900" • "Unknown" <p><gchan> ("GSM channel"—GSM channel number)</p> <ul style="list-style-type: none"> • 32-bit decimal ASCII <p><gmmstate> ("GMM (PS) state" first field—Current GMM state)</p> <ul style="list-style-type: none"> • ASCII string (quotation marks do not appear): <ul style="list-style-type: none"> • "DEREGISTERED" • "Registering" • "REGISTERED" • "Deregistering" • "RA updating" • "Requesting srvc" • "NULL" <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!GSTATUS (continued)	<p>Return operational status (continued)</p> <p><gmmsubstate> ("GMM (PS) state" second field—Current GMM sub-state)</p> <ul style="list-style-type: none"> • ASCII string (quotation marks do not appear): <ul style="list-style-type: none"> • "NORMAL SERVICE" • "LIMITED SERVICE" • "ATT NEEDED" • "ATTEMPTING ATT" • "NO IMSI" • "NO SERVICE" • "PLMN SEARCH" • "SUSPENDED" • "UPDATE NEEDED" • "UPDATING" • "DEATTACHING" • "---" —No sub-state, or a sub-state not defined in this command <p><gstate> ("GPRS State"—State of GMM ↔ LLC interface)</p> <ul style="list-style-type: none"> • ASCII string (quotation marks do not appear): <ul style="list-style-type: none"> • "GPRS IDLE" • "GPRS READY" • "GPRS STANDBY" <p><hccode> ("Color code"—HDR color code)</p> <ul style="list-style-type: none"> • decimal <p><hpoff> ("PN offset"—HDR PN offset)</p> <ul style="list-style-type: none"> • decimal <p><hscid> ("Sector ID"—HDR sector ID)</p> <ul style="list-style-type: none"> • 32 hexadecimal digits in eight groups of four digits, separated by ":" • Example: ABCD:EF12:3456:7890:ABCD:EF23:ED45:B2C3 <p><hsmsk> ("Subnet mask"—HDR subnet mask)</p> <ul style="list-style-type: none"> • decimal <p><ims mode> ("IMS mode")</p> <ul style="list-style-type: none"> • ASCII string (quotation marks do not appear): <ul style="list-style-type: none"> • "Normal" • "Test" • "Not Support"— Device is not configured with IMS <p><IMS state> ("IMS Reg State"—IMS registration state)</p> <ul style="list-style-type: none"> • ASCII string (quotation marks do not appear): <ul style="list-style-type: none"> • "NOT REGISTERED" • "REGISTERED" • "UNKNOWN" <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!GSTATUS (continued)	<p>Return operational status (continued)</p> <p><imssrvstatus> ("IMS Service"—IMS Registered Server status)</p> <ul style="list-style-type: none"> • ASCII string (quotation marks do not appear): <ul style="list-style-type: none"> • "NO SMS,NO VoIP" • "NO SMS,FULL VOIP" • "LIMITED SMS,NO VOIP" • "LIMITED SMS,FULL VOIP" • "FULL SMS,NO VoIP" • "FULL SMS,FULL VoIP" • "LIMITED SMS,UNKNOWN VoIP" • "UNKNOWN SMS,UNKNOWN VoIP" <p><io> ("IO (dBm)"—Total received energy (Io))</p> <ul style="list-style-type: none"> • -106 to -21 <p><lac> ("LAC"—Location Area Code)</p> <ul style="list-style-type: none"> • Hex (decimal) <p><lband> ("LTE band")</p> <ul style="list-style-type: none"> • ASCII string (quotation marks do not appear): <ul style="list-style-type: none"> • "B1" .. "B41" • "No band" <p><lbw> ("LTE bw"—LTE bandwidth)</p> <ul style="list-style-type: none"> • ASCII string (quotation marks do not appear): <ul style="list-style-type: none"> • "1.4 MHz" • "3 MHz" • "5 MHz" • "10 MHz" • "15 MHz" • "20 MHz" • "Unknown" <p><lrchan> ("LTE Rx chan"—LTE Rx channel)</p> <ul style="list-style-type: none"> • decimal <p><ltchan> ("LTE Tx chan"—LTE Tx channel)</p> <ul style="list-style-type: none"> • decimal <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
<p>!GSTATUS (continued)</p>	<p>Return operational status (continued)</p> <p><mmstate> ("MM (CS) state" first field—Current MM state)</p> <ul style="list-style-type: none"> • ASCII string (quotation marks do not appear): <ul style="list-style-type: none"> • "NULL" • "IDLE" • "LA Rejected" • "LA Start" • "CONNECTED" • "Network Command" • "IMSI Detach" • "Wait RR Active" • "Wait RR LU" • "Wait RR Detach" • "Wait RR MM" • "Wait MM" • "Wait add'l MM" • "Wait Re-est Dec" • "Wait RR Re-est" • "Re-est" • "LU Pending" • "Rel not allowed" • "Prompt" <p><mmsubstate> ("MM (CS) state" second field—Current MM sub-state)</p> <ul style="list-style-type: none"> • ASCII string (quotation marks do not appear): <ul style="list-style-type: none"> • "NORMAL SERVICE" • "LIMITED SERVICE" • "NO IMSI" • "NO SERVICE" • "PLMN SEARCH" • "UPDATE NEEDED" • "UPDATING" • "ECALL INACTIVE" • "---" —No sub-state, or a sub-state not defined in this command <p><mode> ("Mode"—Current module mode)</p> <ul style="list-style-type: none"> • ASCII string (quotation marks do not appear): <ul style="list-style-type: none"> • "POWERING OFF" • "FACTORY TEST" • "OFFLINE" • "ONLINE" • "LOW POWER MODE" • "RESETTING" • "NETWORK TEST" • "OFFLINE REQUEST" • "PSEUDO ONLINE" • "RESETTING MODEM" • "Unknown" <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!GSTATUS (continued)	<p>Return operational status (continued)</p> <p><PSstate> ("PS state"—Current PS state of module)</p> <ul style="list-style-type: none"> • ASCII string (quotation marks do not appear): • "Attached" • "Not attached" <p><ri> ("Roaming Indicator")</p> <ul style="list-style-type: none"> • decimal <p><rsrp> ("RSRP (dBm)"—Reference Signal Receive Power)</p> <ul style="list-style-type: none"> • -140 to -44 <p><rsrq> ("RSRQ (dB)"—Reference Signal Receive Quality)</p> <ul style="list-style-type: none"> • -20 to -3 <p><rssi> ("RSSI", "RxM RSSI", "PCC RxM RSSI"—Total received power)</p> <ul style="list-style-type: none"> • -120 to 0 <p><rstcount> "Reset Counter"—Number of resets since last power cycle)</p> <ul style="list-style-type: none"> • 32-bit decimal • Value resets to 0 on power cycle/power on/off. • Value increments when a hardware or software reset is performed. <p><rxdivpwr> ("RX1 (dBm)"—Diversity received power)</p> <ul style="list-style-type: none"> • -106 to -21 <p><sinr> ("SINR (dB)"—Signal to Interference plus Noise)</p> <ul style="list-style-type: none"> • -20 to +30 <p><smode> ("System mode"—Current system mode)</p> <ul style="list-style-type: none"> • ASCII string (quotation marks do not appear): • "None" • "No service" • "AMPS" • "CDMA" • "GSM" • "HDR" • "WCDMA" • "GPS" • "WCDMA+GSM" • "WLAN" • "LTE" • "GWL" • "TD-SCDMA" • "eHRPD" • "Unknown" <p><tac> ("TAC"—Tracking Area Code)</p> <ul style="list-style-type: none"> • Hex (decimal) <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!GSTATUS (continued)	<p>Return operational status (continued)</p> <p><temp> ("Temperature"—Temperature (approximate) in °C, accurate within ~5 °C)</p> <ul style="list-style-type: none"> • 32-bit decimal <p><txpwr> ("Tx Power"—Transmit Power)</p> <ul style="list-style-type: none"> • -100 to +100 • "--"—No transmission <p><wband> ("WCDMA band"—Current WCDMA band being accessed)</p> <ul style="list-style-type: none"> • ASCII string (quotation marks do not appear): • "WCDMA 2100" • "WCDMA 1900" • "WCDMA BC3" • "WCDMA 1700" • "WCDMA 800" • "WCDMA 900" • "WCDMA BC9" • "WCDMA BC11" • "WCDMA BC19" <p><wchan> ("WCDMA channel"—WCDMA channel number)</p> <ul style="list-style-type: none"> • 32-bit decimal ASCII <p><wrstate> ("WCDMA L1 State", "RRC State"—WCDMA RRC state)</p> <ul style="list-style-type: none"> • ASCII string (quotation marks do not appear): • "DISCONNECTED" • "CONNECTING" • "CELL_FACH" • "CELL_DCH" • "CELL_PCH" • "URA_PCH" • "State N/A" • "--" <p><wrxlev> ("RxDRSSI", "RxMRSSI"—Receive power in dBm)</p> <ul style="list-style-type: none"> • decimal <p><wstate> ("WCDMA L1 state")</p> <ul style="list-style-type: none"> • ASCII string (quotation marks do not appear): • "L1M_IDLE" • "L1M_FS" • "L1M_ACQ" • "L1M_BCH" • "L1M_PCH" • "L1M_FACH" • "L1M_DCH" • "L1M_DEACTIVE" • "L1M_PCH_SLEEP" • "L1M_DEEP_SLEEP" • "L1M_STOPPED" • "L1M_SUSPENDED" • "L1M_PCH_BPLMN" • "L1M_WAIT_TRM_STOP" • "--"

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!HWID	<p>Read hardware ID</p> <p>Return the module's hardware ID, which combines the major and minor version number.</p> <p>Password required: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Query: AT!HWID? Response: Revision: <MajorVer>.<MinorVer> OK • Query List: AT!HWID=? Purpose: Display the module's hardware ID. • Query List: AT!HWID=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><MajorVer> (Major version number)</p> <ul style="list-style-type: none"> • Valid range: 0–9 <p><MinorVer> (Minor version number)</p> <ul style="list-style-type: none"> • Valid range: 0–9 <p>Example:</p> <ul style="list-style-type: none"> • AT!HWID? Revision: 1.7 OK

Table 3-2: Modem Status Command Details (Continued)

Command	Description
I	<p>Display product identification information Display the module's hardware and firmware identification information. Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Query: ATI[<n>] Response (if <n> is 0–7, 10-255, or not entered): Manufacturer: <manufacturer> Model: <model> Revision: <revision> ESN: <esn> IMSI: <imsi> IMEI SV: <imeisv> FSN: <fsn> +GCAP: <gcap> <p style="padding-left: 40px;">OK</p> <p>Response (if <n> is 8): Legato Ver: <legatover> OS Ver: <osver> MCU Ver: <mcuver> TAOP version: <taopver></p> <p style="padding-left: 40px;">OK</p> <p>Response (if <n> is 9): Manufacturer: <manufacturer> Model: <model> QTI baseline: <qualcomm mpss stack> Revision: <revision> ESN: <esn> IMSI: <imsi> IMEI SV: <imeisv> FSN: <fsn> +GCAP: <gcap></p> <p style="padding-left: 40px;">OK</p> <p>Purpose: Display the module's hardware or firmware information.</p> <p>Parameters:</p> <p><n> (Information to display)</p> <ul style="list-style-type: none"> • Integer • 8—Firmware information • 0–7; 9–255—Hardware information <p><manufacturer> (See AT+GMI)</p> <ul style="list-style-type: none"> • ASCII string <p><model> (See AT+GMM)</p> <ul style="list-style-type: none"> • ASCII string • Integer <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
I (continued)	<p>Display device information (continued)</p> <p><revision> (See AT+GMR)</p> <ul style="list-style-type: none"> • ASCII string <p><esn> (Electronic Serial Number)</p> <ul style="list-style-type: none"> • Hex string <p><imeisv> (IMEI Software Version)</p> <ul style="list-style-type: none"> • Integer <p><fsn> (Factory Serial Number)</p> <ul style="list-style-type: none"> • ASCII string <p><gcap> (Device Capabilities List)</p> <ul style="list-style-type: none"> • ASCII string <p><legatover> (Legato version)</p> <ul style="list-style-type: none"> • ASCII string <p><osver> (Linux version information)</p> <ul style="list-style-type: none"> • ASCII string <p><mcuver> (MCU version)</p> <ul style="list-style-type: none"> • ASCII string <p><qualcomm mpss stack> (Qualcomm baseline information)</p> <ul style="list-style-type: none"> • ASCII string <p><taopver> (TAOP version)</p> <ul style="list-style-type: none"> • ASCII string

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!IMAGE	<p>Manage Firmware Images List or delete stored firmware and configuration (PRI) images.</p> <hr/> <p><i>Note: This command is intended for use by advanced users who are familiar with the nuances of firmware and PRI image storage requirements and naming conventions.</i></p> <hr/> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!IMAGE=<op>[,<type>],[<slot>],[<build_id>,<unique_id>]]] Response: OK Purpose: Delete or list stored FW and/or PRI images. • Query: AT!IMAGE?[<op>[,<type>]]] Response: TYPE SLOT STATUS LRU FAILURES UNIQUE_ID BUILD_ID <TY> <slot> <status> <lru> <f1> <f2> <unique_id> <build_id> ... Max FW images: <max_fw> Active FW image is at slot <slot> <p>TYPE SLOT STATUS LRU FAILURES UNIQUE_ID BUILD_ID <TY> <slot> <status> <lru> <f1> <f2> <unique_id> <build_id> ... Max PRI images: <max_pri></p> <p>OK</p> <p>Purpose: Display lists of stored firmware and/or PRI images, or the quantity of stored firmware or PRI images. (In the format shown above, the <TY> value in the first group of responses will be 'FW', and the value in the second group will be 'PRI'.)</p> <p>Note: If the active firmware image has been deleted from storage, the "Active FW image is at slot <slot>" line will show "slot 255".</p> <p>Parameters:</p> <p><op> (Operation)</p> <ul style="list-style-type: none"> • 0—Delete. (Note: Valid only for Execution format.) • 1—List stored FW and/or PRI images, depending on <type> • 2—List Max FW images or Max PRI images, depending on <type> <p><type> (Image type)</p> <ul style="list-style-type: none"> • 0—FW (firmware) • 1—PRI (configuration) <p><slot> (Firmware image slot ID)</p> <ul style="list-style-type: none"> • Valid range: 0–FF • Field is ignored for PRI images. <p><build_id> (Build ID)</p> <ul style="list-style-type: none"> • ASCII string, including double-quotes (e.g. "01.00.04.00_ATT") <p><unique_id> (Unique ID)</p> <ul style="list-style-type: none"> • ASCII string, including double-quotes (e.g. "001.000_000") <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!IMAGE (continued)	<p>Manage Firmware Images (continued)</p> <p><TY> (Image type)</p> <ul style="list-style-type: none"> • FW • PRI <p><status> (Image status)</p> <ul style="list-style-type: none"> • EMPTY • GOOD <p><lr> (Least Recently Used count)</p> <ul style="list-style-type: none"> • Indicates how recently the image has been used. • Used automatically during slot selection process to determine which image to remove if a new image is being loaded and there are no empty slots. <p><f1> (Programming failure count)</p> <ul style="list-style-type: none"> • 0–255 <p><f2> (Switching failure count)</p> <ul style="list-style-type: none"> • 0–255 <p><max_fw> (Programming failure count)</p> <ul style="list-style-type: none"> • Device-dependent, maximum number of firmware images that can be stored <p><max_pri> (Programming failure count)</p> <ul style="list-style-type: none"> • Device-dependent, maximum number of PRI images that can be stored

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!IMPREF	<p>Query/set Image Management preferences</p> <p>Indicate (set) which firmware image (firmware plus carrier configuration pair) should be downloaded to the module or enable SIM-based image switching, or list (query) the configuration pairs that are currently downloaded and preferred.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!IMPREF=<carrier-name> or AT!IMPREF="AUTO-SIM" <p>Response: OK</p> <p>Purpose: Indicate which carrier should be used (if a matching carrier PRI and required firmware are found), or specify "AUTO-SIM" to enable SIM-based image switching. Note: If AUTO-SIM is currently enabled, selecting a carrier will disable it.</p> <ul style="list-style-type: none"> • Query: AT!IMPREF? <p>Response:! IMPREF: preferred fw version: <firmware-ver> preferred carrier name: <carrier-name> preferred config name: <carrier-config> current fw version: <firmware-ver> current carrier name: <carrier-name> current config name: <carrier-config></p> <p>[<mismatch information>] OK</p> <p>Purpose: Query (show) the preferred and current firmware plus carrier carrier configuration pairs.</p> <p>Parameters:</p> <p><carrier-name> (Unique code identifying the carrier that the firmware was designed for)</p> <ul style="list-style-type: none"> • ASCII string <p><firmware-ver> (Unique firmware version number assigned by Sierra Wireless)</p> <ul style="list-style-type: none"> • ASCII string <p><carrier-config> (Unique code identifying the carrier and configuration details)</p> <ul style="list-style-type: none"> • ASCII string <p>Example(s):</p> <ul style="list-style-type: none"> • AT!IMPREF="ABC" (where "ABC" is a carrier name)
&K	<p>Flow Control</p> <p>This command has no effect. To set flow control, use AT+IFC instead.</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+KCCINFO	<p>Enable/disable camped cell information notifications</p> <p>Enable or disable unsolicited notifications on camped cell parameter changes. For notification format, see +KCCINFOI (notification).</p> <p>Notes:</p> <ul style="list-style-type: none"> • This command works with a SIM card. • <mode> is automatically stored in persistent memory. • Settings take effect immediately. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+KCCINFO=<mode> Response: OK or +CME ERROR: <err> Purpose: Enable or disable camped cell parameter change notifications. • Query: AT+KCCINFO? Response: +CCINFO: <mode>,<CI>,<RAC>,<TAC> OK Purpose: Display the current state of SIM detection notifications, plus the current camped cell parameter values. • Query List: AT+KCCINFO=? Purpose: Display valid parameter values. <p>Parameters:</p> <p><mode> (Camped cell parameter change notifications state)</p> <ul style="list-style-type: none"> • 0—Disable notifications (Default) • 1—Enable notifications <p><CI> (4-byte location area code, hexadecimal format)</p> <ul style="list-style-type: none"> • String • e.g. "00C3" equals 195 in decimal format <p><RAC> (1-byte routing area code, hexadecimal format)</p> <ul style="list-style-type: none"> • String • "FF" will be displayed if routing area identity information is invalid. <p><TAC> (2-byte tracking area code, hexadecimal format)</p> <ul style="list-style-type: none"> • String • e.g. "00C3" equals 195 in decimal format • "FFFF" will be displayed if tracking area identity information is invalid. <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+KCCINFO (continued)	<p>Enable/disable camped cell information notifications (continued)</p> <p>Example(s):</p> <pre>// Set mode to 1: AT+KCCINFO=1 OK //Test command: AT+KCCINFO=? +KCCINFO: (0-1) OK //Attach to network: AT+COPS=0 OK //URC display after attached to network: +KCCINFOI: "00006773", "01", "FFFF" //Read command: AT+KCCINFO? +KCCINFO: 1, "00006773", "01", "FFFF" OK</pre>
+KCCINFOI (notification)	<p>Camped cell parameter change—Unsolicited notification</p> <p>Notification that a camped cell parameter value has been changed. To enable/disable notifications, see +KCCINFO.</p> <p>Notification format: +KCCINFOI: <CI>, <RAC>, <TAC></p> <p>Parameters:</p> <p><mode> (Camped cell parameter change notifications state)</p> <ul style="list-style-type: none"> • 0—Disable notifications • 1—Enable notifications <p><CI> (4-byte location area code, hexadecimal format)</p> <ul style="list-style-type: none"> • String • e.g. "00C3" equals 195 in decimal format <p><RAC> (1-byte routing area code, hexadecimal format)</p> <ul style="list-style-type: none"> • String • "FF" will be displayed if routing area identity information is invalid. <p><TAC> (2-byte tracking area code, hexadecimal format)</p> <ul style="list-style-type: none"> • String • e.g. "00C3" equals 195 in decimal format • "FFFF" will be displayed if tracking area identity information is invalid.

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+KCELL	<p>Display Detected Cell Details</p> <p>Display information about the cells (serving, neighbor, detected) detected by the module, which are of the currently attached RAT.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+KCELL=<revision> Response (GSM): <nbGSMcells>[, <cell_type=0>, <ARFCN>, <BSIC>, <PLMN>, <LAC>, <GSM_CI>, <RXLEV>, <GSM_TA>][[, <cell_type=1>, <ARFCNi>, <BSIC>, <PLMN>, <LAC>, <CI>, <RXLEV>] [...]] OK Response (UMTS): <nbUMTScells>[, <cell_type=2 3 4>, <dl_ARFCN>, <PLMN>, <LAC>, <UMTS_CI>, <scrambling_code>, <rscp>, <ecio>[, <pathloss>] [...]] OK Response (LTE): <nbLTEcells>[, <cell_type=5>, <PLMN>, <LTE_CI>, <PhyCellInd>, <TrackingAreaCode>, <RSRPResult>, <RSRQResult>, <LTE_TA>][[, <cell_type=6>, <Earfcn>, <PhyCellId>, <RSRPResult>, <RSRQResult>] [...]] OK Purpose: Display details about all cells detected by the module that are of the currently attached RAT: <ul style="list-style-type: none"> • GSM—Active cell first, followed by neighbor cells • UMTS—Serving cell first, then neighbor cells, then monitored cells. • LTE—Serving cell first, followed by neighbor cells • Query: AT+KCELL? Response: OK Purpose: TBD • Query list: AT+KCELL=? Purpose: Displays execution format. <p>Parameters:</p> <p><revision> (Reserved field)</p> <ul style="list-style-type: none"> • 0—Only valid option. Parameter is reserved for future development. <p><nbGSMcells> (Number of available GSM base stations)</p> <ul style="list-style-type: none"> • Valid range: 0–7 <p><cell_type> (Cell type)</p> <ul style="list-style-type: none"> • 0—GSM serving cell • 1—GSM neighbor cell • 2—UMTS serving cell • 3—UMTS neighbor cell • 4—UMTS detected cell • 5—LTE serving cell • 6—LTE neighbor cell <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+KCELL (continued)	<p>Display Detected Cell Details (continued)</p> <p><ARFCN> (Absolute Radio Frequency Channel Number)</p> <ul style="list-style-type: none"> Valid range: 0–1023 Decimal format <p><BSIC> (Base Station Identity Code)</p> <ul style="list-style-type: none"> Valid range: 0–63 <p><PLMN> (PLMN identifier)</p> <ul style="list-style-type: none"> Format: Hexadecimal (3 bytes) per GSM 11.11 specification Combines MCC (Mobile Country Code) and MNC (Mobile Network Code) Example: 42F618 (Hex value for MCC=246 and MNC=81) <p><LAC> (Location Area Code)</p> <ul style="list-style-type: none"> Format: Hexadecimal (4 hex digits) <p><GSM_CI> (GSM Cell Identity)</p> <ul style="list-style-type: none"> Format: Hexadecimal (4 hex digits) Example: ABCD <p><RXLEV> (Received signal level of BCCH carrier)</p> <ul style="list-style-type: none"> Valid range: 0–63 Represents signal level in range -110 to -48 dBm. Refer to GSM 05.08 Radio Subsystem Link Control for details. <p><GSM_TA> (GSM Timing Advance for serving cell)</p> <ul style="list-style-type: none"> Only available when module is in connected state Valid values: <ul style="list-style-type: none"> -1—Not available 0–63 <p><nbUMTSCells> (Number of available UMTS base stations)</p> <ul style="list-style-type: none"> Valid range: 0–25 <p><dl_UARFCN> (DL UARFCN (UTRA Absolute Radio Frequency Channel Number) of serving cell)</p> <ul style="list-style-type: none"> Format: Decimal For valid range, refer to 3GPP TS 25.101 <p><UMTS_CI> (UMTS Cell Identity)</p> <ul style="list-style-type: none"> Format: Hexadecimal (8 hex digits) Example: A12BC3DF <p><scrambling_code> (Downlink scrambling code)</p> <ul style="list-style-type: none"> Valid range: 0–511 Format: Decimal <p><rscp> (Received Signal Code Power, in dBm)</p> <ul style="list-style-type: none"> Power level in one chip <p><ecio> (Ec/Io—Energy per chip to Interference power ratio, in dB)</p> <ul style="list-style-type: none"> Valid range: TBD <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+KCELL (continued)	<p>Display Detected Cell Details (continued)</p> <p><pathloss> (Path loss, in dB)</p> <ul style="list-style-type: none"> • Format: Decimal • Appears for <cell_type=2 3> • Valid values: <ul style="list-style-type: none"> • 46–158—Path loss in dB • 255—Not available <p><nbLTEcells> (Number of available LTE base stations)</p> <ul style="list-style-type: none"> • Valid range: 0–33 <p><LTE_CI> (LTE Cell Identity)</p> <ul style="list-style-type: none"> • Format: Hexadecimal (8 hex digits; length 28 bits), per 3GPP TS 36.331, 6.3.4, Cell Identity • Example: A12BC3DF <p><PhyCellId> (Physical layer identity of LTE Cell)</p> <ul style="list-style-type: none"> • Valid range: 0–503, per 3GPP TS 36.331, 6.3.4, PhysCellId <p><TrackingAreaCode> (Tracking Area Code of LTE Cell)</p> <ul style="list-style-type: none"> • Valid range: 0–65535, per 3GPP TS 36.331, 6.3.4, TrackingAreaCode <p><RSRPResult> (Reference Signal Received Power)</p> <ul style="list-style-type: none"> • Valid range: 0–97. Refer to 3GPP TS 36.331, 6.3.5, RSRP-Range for details. <p><RSRQResult> (Reference Signal Received Quality)</p> <ul style="list-style-type: none"> • Valid range: 0–34. Refer to 3GPP TS 36.331, 6.3.5, RSRQ-Range for details. <p><LTE_TA> (LTE Timing advance)</p> <ul style="list-style-type: none"> • Value available only when module is in connected state. • Valid values: <ul style="list-style-type: none"> • -1—Not available • 0–63—Timing advance • 255—Module is in a 3G voice call <p><Earfcn> (Neighbor cell carrier frequency)</p> <ul style="list-style-type: none"> • Carrier frequency of the neighbor cell designated by the EUTRA Absolute Radio Frequency Channel Number (EARFCN). Refer to 3GPP TS 36.101, 5.7.3 for details. • Valid range: 0–0xFFFF

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+KGSN	<p>Request Product Serial Number Identification and Software Version</p> <p>Notes:</p> <ul style="list-style-type: none"> This command has been developed to provide the IMEI SV and Serial Number through an AT command and it can work without a SIM. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution : AT+KGSN=<number_type> Response (<number_type>=0): +KGSN: <IMEI> OK Response (<number_type>=1): +KGSN: <IMEISV> OK Response (<number_type>=2): +KGSN: <IMEISV_STR> OK Response (<number_type>=3): +KGSN: <FSN> OK Response (<number_type>=4): +KGSN: <FSN-BB> OK Purpose: Display the requested information type. Query List: AT+KGSN=? Purpose: Display valid parameter values. <p>Parameters:</p> <p><number_type> (Information type to display)</p> <ul style="list-style-type: none"> valid range: 0–4 <p><IMEI> (15-digit IMEI)</p> <ul style="list-style-type: none"> Format: <8-digit TAC> + <6-digit SNR> + <1-digit check> e.g. 351578000023006 <p><IMEISV> (16-digit IMEISV)</p> <ul style="list-style-type: none"> Format: <8-digit TAC> + <6-digit SNR> + <2-digit SVN> e.g. 3515780000230001 <p><IMEISV_STR> (Formatted IMEISV string)</p> <ul style="list-style-type: none"> Format: <15-digit + 1 check digit> SV: <software version> e.g. 35157800002300-6 SV:01 <p><FSN> (14-character serial number)</p> <ul style="list-style-type: none"> String e.g. 0123456789ABCD <p><FSN-BB> (14-character serial number) + 2-digit batch revision)</p> <ul style="list-style-type: none"> String e.g. 0123456789ABCD01

Table 3-2: Modem Status Command Details (Continued)

Command	Description																																																																							
+KMCLASS	<p>Set 2G multislots class</p> <p>Set the device's 2G (GPRS/EGPRS) multislots class. The new setting takes effect after the device is reset.</p> <p>Password required: No Reset required to apply changes: Yes Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+KMCLASS=<mclass> Response: OK Purpose: Set the desired multislots class. • Query: AT+KMCLASS? Response: +KMCLASS: <mclass> OK Purpose: Report the current multislots class. • Query List: AT+KMCLASS=? Purpose: Return the execution command format and the supported parameter values. <p>Parameters:</p> <p><mclass> (Multislots class)</p> <ul style="list-style-type: none"> • Integer value (Default—33) • Valid values: <table border="1" data-bbox="557 984 1256 1852"> <thead> <tr> <th rowspan="2">Class</th> <th colspan="3">Max number of slots</th> </tr> <tr> <th>Rx</th> <th>Tx</th> <th>Total</th> </tr> </thead> <tbody> <tr><td>1</td><td>1</td><td>1</td><td>2</td></tr> <tr><td>2</td><td>2</td><td>1</td><td>3</td></tr> <tr><td>3</td><td>2</td><td>2</td><td>3</td></tr> <tr><td>4</td><td>3</td><td>1</td><td>4</td></tr> <tr><td>5</td><td>2</td><td>2</td><td>4</td></tr> <tr><td>6</td><td>3</td><td>2</td><td>4</td></tr> <tr><td>7</td><td>3</td><td>3</td><td>4</td></tr> <tr><td>8</td><td>4</td><td>1</td><td>5</td></tr> <tr><td>9</td><td>3</td><td>2</td><td>5</td></tr> <tr><td>10</td><td>4</td><td>2</td><td>5</td></tr> <tr><td>11</td><td>4</td><td>3</td><td>5</td></tr> <tr><td>12</td><td>4</td><td>4</td><td>5</td></tr> <tr><td>30</td><td>5</td><td>1</td><td>6</td></tr> <tr><td>31</td><td>5</td><td>2</td><td>6</td></tr> <tr><td>32</td><td>5</td><td>3</td><td>6</td></tr> <tr><td>33</td><td>5</td><td>4</td><td>6</td></tr> </tbody> </table>	Class	Max number of slots			Rx	Tx	Total	1	1	1	2	2	2	1	3	3	2	2	3	4	3	1	4	5	2	2	4	6	3	2	4	7	3	3	4	8	4	1	5	9	3	2	5	10	4	2	5	11	4	3	5	12	4	4	5	30	5	1	6	31	5	2	6	32	5	3	6	33	5	4	6
Class	Max number of slots																																																																							
	Rx	Tx	Total																																																																					
1	1	1	2																																																																					
2	2	1	3																																																																					
3	2	2	3																																																																					
4	3	1	4																																																																					
5	2	2	4																																																																					
6	3	2	4																																																																					
7	3	3	4																																																																					
8	4	1	5																																																																					
9	3	2	5																																																																					
10	4	2	5																																																																					
11	4	3	5																																																																					
12	4	4	5																																																																					
30	5	1	6																																																																					
31	5	2	6																																																																					
32	5	3	6																																																																					
33	5	4	6																																																																					

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+KSIMDET	<p>Enable/Disable SIM Detection notifications</p> <p>Enable or disable unsolicited notifications on SIM insertion or removal. For notification format, see +SIM (notification).</p> <p>Notes:</p> <ul style="list-style-type: none"> • This command can be supported even without a SIM card. • This command is only applicable to external SIM card detection. • UIM1_DET (GPIO 34) is used for SIM1 detection. <p>Password required: No</p> <p>Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+KSIMDET=<mode> Response: +KSIMDET: <mode> OK Purpose: Enable or disable SIM detection notifications. • Query: AT+KSIMDET? Response: +KSIMDET: <mode> OK Purpose: Display the current state of SIM detection notifications. • Query List: AT+KSIMDET=? Purpose: Display valid parameter values. <p>Parameters:</p> <p><mode> (Unsolicited SIM notifications state)</p> <ul style="list-style-type: none"> • 0—Disable SIM detection notifications • 1—Enable SIM detection notifications (Default) <p>Example(s):</p> <pre>// Enable SIM detection URC indications AT+KSIMDET=1 OK // SIM card is removed +SIM: 0 // SIM card is inserted +SIM: 1 // No URC indication when SIM card is removed or inserted AT+KSIMDET=0 OK // Read current setting AT+KSIMDET? +KSIMDET: 0 OK // Test command AT+KSIMDET=? +KSIMDET: (0-1) OK</pre>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+KSLEEP	<p>Configure UART1 power management (sleep mode entry conditions)</p> <p>Configure UART1 power management, indicating under which conditions the module will enter sleep mode.</p> <p>Password required: No</p> <p>Persistent across power cycles: Yes</p> <p>Requirements:</p> <ul style="list-style-type: none"> To have DTR control sleep mode (<mngt>=0), AT!RIOWNER=0 must be used before using +KSLEEP. <p>Notes:</p> <ul style="list-style-type: none"> Controls only UART1 power management; does not affect USB AT command port. When KSLEEP=1 and the module is in sleep mode, the user must input a character to wake the module. When the module is awake, AT commands can be input as normal. <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT+KSLEEP=<mngt> Response: OK Purpose: Set the power management configuration. Query: AT+KSLEEP? Response:! +KSLEEP: <mngt> OK Purpose: Indicate current power management configuration. Query list: AT+KSLEEP=? Purpose: Return a list of supported <mngt> values. <p>Parameters:</p> <p><mngt> (UART1 Power management configuration)</p> <ul style="list-style-type: none"> 0—Module will not enter sleep mode when DTR is active (low level). If DTR is inactive, module enters sleep mode once all wakeup sources are released. Note: DTR must be active to send AT commands. 1—Module enters sleep mode automatically after 5 seconds of inactivity. 2—Module never enters sleep mode (regardless of DTR state)

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+KSRAT	<p>Set the current RAT Set the current RAT mode(s) for acquisition.</p> <hr/> <p>Important: To avoid issues with incompatible RAT/band combinations, !BAND must be set to 'All Bands', and !SELRAT must not be used.</p> <hr/> <p>Password required: No Reset required to apply changes: No Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+KSRAT=<ratInd> Response: OK Purpose: Set the desired RAT. • Query: AT+KSRAT? Response: +KSRAT: <ratInd> OK or Unknown RAT mode. Use AT+KSRAT to set mode. OK Purpose: Return the current RAT (<ratInd>). • Query List: AT+KSRAT=? Purpose: Return a list of supported RAT index values and their descriptions. <p>Parameters: <ratInd> (RAT index):</p> <ul style="list-style-type: none"> • 0—All RATs, automatic • 1—GSM only • 2—UMTS only • 4—UMTS and GSM • 5—LTE only • 7—LTE and UMTS • 9—LTE and GSM

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+KSREP	<p>Enable/disable startup reporting</p> <p>Enable or disable startup reporting.</p> <p>When enabled, the module sends an unsolicited notification (+KSUP (notification)) during startup.</p> <p>By default, startup reporting is disabled.</p> <p>Password required: No</p> <p>Reset required to apply changes: No</p> <p>Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+KSREP=<mode> Response: OK Purpose: Enable or disable startup reporting. • Query: AT+KSREP? Response: +KSREP: <mode>,<status> OK Purpose: Report current setting for startup reporting, and the current status. • Query List: AT+KSREP=? Purpose: Return the execution command format. See the parameter descriptions below for details. <p>Parameters:</p> <p><mode> (Startup reporting state)</p> <ul style="list-style-type: none"> • 0 (Default)—Disabled • 1—Enabled <p><status> (Module status)</p> <ul style="list-style-type: none"> • 0—Module is ready to receive commands for the TE. No access code is required. • 1—Module is waiting for an access code. Use AT+CPIN? to determine the code. • 2—SIM card is not present. • 3—Module is in "SIM lock" state. • 4—Unrecoverable error • 5—Unknown state
+KSUP (notification)	<p>Startup notification (unsolicited notification)</p> <p>Unsolicited notification received from the module at startup, if enabled using +KSREP.</p> <p>Usage:</p> <ul style="list-style-type: none"> • Notification: +KSUP: <status> Purpose: Indicates the state of the module at startup time. <p>Parameters:</p> <p><status> (Module status)</p> <ul style="list-style-type: none"> • 0—Module is ready to receive commands for the TE. No access code is required. • 1—Module is waiting for an access code. Use AT+CPIN? to determine the code. • 2—SIM card is not present. • 3—Module is in "SIM lock" state. • 4—Unrecoverable error • 5—Unknown state

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!MAPUART	<p>Map services to UART</p> <p>Map services to the module's physical UARTs. Note that a reset is required for the change to take effect.</p> <hr/> <p><i>Note: Input to UART2 (when mapped as a Linux Console) cannot wake the module while it is sleeping.</i></p> <hr/> <p>Password required: No Reset required to apply changes: Yes Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: ATIMAPUART=<service>[,<uart>] Response: OK Purpose: Map the specified <service> to the specified <uart> (if no <uart> is specified, UART1 is used). • Query: ATIMAPUART? Response: !MAPUART: <service (UART1)>[,<service (UART2)>] OK Purpose: Report the current mappings for both UARTs. • Query List: ATIMAPUART=? Purpose: Return the command format and the supported parameter values. <p>Parameters:</p> <p><service> (Service to map to a UART)</p> <ul style="list-style-type: none"> • 0—UART disabled • 1—AT command service (Note: Not available for UART2) <p><uart> (Physical UART)</p> <ul style="list-style-type: none"> • 1—UART1 (Default) • 2—UART2

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!MUXMODE	<p>Enable/disable CMUX mode Enable CMUX (over UART or USB) or disable the feature. Password required: No Reset required to apply changes: Yes Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!MUXMODE=<mode> Response: OK Purpose: Enable or disable CMUX feature. • Query: AT!MUXMODE? Response: !MUXMODE: <mode> OK Purpose: Report current state of CMUX feature. • Query List: AT!MUXMODE=? Purpose: Return the execution command format and the supported parameter values. <p>Parameters: <mode> (CMUX feature state)</p> <ul style="list-style-type: none"> • 0—Disable (Default) • 1—Enable CMUX over UART • 2—Enable CMUX over USB
!NETNUM	<p>Set/report number of supported network interfaces Configure the modem to support a specific NAS (Non-Access Stratum) release compliance version. Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!NETNUM=<usb_netnum> Response: OK Purpose: Set the number of supported network interfaces. • Query: AT!NETNUM? Response: <usb_netnum> OK Purpose: Report the number of supported network interfaces. <p>Parameters: <usb_netnum> (Number of network interfaces supported over USB (RmNet))</p> <ul style="list-style-type: none"> • 0–255

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!NVBACKUP	<p>Backup NV data Password required: Yes (for <category=2>)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!NVBACKUP=<category>] Response: !NVBACKUP: NV Items Saved: <saved> [NV Items Skipped: <skipped>] OK Purpose: Perform the specified backup type. <p>Parameters:</p> <category> (Backup type) <ul style="list-style-type: none"> • 2—OEM/User • 3—Cache (Boot and frequently-updated NV items) <saved> (Number of NV items saved) <ul style="list-style-type: none"> • Range: 0–255 <skipped> (Number of NV items skipped) <ul style="list-style-type: none"> • Range: 1–255 • The 'skipped' response line does not appear if there were no items skipped.
!PACKAGE	<p>Return package version string This command returns the configuration package name loaded in the modem. Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Query: AT!PACKAGE? Response: !PACKAGE:<PackageName> OK Purpose: Return the package name string. <p>Parameters:</p> <PackageName> <ul style="list-style-type: none"> • Character string, maximum 126 characters • Example: MC7750_01.00.02.03_00_VZW_011.006_000

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!PATEMP	<p>Return PA temperature information</p> <p>Return the module's PA temperature state and current temperature.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Query: ATIPATEMP? Response: Temp state: <state> Temperature: <temperature> degC OK Purpose: Return the module's Power control temperature information. <p>Parameters:</p> <p><state> (Temperature state):</p> <ul style="list-style-type: none"> • Valid values: <ul style="list-style-type: none"> • "Initializing" • "Normal" • "High Warning" • "High Critical" <p><temperature> (Current temperature):</p> <ul style="list-style-type: none"> • Decimal ASCII string • Current PA temperature in degrees Celsius. This is the temperature reported by a thermistor positioned near the power amplifiers. • Example: "32.3"
!PATEMP (notification)	<p>PA temperature state change—Unsolicited notification</p> <p>Unsolicited notification received when the PA temperature state changes.</p> <p>To enable !PATEMP (and other notifications), use AT+WUSLMSK.</p> <p>Notification format:</p> <p>!PATEMP: <state></p> <p>Parameters:</p> <p><state> (PMIC temperature state)</p> <ul style="list-style-type: none"> • Valid range: 1–3 • 1—Normal • 2—High Warning • 3—High Critical

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!PCINFO	<p>Return power control status information</p> <p>Return the modem's power control status information.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Query: AT!PCINFO? Response: State: <state> LPM force flags - W_DISABLE:<ForceFlag>, User:<ForceFlag>, Temp:<ForceFlag>, Volt:<ForceFlag>, BIOS:<ForceFlag>, GOBIIM:<ForceFlag> W_DISABLE: <ForceFlag> Poweroff mode: <ForceFlag> LPM Persistent: <ForceFlag> OK Purpose: Return power control information. <p>Parameters:</p> <p><state> (The modem's power mode)</p> <ul style="list-style-type: none"> • ASCII string (quotation marks do not appear): <ul style="list-style-type: none"> • "Emergency Call" • "Emergency Call LPM" • "Emergency Call Power Down" • "Emergency Call Reset" • "Initialization" • "Low Power Mode" • "LPM in Progress" • "Offline" • "Offline In Progress" • "Online" • "Online In Progress" • "Power Down" • "Power Down In Progress" • "Reset" • "Reset In Progress" <p><ForceFlag> (List of conditions indicating which ones caused modem to enter LPM)</p> <ul style="list-style-type: none"> • Valid values: <ul style="list-style-type: none"> • 0=Did not cause 1=Caused • Condition types: <ul style="list-style-type: none"> • W_DISABLE—W_DISABLE is asserted • USER—AT/SDK/Legato command was issued • TEMP—Temperature is outside operational limits • VOLT—Voltage is outside operational limits • BIOS—Host BIOS locking is enabled • GOBIIM—Image preference mismatch

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!PCTEMP	<p>Return Power control temperature information</p> <p>Return the module's power control temperature state and current temperature.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Query: AT!PCTEMP? Response: Temp state: <state> Temperature: <temperature> degC OK Purpose: Return the module's power control temperature information. <p>Parameters:</p> <p><state> (Temperature state):</p> <ul style="list-style-type: none"> • Valid values: <ul style="list-style-type: none"> • "Initializing" • "Normal" • "High Warning" • "High Critical" • "Low Critical" <p><temperature> (Current temperature):</p> <ul style="list-style-type: none"> • Decimal ASCII string • Current temperature in degrees Celsius. • Example: "32.3"
!PCTEMP (notification)	<p>PMIC temperature state change—Unsolicited notification</p> <p>Unsolicited notification received when the PMIC temperature state changes. To enable !PCTEMP (and other notifications), use AT+WUSLMSK.</p> <p>Notification format:</p> <p>!PCTEMP: <state></p> <p>Parameters:</p> <p><state> (PMIC temperature state)</p> <ul style="list-style-type: none"> • Valid range: 1–5 • 1—Normal • 2—High Warning • 3—High Critical • 4—Low Warning • 5—Low Critical

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!PCTEMPLIMITS	<p>Set/report temperature state limit values</p> <p>Certain modem functionality is affected by the modem's temperature state. The possible temperature states are high critical, high warning, high normal, low normal, and low critical. Use this command to report or set the limits that correspond to these temperature states. To display the current temperature and temperature state, see !PCTEMP on page 85.</p> <hr/> <p><i>Note: All temperatures are in Celsius.</i></p> <hr/> <p>Password required: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!PCTEMPLIMITS=<hc>,<hw>,<hn>,<ln>,<lc> Response: OK Purpose: Set the temperature limits for each state (all five values must be specified). • Query: AT!PCTEMPLIMITS? Response: HI CRIT: <hc> HI WARN: <hw> HI NORM: <hn> LO NORM: <ln> LO CRIT: <lc> Purpose: Return the temperature limits for each state. <p>Parameters:</p> <hr/> <p><i>Note: Minimum separation between threshold values is 4°C. (e.g. If <hc> = 120, <hw> must be ≤ 116.)</i></p> <hr/> <p><hc> (High Critical)</p> <ul style="list-style-type: none"> • Temperature limit varies by device (see device Product Specification Document or Product Technical Specification). • Default = 108°C. <p><hw> (High Warning)</p> <ul style="list-style-type: none"> • Temperature limit varies by device (see device Product Specification Document or Product Technical Specification). • Default = 95°C. <p><hn>(High Normal)</p> <ul style="list-style-type: none"> • Temperature limit varies by device (see device Product Specification Document or Product Technical Specification). • Default = 85°C. <p><ln> (Low Normal)</p> <ul style="list-style-type: none"> • Temperature limit varies by device (see device Product Specification Document or Product Technical Specification). • Default = -15°C. <p><lc> (Low Critical)</p> <ul style="list-style-type: none"> • Temperature limit varies by device (see device Product Specification Document or Product Technical Specification). • Default = -25°C.

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!PCVOLT	<p>Return current power supply voltage information Return the module's power control supply state and actual voltage. Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Query: AT!PCVOLT? Response: Volt state: Normal Power supply voltage: <voltage> mV (<raw> cnt) OK Purpose: Return the module's voltage information. <p>Parameters:</p> <p><state> (Power supply state):</p> <ul style="list-style-type: none"> • Valid values: <ul style="list-style-type: none"> • "Initializing" • "Normal" • "High Critical" • "Low Warning" • "Low Critical" <p><voltage>:</p> <ul style="list-style-type: none"> • Current voltage reading in mV. • Decimal ASCII <p><raw>:</p> <ul style="list-style-type: none"> • ADC (Analog/digital convertor) reading • Decimal ASCII
!PCVOLT (notification)	<p>PMIC voltage state change—Unsolicited notification Unsolicited notification received when the PMIC voltage state changes. To enable !PCVOLT (and other notifications), use AT+WUSLMSK.</p> <p>Notification format: !PCVOLT: <state></p> <p>Parameters:</p> <p><state> (Power supply state)</p> <ul style="list-style-type: none"> • Valid range: 1–4 • 1—Normal • 2—Low Warning • 3—Low Critical • 4—High Critical

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!PCVOLTLIMITS	<p>Set/report power supply voltage state limit values</p> <p>Certain modem functionality is affected by the modem's power supply voltage state. The possible voltage states are high critical, high normal, low normal, low warning, and low critical. Use this command to report or set the limits that correspond to these voltage states.</p> <p>Password required: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!PCVOLTLIMITS=<hc>,<hn>,<ln>,<lw>,<lc> Response: OK Purpose: Set the voltage limits for each state (all five values must be specified). • Query: AT!PCVOLTLIMITS? Response: HI CRIT: <hc> HI NORM: <hn> LO NORM: <ln> LO WARN: <lw> LO CRIT: <lc> Purpose: Return the voltage limits for each state. <p>Parameters:</p> <p><hc> (High Critical)</p> <ul style="list-style-type: none"> • Voltage limit varies by device (see device Product Specification Document or Product Technical Specification) • Default = 4400 mV <p><hn> (High Normal)</p> <ul style="list-style-type: none"> • Voltage limit varies by device (see device Product Specification Document or Product Technical Specification) • Default = 4300 mV <p><ln> (Low Normal)</p> <ul style="list-style-type: none"> • Voltage limit varies by device (see device Product Specification Document or Product Technical Specification) • Default = 3300 mV <p><lw> (Low Warning)</p> <ul style="list-style-type: none"> • Voltage limit varies by device (see device Product Specification Document or Product Technical Specification) • Default = 3200 mV <p><lc> (Low Critical)</p> <ul style="list-style-type: none"> • Voltage limit varies by device (see device Product Specification Document or Product Technical Specification) • Default = 3100 mV
!POWERDOWN	<p>Power down system</p> <p>Power down the system.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!POWERDOWN Response: OK Purpose: Power the system down.

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!POWERMODE	<p>Enable/disable PSM</p> <p>Enable or disable power saving mode (PSM). When this command is used to enable PSM, the +CPSMS parameters will be renegotiated with the network at the same time.</p> <p>A network-connected device will enter PSM only if the PSM parameter's negotiation succeeds. (The parameters (timers) specified in +CPSMS are requested values—the PSM negotiation determines the actual timer values that will be used.)</p> <p>Password required: No</p> <p>Requirements:</p> <ul style="list-style-type: none"> • AT!POWERWAKE must be used to configure wakeup sources before using this command to enable PSM. <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!POWERMODE=<mode> Response: OK Purpose: Enable/disable PSM. • Query: AT!POWERMODE? Response: !POWERMODE: <mode> Purpose: Display the current state of PSM. • Query List: AT!POWERMODE=? Purpose: Return the execution command format and the supported parameter values. <p>Parameters:</p> <p><mode> (Power saving mode)</p> <ul style="list-style-type: none"> • 0—Disable PSM. • 1—Enable PSM. When enabled, the module enters PSM, then begins monitoring for wakeup sources that were previously configured using !POWERWAKE. • To power down the module use !POWERDOWN.

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!POWERWAKE	<p>Configure PSM wakeup sources</p> <p>Configure the wakeup sources (triggers) for Power Saving Mode (PSM). When a module is in PSM, it is in a network-aware state. The module's low state is registered on the network and sleep time is negotiated. When a configured trigger is detected (e.g. when the trigger meets the <above> and <below> conditions), the module boots.</p> <hr/> <p><i>Note: Use <above> and <below> as follows:</i></p> <ul style="list-style-type: none"> • To set a trigger condition inside a range (e.g. trigger in the range 0.5 to 1.0V), set <below> > <above> (e.g. trigger: <above> 0.5V and <below> 1.0V) • To set a trigger condition outside a range (e.g. trigger outside the range 0.5 to 1.0V), set <below> < <above> (e.g. trigger: <below> 0.5V and <above> 1.0V) <hr/> <p>After configuring wakeup triggers, the command AT!POWERMODE can be used to enter PSM.</p> <p>Password required: No</p> <p>Persistent across power cycles: Partial (PSM timers persist, GPIO and ADC do not persist)</p> <p>Notes:</p> <ul style="list-style-type: none"> • Timer must be configured for PSM mode. • At least one wakeup source must be configured before !POWERMODE can be used to select a power saving mode option that requires wakeup sources. • The PSM timer is not cleared by the "Execution (clear)" command format. <p>Usage:</p> <ul style="list-style-type: none"> • Execution (timer): AT!POWERWAKE=<type>,<psm>,[<active>] <p>Response: OK</p> <p>Purpose: Set the timeout period for a wakeup timer.</p> <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!POWERWAKE continued	<p>Configure ULPS (ULPM/PSM) wakeup sources (continued)</p> <ul style="list-style-type: none"> Query: AT!POWERWAKE? Response: !POWERWAKE:<type>,<psm>,<active> OK Purpose: Show currently configured wakeup sources. If a source is not configured, it will not appear. Query List: AT!POWERWAKE=? Purpose: Return the execution command format and the supported parameter values. <p>Parameters:</p> <p><type> (Wakeup source type)</p> <ul style="list-style-type: none"> 1—Timer <p><psm> (Requested timer duration for staying in PSM)</p> <ul style="list-style-type: none"> Timer is the requested extended periodic TAU value (refer to +CPSMS). Timer value must be greater than threshold specified in PSM configuration. Max value: 35712000 (Timer duration in seconds) Note: Power consumption may be impacted if a short timeout is used. <p><active> (Requested active timer duration, in seconds)</p> <ul style="list-style-type: none"> 0–3456000—Active timer duration. The value indicates the period during which the device remains reachable for mobile-terminated (MT) transactions on transition from connected mode to idle mode. If no value is specified, active time of 0 is configured. Value must conform to GPRS Timer 2 IE in 3GPP TS 24.008.
!PRIID	<p>Report module PRI part number and revision</p> <p>Report the module's customer and carrier PRI part numbers and revisions.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> Query: AT!PRIID? Response: PRI Part Number: <priPn> Revision: <priRevDisplay> <p>Carrier PRI: None OK</p> <p>Purpose: Return the module's PRI part number (<priPn>) and revision (<priRevDisplay>). (In the example shown above, no Carrier PRI is present. If it were, then the Part Number and Revision would display.)</p> <p>Parameters:</p> <p><priPn> (PRI part number)</p> <ul style="list-style-type: none"> 7-digit ASCII number Example: 9991234 <p><priRevDisplay> (PRI revision number being read from the module)</p> <ul style="list-style-type: none"> 4-digit ASCII: XX.YY Example: 01.00

Table 3-2: Modem Status Command Details (Continued)

Command	Description
*PSRDBS	<p>Select operating bands</p> <p>Select the device's operating bands.</p> <p>Password required: No</p> <p>Reset required to apply changes: No</p> <p>Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT*PSRDBS=<mode>,<band> Response: OK Purpose: Set a group of bands (<band>) to take effect when specified by <mode>. If the selected bands conflict with the current RAT setting, an error will be returned. If the command succeeds and <band> does not match any of the existing frequency groups from AT!BAND=?, then <band> creates or replaces the "User bands" group in the !BAND list. (This is a persistent change.) • Query: AT*PSRDBS? Response: *PSRDBS: <band> OK Purpose: Report the current <band> value (which identifies the list of operating bands). • Query List: AT*PSRDBS=? Purpose: Return the execution command format and the supported parameter values. <p>Parameters:</p> <p><mode> (Time when <band> selection takes effect)</p> <ul style="list-style-type: none"> • 0 = Set operating bands at next boot • 1 = Set operating bands immediately <p><band> (Operating bands to use)</p> <ul style="list-style-type: none"> • Integer value (sum of values associated with operating bands): <ul style="list-style-type: none"> • 2—GSM 900MHz (G900) • 8—DCS 1800MHz (G1800) • 32—UMTS Band I (W2100) • 64—UMTS Band II (W1900) • 128—UMTS Band IV (W1700) • 256—UMTS Band V (W850) • 512—UMTS Band VIII (W900) • 131072—LTE Band 1 (B1) • 524288—LTE Band 3 (B3) • 1048576—LTE Band 4 (B4) • 2097152—LTE Band 5 (B5) • 8388608—LTE Band 7 (B7) • 16777216—LTE Band 8 (B8) • 268435456—LTE Band 12 (B12) • 536870912—LTE Band 13 (B13) • 1073741824—LTE Band 14 (B14) • 8589934592—LTE Band 17 (B17) • 68719476736—LTE Band 20 (B20) • 2199023255552—LTE Band 25 (B25) <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
*PSRDBS (continued)	Select operating bands (continued) <ul style="list-style-type: none"> • 4398046511104—LTE Band 26 (B26) • 17592186044416—LTE Band 28 (B28) • 72057594037927936—LTE Band 40 (B40) • 144115188075855872—LTE Band 41 (B41) • 2305843009213693952—LTE Band 66 (B66)
!RESET	Reset modem Perform a modem reset. Password required: No Usage: <ul style="list-style-type: none"> • Execution: AT!RESET Response: OK Purpose: Reset the modem.

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+RSCP	<p>Display RSCP value(s) (WCDMA only)</p> <p>Display the Received Signal Code Power (RSCP) of the active set's neighbor cells (WCDMA only).</p> <p>Values are displayed as signed dBm and listed in order from strongest to weakest cell.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Query: AT+RSCP? <p>Response (Single-carrier cells):</p> <pre>+RSCP: [<nbr_cell PSC>,<freq>,<nbr_cell strength>] [, ...] OK</pre> <p>Response (Dual-carrier cells):</p> <pre>+RSCP: Car0 RSCP: [<nbr_cell PSC>,<freq>,<nbr_cell strength>] [, ...] Car1 RSCP: [<nbr_cell PSC>,<freq>,<nbr_cell strength>] [, ...] OK</pre> <p>Purpose: Display RSCP values for the supported neighbor cells.</p> <p>Parameters:</p> <p><nbr_cell PSC> (Neighbor cell's Primary Scrambling Code)</p> <ul style="list-style-type: none"> • signed dBm <p><freq> (Neighbor cell's frequency, in Hz)</p> <ul style="list-style-type: none"> • Integer value <p><nbr_cell strength> (Neighbor cell's strength, in signed dBm)</p> <ul style="list-style-type: none"> • Signed numeric string (quotes included) • Format: "±999.999" (e.g. "-070.00") <p>Examples:</p> <ul style="list-style-type: none"> • AT!RSCP? (<i>Single-carrier cells</i>) <pre>+RSCP: 480,10613,"-070.00",488,10613,"-073.00",232,10613,"-075.00",220,10613,"-078.00" OK</pre> <ul style="list-style-type: none"> • AT!RSCP? (<i>Dual-carrier cells</i>) <pre>Car0 RSCP: 480,10613,"-070.00",488,10613,"-073.00",232,10613,"-075.00",220,10613,"-078.00" Car1 RSCP: 480,10613,"-070.00",488,10613,"-073.00",232,10613,"-075.00",220,10613,"-078.00" OK</pre>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
S11	<p>Query/set DTMF dialing speed</p> <p>This command has no effect.</p> <p><i>Note:</i> The purpose of including the command is to comply with V.25ter.</p> <p>Notes:</p> <ul style="list-style-type: none"> Parameters are ignored and are not saved in non-volatile memory. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: ATS11=<time> Response: OK Purpose: Set DTMF dialing speed. Query: ATS11? Response: <time> OK Purpose: Display DTMF dialing speed. <p>Parameters:</p> <p><time> (DTMF dialing speed, in milliseconds)</p> <ul style="list-style-type: none"> Valid range: 50–255

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!ISCACT	<p>Activate/deactivate data connection</p> <p>Activate or deactivate a specific data connection between the host and network.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: ATISCACT=<state>,<pid> Response: OK Purpose: Activate or deactivate the connection for the specified <pid>. If <pid> is not included, use the default <pid> (see <pid> for values). • Query: ATISCACT?[<pid>] Response: !ISCACT: <pid>,<state> ... (additional <pid>/<state> combinations) OK Purpose: Display a list of all defined connections and their current state, or display a specified connection and its state. • Query list: ATISCACT=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><pid> (PDN connection ID)</p> <ul style="list-style-type: none"> • Valid values: <ul style="list-style-type: none"> • GSM/UMTS/LTE: <ul style="list-style-type: none"> • 1–16 • 3 (Sprint, Verizon) • CDMA: <ul style="list-style-type: none"> • 101–107 • Default: 101 (all networks except Sprint and Verizon) • 103 (Sprint, Verizon) <p><state> (Current state of specified <pid>)</p> <ul style="list-style-type: none"> • 0= Deactivated • 1=Activated • Any other value causes command execution to return ERROR.

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!SCUMMTU	<p>Set/Report MTU Size</p> <p>Set or report the MTU (maximum transmission unit) size used by 3GPP/3GPP2 Um and USB Rm interface.</p> <p>Password required: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!SCUMMTU=<mtu> Response: OK Purpose: Set the MTU size for all RATs/interfaces. • Query: AT!SCUMMTU? Response: !SCUMMTU: 3GPP MTU : <mtu> USB MTU : <mtu> OK Purpose: Display the MTU sizes used for supported RATs (only supported RATs will appear). • Query list: AT!SCUMMTU=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><mtu> (Maximum Transmission Unit, in bytes)</p> <ul style="list-style-type: none"> • 0—Use default value • 576–2000—Other values required by carriers.

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!SELACQ	<p>Select RAT acquisition order Select the acquisition order for RATs (Radio Access Technologies).</p> <hr/> <p><i>Note: If the last registered PLMN is found from either the SIM/USIM card or NV storage, it takes precedence over the acquisition order from this command for registration.</i></p> <hr/> <p>Password required: Yes</p> <p>Usage:</p> <hr/> <p><i>Note: The number of <mode> parameters supported varies is device dependent. Use the Query list command format to show the supported number and type of <mode> values.</i></p> <hr/> <ul style="list-style-type: none"> • Execution: ATISELACQ=<mode1>[,<mode2>[,<mode3>[,<mode4>[,<mode5>[,<mode6>]]]]] Response: OK Purpose: Indicate the RAT acquisition order (number of RATs is device dependent). See <mode> parameter description for details. • Query: ATISELACQ? Response: <mode1> <mode2> <mode3> <mode4> <mode5> <mode6> OK Purpose: Show the current acquisition order for the supported RATs. • Query list: ATISELACQ=? Purpose: Display valid execution format and parameter values. <p>Parameters: <moden> (RAT types)</p> <ul style="list-style-type: none"> • Available RAT types are device-dependent. (e.g. "TDS" valid only on modules supporting TDSCDMA) Valid values: <ul style="list-style-type: none"> • "CDMA" • "LTE" • "LTE-M1" • "LTE-NB1" • "WCDMA" • "HDR" • "GSM" • "TDS" • If the execution format is issued with fewer than the number of supported <mode>s, the missing entries are appended based on the default order shown above. <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
<p>!SELACQ (continued)</p>	<p>Select RAT acquisition order (continued)</p> <ul style="list-style-type: none"> Example: If the command is issued as ATISELACQ=HDR,CDMA,GSM Then ATISELACQ? will show: <pre>HDR CDMA GSM LTE WCDMA</pre> <hr/> <p><i>Note: Even if the device does not support a specific RAT (for example, CDMA), the RAT will still appear in the Query List response.</i></p>
<p>!SELCIOT</p>	<p>Set/report Cellular IoT preferences</p> <p>Use this command to set Cellular IoT (CIOT) operating mode preferences on the device.</p> <hr/> <p><i>Note: The acquisition order of the selected LTE operating modes can be set using AT!SELACQ.</i></p> <hr/> <p>Password required: No Reset required to apply changes: No Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: ATISELCIOT=<oper_mode> Response: OK Purpose: Enable/disable the LTE operating modes (based on bitmask value). Query: ATISELCIOT? Response: Current Operating Mode: <oper_mode> <p style="margin-left: 40px;">Supported Operating Modes: LTE WB: 0x01 LTE M1: 0x02 LTE NB1: 0x04 OK</p> <ul style="list-style-type: none"> Purpose: Indicate the currently enabled LTE operating modes (bitmask value). Query List: ATISELCIOT=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><oper_mode> (LTE operating modes)</p> <ul style="list-style-type: none"> Format: 8-bit bitmask <ul style="list-style-type: none"> Each bit: 0=Disabled; 1=Enabled Bit 0—LTE WB (Non-CIOT (M1/NB1) operation) Bit 1—LTE M1 Bit 2—LTE NB1

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!SELMODE	<p>Set/return current service domain Configure the modem to use a specific service domain. Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: ATISELMODE=<sdInd> Response: OK Purpose: Set the desired service domain. • Query: ATISELMODE? Response: <sdInd>, Service Domain description OK <i>or</i> Unknown service domain mask. Use ATISELMODE to set service domain. <sdInd> OK • Query List: ATISELMODE=? Purpose: Return a list of supported service domain indexes. <p>Parameters: <sdInd> (Service domain index):</p> <ul style="list-style-type: none"> • 00=CS only • 01=PS only • 02=CS and PS

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!SELRAT	<p>Set preferred RAT</p> <p>Set the preferred RAT mode(s) for acquisition.</p> <p>If the module's current band setting is not compatible with the selected RAT, an appropriate band will be selected automatically and set on the modem.</p> <p>TD-SCDMA-related RATs are available only on products supporting TD-SCDMA.</p> <hr/> <p>Important: <i>To avoid issues with incompatible RAT/band combinations:</i></p> <ul style="list-style-type: none"> • If !SELRAT is used, +KSRAT must be set to 'All RATS, automatic'. • If +KSRAT is used, !SELRAT must not be used and !BAND must be set to 'All Bands'. • If !BAND and !SELRAT are used, either !BAND must be set to 'All Bands' or !SELRAT must be set to 'Automatic'. <hr/> <p>Password required: No Reset required to apply changes: No Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!SELRAT=<ratInd> Response: OK Purpose: Set the desired RAT. • Query: AT!SETRAT? Response: <ratInd>, RAT configuration description OK or Unknown RAT mode. Use AT!SELRAT to set mode. <ratInd> OK Purpose: Return the current RAT (<ratInd>) and description. If the <ratInd> is undefined, an error message is returned. • Query List: AT!SELRAT=? Purpose: Return a list of supported RAT index values and their descriptions. <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!SELRAT (continued)	<p>Set preferred RAT (continued)</p> <p>Parameters:</p> <p><ratInd> (RAT index):</p> <ul style="list-style-type: none"> • 00—Automatic • 01—UMTS 3G only • 02—GSM 2G only • 03—UMTS 3G preferred • 04—GSM 2G preferred • 05—GSM and UMTS only • 06—LTE only • 07—GSM, UMTS, LTE • 08—CDMA, HRPD, GSM, UMTS, LTE • 09—CDMA only • 0A—HRPD only • 0B—hybrid CDMA/HRPD • 0C—CDMA, LTE • 0D—HRPD, LTE • 0E—CDMA, HRPD, LTE • 0F—CDMA, GSM, UMTS • 10—CDMA, HRPD, GSM, UMTS • 11—UMTS and LTE only • 12—GSM and LTE only • 13—TDS and LTE only • 14—TDS, GSM, LTE • 15—TDS, WCDMA, LTE • 16—TDS, GSM, WCDMA, LTE • 17—TDS only • 18—TDS and GSM only • 19—TDS and WCDMA only • 1A—TDS, GSM, WCDMA

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!SELSNR	<p>Set/report LTE-NB1 band scan configuration</p> <p>Use this command to set the band scan configuration on LTE-NB1 networks to restrict scanning to certain SNR levels.</p> <p>The available scan options are based on SNR and reflect a trade-off between scan time and depth of scan:</p> <ul style="list-style-type: none"> • Frequency scan level 0—Used for good SNR levels; detects strong cells first and has the shortest cell acquisition time. • Frequency scan level 1—Used for medium SNR levels. • Frequency scan level 2—Used for poor SNR levels; has the longest cell acquisition time. <p>Password required: No Reset required to apply changes: Yes Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: ATISELSNR=<scan_level> Response: OK Purpose: Set the specified scan level combination. • Query: ATISELSNR? Response: !SELSNR: <scan_level> OK Purpose: Indicate the currently scan level combination. • Query List: ATISELSNR=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><scan_types> (SRN Level combinations to attempt by UE during band scan)</p> <ul style="list-style-type: none"> • Integer value • Valid options: <ul style="list-style-type: none"> • 0—Frequency scan level 0 only • 1—Frequency scan level 0, then level 1 • 2—Frequency scan level 0, then level 1, then level 2 • 3—Frequency scan level 2 only
+SIM (notification)	<p>SIM inserted/removed—Unsolicited notification</p> <p>Notification that a SIM card has been inserted or removed.</p> <p>To enable/disable notifications, see +KSIMDET.</p> <p>Notification format:</p> <p>+SIM: <status></p> <p>Parameters:</p> <p><status> (Event status)</p> <ul style="list-style-type: none"> • 0—SIM removed • 1—SIM inserted

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!SKU	<p>Read Module SKU Read the module's SKU value. Password required: Yes</p> <p>Usage:</p> <ul style="list-style-type: none">• Query: ATISKU? Response: <value₁>,<value₂>, ..., <value₄₀> OK <p>Purpose: Display the test history 40-byte array.</p> <p>Parameters:</p> <p><value> (Test history value)</p> <ul style="list-style-type: none">• Hex ASCII format• Range: 00–FF

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!USBCOMP	<p>Set/report USB interface configuration</p> <p>Use this command with modems that have been configured with multiple USB compositions. By default, devices are typically configured to use a USB composition that presents a minimal set of interfaces to reduce end-user modem enumeration time. If the device also supports other compositions, this command can be used to build and select custom compositions from the supported interfaces.</p> <hr/> <p>Important: <i>By default, the DIAG (DM) interface is enabled. This command can be used to disable DIAG (DM), but cannot re-enable it.</i></p> <hr/> <p>Notes:</p> <ul style="list-style-type: none"> • Interface support may vary by product and firmware version. Use the Query List command to determine actual support. • Endpoints: <ul style="list-style-type: none"> • All interfaces support Bulk In and Bulk Out endpoint. • NMEA, Modem, Raw Data, and RMNET interfaces also support an Interrupt In endpoint for notifications. • Endpoint 0 is reserved in both directions. <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: ATIUSBCOMP=<Config Index>,<Config Type>,<Interface bitmask> Response: OK Purpose: Set the current composition. For the change to take effect, you must reset the modem. • Query: ATIUSBCOMP? Response: Config Index: <Config Index> Config Type: <Config Type> Interface bitmask: <Interface bitmask> OK Purpose: Report the current interface composition. • Query List: ATIUSBCOMP=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><Config Index> (Configuration index to which composition applies)</p> <ul style="list-style-type: none"> • Valid value(s): 1 <p><Config Type> (Configuration type)</p> <ul style="list-style-type: none"> • Valid value(s): • 1—Generic • 2—Reserved. Do not use this option, not supported for RC76xx modules. <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!USBCOMP (continued)	<p>Set/report USB interface configuration (continued)</p> <p><Interface bitmask> (Interfaces enabled for selected configuration)</p> <ul style="list-style-type: none"> • Format: 32-bit bitmask • Valid values: <ul style="list-style-type: none"> • 00000001—DIAG (DM). This interface can be disabled, but cannot be re-enabled. • 00000004—NMEA • 00000008—MODEM. This interface cannot be disabled. (The command will return ERROR if this is not selected.) • 00000040—RAWDATA • 00000100—RMNET0 • 00080000—ECM
!USBINFO	<p>Return information from active USB descriptor</p> <p>Return information from the active USB descriptor.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Query: ATIUSBINFO? Response: VID: <vendor_id> APP PID: <app_product_id> BOOT PID: <boot_product_id> Manufacturer: <manuString> Product: <prodString> Purpose: Display USB descriptor information. <p>Parameters:</p> <p><vendor_id> (Vendor ID):</p> <ul style="list-style-type: none"> • Valid range: 0000–FFFF <p><app_product_id> (Product ID used when modem is in application mode):</p> <ul style="list-style-type: none"> • Valid range: 0000–FFFF <p><boot_product_id> (Product ID used when modem is in boot loader mode):</p> <ul style="list-style-type: none"> • Valid range: 0000–FFFF <p><manuString> (Manufacturer string):</p> <ul style="list-style-type: none"> • ASCII string (32 characters maximum) • Example: "Sierra Wireless, Incorporated" <p><prodString> (Product string):</p> <ul style="list-style-type: none"> • ASCII string (64 characters maximum) • Example: "Sierra Wireless RC7620"

Table 3-2: Modem Status Command Details (Continued)

Command	Description
!USBPID	<p>Set/report product ID in USB descriptor</p> <p>Use this command to set the device's product ID in the USB descriptor. (Some devices may support more than one product ID.)</p> <hr/> <p><i>Note: If a custom PID is used for <app product_id>, then the <boot product_id> must be set at the same time.</i></p> <hr/> <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: ATIUSBPID=<app product_id> [,<boot product_id>] Response: OK Purpose: Set the application and boot product IDs in the USB descriptor. NOTE: <boot_product_id> is required if <app_product_id> is a custom PID. • Query: ATIUSBPID? Response: !USBPID: <app_product_id>[, <boot product_id>] OK Purpose: Report the product ID that is stored in the USB descriptor. • Query List: ATIUSBPID=? Purpose: Display a list of default (non-custom) product IDs for the device. <p>Parameters:</p> <p><app product_id></p> <ul style="list-style-type: none"> • Hexadecimal ASCII value. • Valid range: 0000–FFFF <p>< boot product_id></p> <ul style="list-style-type: none"> • Hexadecimal ASCII value. • Valid range: 0000–FFFF • In the Execution command format, if the <app product_id> is a custom PID, then the <boot product_id> must be set at the same time. (To check if the <app product_id> is a custom PID, use AT!UDPID=? to see a list of all available non-custom PIDs.)

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+WFWUPD	<p>Download/install firmware package</p> <p>Download a firmware package, or install the downloaded package locally over the AT port using 1K X-modem protocol.</p> <p>Package download process:</p> <ol style="list-style-type: none"> 1. Download requested with AT+WFWUPD=0. 2. AT port switches to raw data mode. 3. TE sends <NACK> character to host at 1 second intervals to indicate it is ready to receive data using the 1K-Xmodem protocol. 4. Package download begins. 5. 'OK' response is received if package downloads successfully, or a CME ERROR: 3 response is received if no data is sent to the device in 5 minutes. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+WFWUPD=<op> Response: OK or ERROR Purpose: Download or install a firmware package. See <op> parameter description for response details. • Query: AT+WFWUPD? Response: +WFWUPD: <pkg> OK Purpose: Indicate whether a package is available to be installed • Query List: AT+WFWUPD=? Purpose: Return the execution command format and the supported parameter values. <p>Parameters:</p> <p><op> (Operation mode)</p> <ul style="list-style-type: none"> • 0—Start downloading the firmware package using the XModem protocol Execution response: <ul style="list-style-type: none"> • OK—Download succeeded • ERROR—Download failed • 1—Install the firmware update from the downloaded package Execution response: <ul style="list-style-type: none"> • OK—Package is available (has been downloaded). Device reboots immediately to start the firmware update. • ERROR—Package is not available (has not been downloaded). <p><pkg> (Package loading status)</p> <ul style="list-style-type: none"> • 0—No package is available to be installed • 1—Package is loaded and available to be installed

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+WFWUPD (notification)	<p>Firmware package install notification</p> <p>Notification received after a package install is launched with AT+WFWUPD=1. After receiving the notification, use AT!3 and AT!8 to confirm the installed version information.</p> <p>Notification format: +WFWUPD: <stat></p> <p>Examples:</p> <ul style="list-style-type: none"> • AT+WFWUPD? +WFWUPD: 1 <i>Check whether package was previously downloaded. Response indicates package is downloaded and ready to install.</i> AT+WFWUPD=1 <i>Request package installation. Device reboots immediately to start firmware update</i> ... +WFWUPD: 0 <i>Unsolicited notification received indicating package installed successfully</i> • <i>Package previously downloaded using AT+WFWUPD=0</i> AT+WFWUPD=1 <i>Device reboots immediately to start firmware update</i> ... +WFWUPD: 1 <i>Notification received indicating package failed to install</i> <p>Parameters:</p> <p><stat> (Installation status)</p> <ul style="list-style-type: none"> • 0—Package installed successfully • 1—Package did not install. Optionally, use !BCFWUPDATESTATUS on page 142 for firmware update status details.

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+WJAM (notification)	<p>Jamming events—Unsolicited notification</p> <p>Unsolicited notification received for various jamming events. To enable +WJAM (and other notifications), use AT+WUSLMSK.</p> <p>Notification format: +WJAM: <response type>,<jam status>]</p> <p>Examples:</p> <ul style="list-style-type: none"> • +WJAM: 0,2 <i>Intermediate report, possible jammer detected</i> • +WJAM: 1,1 <i>Final result, no jamming detected</i> <p>Parameters:</p> <p><response type> (Response type)</p> <ul style="list-style-type: none"> • 0—Final • 1—Intermediate <hr/> <p><i>Note: If <response_type> = 0 (Final), the <jam status> value can only be 1 (Null) or 5 (Jammed).</i></p> <hr/> <p><jam status> (Jamming status)</p> <ul style="list-style-type: none"> • 0—Unknown. Status is unknown. • 1—Null. No jamming suspicion; radio environment is considered normal. • 2—Low. Low probability that the device is jammed, but some radio environment parameters are considered abnormal. • 3—Medium. Medium probability that the device is jammed; a lot of interference in the radio spectrum. • 4—High. High probability that the device is jammed; radio environment is considered jammed, but there is still a possibility that the module succeeds in synchronizing a cell. • 5—Jammed. Module is jammed; cell synchronization impossible while sufficient power level is detected on a large number of frequencies.

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+WJAMTHRESH	<p>Set/Report Jamming Detection Threshold Value</p> <p>Set or report (display) the jamming detection threshold values for supported modes.</p> <p><i>Note:</i> For details on unsolicited jamming notifications received in response to jamming events, see +WJAM on page 110 for details.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+WJAMTHRESH=<mode>,<threshold> Response: OK Purpose: Set the jamming threshold value for the specified <mode>. • Query: AT+WJAMTHRESH? Response: +WJAMTHRESH: <mode>,<threshold> ... OK Purpose: Display all configured jamming threshold values. • Query List: AT+WJAMTHRESH=? Purpose: Return the execution command format and the supported parameter values. <p>Parameters:</p> <p><mode> (Radio Access Technology (RAT))</p> <ul style="list-style-type: none"> • 0—GSM • 1—UMTS • 2—CDMA • 3—LTE <p><threshold> (Jamming threshold value)</p> <ul style="list-style-type: none"> • Supported range is <mode>-dependent. • Value corresponds to RSSI value (e.g. '45' represents "-45 dBm") • GSM: 0–63 • UMTS: 0–70 • CDMA: 0–125 • LTE: 0–125

Table 3-2: Modem Status Command Details (Continued)

Command	Description
+WUSLMSK	<p>Enable/disable unsolicited notifications</p> <p>Enable or disable unsolicited notifications. When enabled, unsolicited notifications are output to the AT port when specific events occur.</p> <p>By default, unsolicited notifications are disabled.</p> <p>Password required: No</p> <p>Reset required to apply changes: No</p> <p>Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+WUSLMSK=<bitmask>,<mask_position> Response: OK Purpose: Enable or disable the selected notifications (in <bitmask>) defined in the specified 32-bit <mask_position>. • Query: AT+WUSLMSK? Response: +WUSLMSK: <bitmask><mask_position> OK Purpose: Report current state of system mode indications (enabled/disabled), showing the upper 32-bit mask followed by the lower 32-bit mask. Example: +WUSLMSK: 00002B0E710241D0 OK (The upper mask is 00002B0E, and lower mask is 710241D0.) • Query List: AT+WUSLMSK=? Purpose: Return the execution command format. See the parameter descriptions below for details. <p>Parameters:</p> <p><bitmask> (Unsolicited notifications bit mask, applied to the specified 32-bit <mask_position>)</p> <ul style="list-style-type: none"> • Bit mask indicating which notifications to enable/disable. • Range: 00000000–FFFFFFFF. For example: <ul style="list-style-type: none"> • 00000000=All bits off (Default value) • FFFFFFFF=All bits on • Any other combination=Combination of bits off and on • See LOWER unsolicited notifications mask on page 113 and UPPER unsolicited notifications mask on page 114 for supported messages <p><mask_position> (The 32-bit mask of notifications that the <bitmask> is to be applied to.)</p> <ul style="list-style-type: none"> • 0=Lower 32-bit mask • 1=Upper 32-bit mask <p>(Continued on next page)</p>

Table 3-2: Modem Status Command Details (Continued)

Command	Description	
+WUSLMSK (continued)	Enable/disable unsolicited notifications (continued)	
	<i>Note: Notification support is firmware-dependent. Some of these notifications may not be supported or applicable.</i>	
	LOWER unsolicited notifications mask	
	Bit	Mask value Unsolic. Notif. Responsible for:
	0	0x00000001 --- Reserved
	1	0x00000002 --- Reserved
	2	0x00000004 +CSQ (notification) RSSI change across threshold
	3	0x00000008 --- Reserved
	4	0x00000010 --- Reserved
	5	0x00000020 --- Reserved
	6	0x00000040 --- Reserved
	7	0x00000080 --- Reserved
	8	0x00000100 --- Reserved
	9	0x00000200 --- Reserved
	10	0x00000400 --- Reserved
	11	0x00000800 --- Reserved
	12	0x00001000 --- Reserved
	13	0x00002000 --- Reserved
	14	0x00004000 --- Reserved
	15	0x00008000 --- Reserved
	16	0x00010000 --- Reserved
	17	0x00020000 --- Reserved
	18	0x00040000 --- Reserved
	19	0x00080000 --- Reserved
	20	0x00100000 --- Reserved
	21	0x00200000 --- Reserved
	22	0x00400000 --- Reserved
	23	0x00800000 --- Reserved
	24	0x01000000 --- Reserved
	25	0x02000000 --- Reserved
	26	0x04000000 --- Reserved
	27	0x08000000 --- Reserved
28	0x10000000 --- Reserved	
29	0x20000000 --- Reserved	
30	0x40000000 --- Reserved	
31	0x80000000 --- Reserved	
	(Continued on next page)	

Table 3-2: Modem Status Command Details (Continued)

Command	Description			
+WUSLMSK (continued)	Enable/disable unsolicited notifications (continued)			
	UPPER unsolicited notifications mask			
	<hr/> <i>Note: Notification support is firmware-dependent. Some of these notifications may not be supported or applicable.</i> <hr/>			
	Bit	Mask value	Unsolic. Notif.	Responsible for:
	0	0x00000001	---	Reserved
	1	0x00000002	IPC VOLT	PMIC voltage state change
	2	0x00000004	IPC TEMP	PMIC temperature state change
	3	0x00000008	IPATEMP	PA Temperature state change
	4	0x00000010	+WJAM	Jamming event
	5	0x00000020	---	Reserved
	6	0x00000040	---	Reserved
	7	0x00000080	---	Reserved
	8	0x00000100	---	Reserved
	9	0x00000200	---	Reserved
	10	0x00000400	---	Reserved
	11	0x00000800	---	Reserved
	12	0x00001000	---	Reserved
	13	0x00002000	---	Reserved
	14	0x00004000	---	Reserved
	15	0x00008000	---	Reserved
	16	0x00010000	---	Reserved
	17	0x00020000	---	Reserved
	18	0x00040000	---	Reserved
	19	0x00080000	---	Reserved
	20	0x00100000	---	Reserved
	21	0x00200000	---	Reserved
	22	0x00400000	---	Reserved
	23	0x00800000	---	Reserved
	24	0x01000000	---	Reserved
	25	0x02000000	---	Reserved
	26	0x04000000	---	Reserved
	27	0x08000000	---	Reserved
28	0x10000000	---	Reserved	
29	0x20000000	---	Reserved	
30	0x40000000	---	Reserved	
31	0x80000000	---	Reserved	

>> 4: SIM Toolkit Commands

Introduction

This chapter describes commands and notifications used to enable the AT Interface's SIM toolkit support, and receive and respond to unsolicited SIM command notifications.

Note: SIM toolkit commands are available only if the feature is enabled via AT!CUSTOM="STKUIEN",2).

Command summary

Table 4-1 lists the commands described in this chapter.

Table 4-1: SIM Toolkit Commands

Command	Description	Page
*PSSTKI	Configure AT interface's SIM toolkit support	116
!STKC	Report last unsolicited proactive SIM command notification	117
!STKC (notification)	Unsolicited proactive SIM command notification	118
!STKCR	Respond to proactive SIM command	119
!STKGC	Get (retrieve) data for last unsolicited proactive SIM command notification	124
!STKMS	Inform SIM of menu item selection or provide help information	136
!STKN (notification)	Response to mobile-originated Call or SMS control request (notification)	137
!STKPD	Select host-supported STK features	139

Command reference

Table 4-2: SIM Toolkit Command Details

Command	Description
*PSSTKI	<p>Configure AT interface's SIM toolkit support</p> <p>Configure the AT interface's support (interaction method with terminal equipment (TE)) for SIM Toolkit.</p> <p>Password required: No Reset required to apply changes: No Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT*PSSTKI=<mode> Response: OK Purpose: Configure the AT interface's STK support to the specified <mode>. • Query: AT*PSSTKI? Response: *PSSTKI: <mode> OK Purpose: Display the AT interface's current <mode> for STK support. • Query List: AT*PSSTKI=? Purpose: Return the execution command format. See the parameter descriptions below for details. <p>Parameters:</p> <p><mode> (AT interface's STK support mode)</p> <ul style="list-style-type: none"> • 0—STK not supported. Module does not send unsolicited result codes to TE, and TE does not send STK AT command to module. • 1—Manual mode. Module sends URCs to TE, and TE must acknowledge proactive command notification to continue • 2—Auto-acknowledge mode. Module responds to STK without TE. Any URCs are sent to TE. • 3 (Default)—Auto-acknowledge mode. Module responds without sending URC to the TE. • NOTE: Modes 2 and 3 are used only for the following STK proactive commands that require user interaction: <ul style="list-style-type: none"> • Commands that require Yes/No responses: <ul style="list-style-type: none"> • SEND SMS • SEND SS • SEND USSD • SEND DTMF • SET UP CALL • SET UP MENU • Commands that require MMI (man-machine interaction) and Yes/No responses when complete: <ul style="list-style-type: none"> • SET UP IDLE MODE TEXT • DISPLAY TEXT • For BIP (Bearer Independent Protocol) feature: <ul style="list-style-type: none"> • OPEN CHANNEL

Table 4-2: SIM Toolkit Command Details (Continued)

Command	Description
!STKC	<p>Report last unsolicited proactive SIM command notification</p> <p>Display the most recent unsolicited proactive SIM command notification (!STKC (notification) on page 118).</p> <p>All notifications (except where <cmdId> is "01" or "81") require a response to be sent using AT!STKCR on page 119.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Query: AT!STKC? Response: [Outstanding Proactive Command: <cmdId>] OK Purpose: Display the most recent unsolicited !STKC notification. If none, return only "OK". <p>Parameters:</p> <p><cmdId> (Unique ID of proactive SIM command)</p> <ul style="list-style-type: none"> • Note: This is the full set of supported <cmdID> types. • Hexadecimal ID as ASCII string (without quotation marks): <ul style="list-style-type: none"> • "01"—Refresh • "05"—Set Up Event List • "10"—Set Up Call • "11"—Send SS • "12"—Send USSD • "13"—Send SMS • "14"—Send DTMF • "15"—Launch Browser • "20"—Play Tone • "21"—Display Text • "22"—Get Inkey • "23"—Get Input • "24"—Select Item • "25"—Set Up Menu • "28"—Set Up Idle Mode Text • "35"—Language Notification • "40"—Open Channel • "81"—End of proactive session

Table 4-2: SIM Toolkit Command Details (Continued)

Command	Description
!STKC (notification)	<p>Unsolicited proactive SIM command notification</p> <p>Unsolicited notification indicating a proactive SIM command has been received.</p> <p>All notifications (except where <cmdId> is "01" or "81") require a response to be sent using AT!STKCR on page 119.</p> <p>Notification format:</p> <p>+STKC: <cmdId></p> <p>Parameters:</p> <p><cmdId> (Unique ID of proactive SIM command)</p> <ul style="list-style-type: none"> • Note: This is the full set of supported <cmdID> types. • Hexadecimal ID as ASCII string (without quotation marks): <ul style="list-style-type: none"> • "01"—Refresh • "05"—Set Up Event List • "10"—Set Up Call • "11"—Send SS • "12"—Send USSD • "13"—Send SMS • "14"—Send DTMF • "15"—Launch Browser • "20"—Play Tone • "21"—Display Text • "22"—Get Inkey • "23"—Get Input • "24"—Select Item • "25"—Set Up Menu • "28"—Set Up Idle Mode Text • "35"—Language Notification • "40"—Open Channel • "81"—End of proactive session

Table 4-2: SIM Toolkit Command Details (Continued)

Command	Description
!STKCR	<p>Respond to proactive SIM command</p> <p>Respond to the last unsolicited proactive SIM command. This command must be issued before the next unsolicited command is received, otherwise an error will be returned.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: ATISTKCR=<cmdId>,<result>[,<data>] Response: OK <i>or</i> ERROR • Purpose: Respond to the last received unsolicited proactive SIM command. If the <cmdId> is different than the last received command, ERROR is returned. • Query List: ATISTKCR=? Purpose: Return the execution command format. See the parameter descriptions below for details. <p>Parameters:</p> <p><cmdId> (Unique ID of proactive SIM command being responded to)</p> <ul style="list-style-type: none"> • Note: !STKCR is not used to respond to the following <cmdID> values: '81'. • Hexadecimal ID as ASCII string (without quotation marks): <ul style="list-style-type: none"> • "05"—Set Up Event List (Note: This triggers the event identified in the response and sends the corresponding ENVELOPE command to the UICC. Once the envelope is sent successfully, the event is removed from the event list, per 3GPP TS 31.111.) • "10"—Set Up Call • "11"—Send SS • "12"—Send USSD • "13"—Send SMS • "14"—Send DTMF • "15"—Launch Browser • "20"—Play Tone • "21"—Display Text • "22"—Get Inkey • "23"—Get Input • "24"—Select Item • "25"—Set Up Menu • "28"—Set Up Idle Mode Text • "35"—Language Notification • "40"—Open Channel <p>(Continued on next page)</p>

Table 4-2: SIM Toolkit Command Details (Continued)

Command	Description
!STKCR (continued)	<p>Respond to proactive SIM command (continued)</p> <p><result>[,<data>] (Response being sent for the specified <cmdId>)</p> <ul style="list-style-type: none"> • Note: The <data> portion of the response format is unique for each <cmdID>. For example, <cmdId = "05"> returns <event> as the <data> portion, and <cmdID = "22"> returns <DCS>,<text> as the <data> portion. • The response format depends on the <cmdId> type: <ul style="list-style-type: none"> • If <cmdId>="05" (Set Up Event List), then response format is: <p><result>,<event></p> <ul style="list-style-type: none"> • <result> (Command result being returned) <ul style="list-style-type: none"> • 0—No meaning, 0 always returned as <result> value • <event> (Supported Events list) <ul style="list-style-type: none"> • 4—User activity • 5—Idle Screen available • Note: This is to trigger the <event> and send the corresponding ENVELOPE command to the UICC. Once the envelope is sent successfully, the event will be removed from the event list (per 3GPP TS 31.111). • If <cmdId>="10" (Set Up Call), then response format is: <p><result></p> <ul style="list-style-type: none"> • <result> (Command result being returned) <ul style="list-style-type: none"> • 0—Command performed successfully • 1—Command beyond ME's capabilities • 2—Currently busy on call • 3—Currently busy with SS transaction • 4—Terminated by user • 5—SS returned Result Error Code • 6—Network currently unable to process command • 7—Call setup not accepted • 8—User cleared down call before connection or network release • 9—Command performed successfully, but requested icon could not be displayed • If <cmdId>="11" (Send SS), then response format is: <p><result></p> <ul style="list-style-type: none"> • <result> (Command result being returned) <ul style="list-style-type: none"> • 0—Command performed successfully • 1—Command beyond ME's capabilities • 2—Currently busy with USSD transaction • 3—Currently busy with SS transaction • 4—Terminated by user • 5—SS returned Result Error Code • 6—Network currently unable to process command • 7—Command performed successfully, but requested icon could not be displayed <p>(Continued on next page)</p>

Table 4-2: SIM Toolkit Command Details (Continued)

Command	Description
!STKCR (continued)	<p>Respond to proactive SIM command (continued)</p> <ul style="list-style-type: none"> • If <cmdId>="12" (Send USSD), then response format is: <result> <ul style="list-style-type: none"> • <result> (Command result being returned) <ul style="list-style-type: none"> • 0—Command performed successfully • 1—Command beyond ME's capabilities • 2—Currently busy with USSD transaction • 3—Currently busy with SS transaction • 4—Terminated by user • 5—USSD returned Result Error Code • 6—Network currently unable to process command • 7—Command performed successfully, but requested icon could not be displayed • If <cmdId>="13" (Send Short Message), then response format is: <result> <ul style="list-style-type: none"> • <result> (Command result being returned) <ul style="list-style-type: none"> • 0—Command performed successfully • 1—Command beyond ME's capabilities • 2—SMS RP error • If <cmdId>="14" (Send DTMF), then response format is: <result> <ul style="list-style-type: none"> • <result> (Command result being returned) <ul style="list-style-type: none"> • 0—Command performed successfully • 1—Command beyond ME's capabilities • 2—Not in speech call • 3—Terminate proactive session • 4—Command performed successfully, but requested icon could not be displayed • If <cmdId>="15" (Launch Browser), then response format is: <result> <ul style="list-style-type: none"> • <result> (Command result being returned) <ul style="list-style-type: none"> • 0—Command performed successfully • 1—Command performed – partial completion • 2—Command performed – missing information • 3—Error – no specific cause given • 4—Bearer unavailable • 5—Browser unavailable • 6—ME cannot process command • 7—Network cannot process command • 8—Command beyond ME's capabilities • If <cmdId>="20" (Play Tone), then response format is: <result> <ul style="list-style-type: none"> • <result> (Command result being returned) <ul style="list-style-type: none"> • 0—Command performed successfully • 1—Terminate proactive session • 2—Specified tone not supported <p>(Continued on next page)</p>

Table 4-2: SIM Toolkit Command Details (Continued)

Command	Description
!STKCR (continued)	<p>Respond to proactive SIM command (continued)</p> <ul style="list-style-type: none"> • If <cmdId>="21" (Display Text), then response format is: <result> <ul style="list-style-type: none"> • <result> (Command result being returned) <ul style="list-style-type: none"> • 0—Message displayed OK • 1—Terminate proactive session • 2—Screen is busy • 3—Backward move requested • 4—No response from user • If <cmdId>="22" (Get Inkey), then response format is: <result>[,<DCS>,<text>] <ul style="list-style-type: none"> • <result> (Command result being returned) <ul style="list-style-type: none"> • 0—Data entered OK • 1—Terminate proactive session • 2—Help information requested • 3—Backward move requested • 4—No response from user • Note: <DCS> and <text> are sent only for <result>=0 (The SIM expects input to be in a Text String Data Object in the Terminal Response SIM command when data has been input.) • <DCS> (Data coding scheme for <text>) <ul style="list-style-type: none"> • 0—7-bit GSM default alphabet (packed) • 4—8-bit GSM default alphabet (unpacked) • 8—UCS2 alphabet • <text> (Text string, in <DCS> format) <ul style="list-style-type: none"> • Hex string • For Yes/No responses, use the following hex strings: <ul style="list-style-type: none"> 00—Negative response entered 01—Positive response entered • If <cmdId>="23" (Get Input), then response format is: <result>[,<DCS>,<text>] <ul style="list-style-type: none"> • <result> (Command result being returned) <ul style="list-style-type: none"> • 0—Data entered OK • 1—Terminate proactive session • 2—Help information requested • 3—Backward move requested • 4—No response from user • Note: <DCS> and <text> are sent only for <result>=0 (The SIM expects input to be in a Text String Data Object in the Terminal Response SIM command when data has been input.) • <DCS> (Data coding scheme for <text>) <ul style="list-style-type: none"> • 0—7-bit GSM default alphabet (packed) • 4—8-bit GSM default alphabet (unpacked) • 8—UCS2 alphabet • <text> (Text string, in <DCS> format) <ul style="list-style-type: none"> • Hex string • If the string is empty (e.g. the user makes an 'empty' input), either leave the parameter blank or send a null test string (""). <p>(Continued on next page)</p>

Table 4-2: SIM Toolkit Command Details (Continued)

Command	Description
!STKCR (continued)	<p>Respond to proactive SIM command (continued)</p> <ul style="list-style-type: none"> • If <cmdId>="24" (Select Item), then response format is: <result>[,<itemId>] • <result> (Command result being returned) <ul style="list-style-type: none"> • 0—Item selected OK • 1—Terminate proactive session • 2—Help information requested • 3—Backward move requested • 4—No response from user • <itemId> (Identifier of menu item selected) <ul style="list-style-type: none"> • Integer value • Applies to <result> types 0 and 2 • If <cmdId>="25" (Set Up Menu), then response format is: <result> <ul style="list-style-type: none"> • <result> (Command result being returned) <ul style="list-style-type: none"> • 0—Menu successfully added/removed • 1—Problem with menu operation • If <cmdId>="28" (Set Up Idle Mode Text), then response format is: <result> <ul style="list-style-type: none"> • <result> (Command result being returned) <ul style="list-style-type: none"> • 0—Text successfully added/removed • 1—Problem performing command • If <cmdId>="35" (Language Notification), then response format is: <result> <ul style="list-style-type: none"> • <result> (Command result being returned) <ul style="list-style-type: none"> • 0—Command performed successfully • If <cmdId>="40" (Open Channel), then response format is: <result> <ul style="list-style-type: none"> • <result> (Command result being returned) <ul style="list-style-type: none"> • 0—Command performed successfully • 1—User did not accept the proactive command

Table 4-2: SIM Toolkit Command Details (Continued)

Command	Description
!STKGC	<p>Get (retrieve) data for last unsolicited proactive SIM command notification</p> <p>Get the data associated with the most recent unsolicited proactive SIM command. This command must be issued before the next unsolicited command is received, otherwise the data will not be accessible.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!STKGC=<cmdId> Response: !STKGC: <cmdId>[,<data>] OK <li style="text-align: center;"><i>or</i> • Purpose: Get the data associated with the last received unsolicited proactive SIM command. If the <cmdId> is different than the last received command, ERROR is returned. • Query List: AT!STKGC=? Purpose: Return the execution command format. See the parameter descriptions below for details. <p>Parameters:</p> <p><cmdId> (Unique ID of proactive SIM command for which data is to be retrieved)</p> <ul style="list-style-type: none"> • Note: !STKGC is not used to respond to the following <cmdID> values: '01', '81'. • Hexadecimal ID as ASCII string (without quotation marks): <ul style="list-style-type: none"> • "05"—Set Up List • "10"—Set Up Call • "11"—Send SS • "12"—Send USSD • "13"—Send SMS • "14"—Send DTMF • "15"—Launch Browser • "20"—Play Tone • "21"—Display Text • "22"—Get Inkey • "23"—Get Input • "24"—Select Item • "25"—Set Up Menu • "28"—Set Up Idle Mode Text • "35"—Language Notification • "40"—Open Channel <p>(Continued on next page)</p>

Table 4-2: SIM Toolkit Command Details (Continued)

Command	Description
!STKGC (continued)	<p>Get (retrieve) data for last unsolicited proactive SIM command notification (continued)</p> <p><data> (Data retrieved for the specified <cmdId>)</p> <ul style="list-style-type: none"> • The format of the received <data> depends on the <cmdId> type: <ul style="list-style-type: none"> • If <cmdId>="05" (Set Up Event List), then <data> format is a string containing all supported event types: <event><event> <ul style="list-style-type: none"> • <event> (Event types, to be monitored by the host) <ul style="list-style-type: none"> • 04—User activity • 05—Idle screen available • If <cmdId>="10" (Set Up Call), then <data> format is: <method>, <TON>, <NPI>, <address>, <subaddress>, <ccp>, <DCS1>, <alphaId1>, <iconId1>, <dispMode1>, <DCS2>, <alphaId2>, <iconId2>, <dispMode2>, <redial>, <timeout> <ul style="list-style-type: none"> • <method> (Call setup method) <ul style="list-style-type: none"> • 0—Only if there are no other calls • 1—Put all other calls on hold • 2—Disconnect all other calls • <TON> (Type of number) <ul style="list-style-type: none"> • 0—Unknown • 1—International • 2—National • 3—Network-specific • <NPI> (Numbering Plan Identifier) <ul style="list-style-type: none"> • 0—Unknown • 1—ISDN Telephony • 3—Data • 4—Telex • 9—Private • <address> (Dialing address) <ul style="list-style-type: none"> • Hex string • <subaddress> (Dialing sub-address) <ul style="list-style-type: none"> • Hex string • <ccp> (Capability configuration parameters) <ul style="list-style-type: none"> • Hex string • <DCS1> (Data coding scheme for <alphaId1>) <ul style="list-style-type: none"> • 0—7-bit GSM default alphabet (packed) • 4—8-bit GSM default alphabet (unpacked) • 8—UCS2 alphabet • <alphaId1> (Alpha identifier for user confirmation) <ul style="list-style-type: none"> • Hex string • <iconId1> (Numeric tag (index) of icon image file on SIM to be displayed) <ul style="list-style-type: none"> • 0—No icon • 1–255—Icon tag <p>(Continued on next page)</p>

Table 4-2: SIM Toolkit Command Details (Continued)

Command	Description
!STKGC (continued)	<p>Get (retrieve) data for last unsolicited proactive SIM command notification (continued)</p> <ul style="list-style-type: none"> • <dispMode1> (Icon image usage) <ul style="list-style-type: none"> • 0—Display icon only (replaces <alphaId1>) • 1—Display with <alphaId1> • <DCS2> (Data coding scheme for <alphaId2>) <ul style="list-style-type: none"> • 0—7-bit GSM default alphabet (packed) • 4—8-bit GSM default alphabet (unpacked) • 8—UCS2 alphabet • <alphaId2> (Alpha identifier for call setup display) <ul style="list-style-type: none"> • Hex string • <iconId2> (Numeric tag (index) of icon image file on SIM to be displayed) <ul style="list-style-type: none"> • 0—No icon • 1–255—Icon tag • <dispMode2> (Icon image usage) <ul style="list-style-type: none"> • 0—Display icon only (replaces <alphaId2>) • 1—Display with <alphaId2> • <redial> (Redial flag) <ul style="list-style-type: none"> • 0—Redial not required • 1—Redial required • <timeout> (Timeout period, in ms) <ul style="list-style-type: none"> • Integer • 0—No timeout • 100–15300000—Timeout ranging from 0.1 second to 255 minutes • If <cmdId>="11" (Send SS), then <data> format is: <ul style="list-style-type: none"> • <TON>, <NPI>, <address>, <DCS>, <alphaId>, <iconId>, <dispMode> • <TON> (Type of number) <ul style="list-style-type: none"> • 0—Unknown • 1—International • 2—National • 3—Network-specific • <NPI> (Numbering Plan Identifier) <ul style="list-style-type: none"> • 0—Unknown • 1—ISDN Telephony • 3—Data • 4—Telex • 9—Private • <address> (Dialing address) <ul style="list-style-type: none"> • Hex string • <DCS> (Data coding scheme for <alphaId>) <ul style="list-style-type: none"> • 0—7-bit GSM default alphabet (packed) • 4—8-bit GSM default alphabet (unpacked) • 8—UCS2 alphabet • <alphaId> (Alpha identifier for user confirmation) <ul style="list-style-type: none"> • Hex string • <iconId> (Numeric tag (index) of icon image file on SIM to be displayed) <ul style="list-style-type: none"> • 0—No icon • 1–255—Icon tag <p>(Continued on next page)</p>

Table 4-2: SIM Toolkit Command Details (Continued)

Command	Description
!STKGC (continued)	<p>Get (retrieve) data for last unsolicited proactive SIM command notification (continued)</p> <ul style="list-style-type: none"> • <dispMode> (Icon image usage) <ul style="list-style-type: none"> • 0—Display icon only (replaces <alphald>) • 1—Display with <alphald> • If <cmdId>="12" (Send USSD), then <data> format is: <DCS1>, <ussd>, <DCS2>, <alphald>, <iconId>, <dispMode> <ul style="list-style-type: none"> • <DCS1> (Data coding scheme for <ussd>) <ul style="list-style-type: none"> • 0—7-bit GSM default alphabet (packed) • 4—8-bit GSM default alphabet (unpacked) • 8—UCS2 alphabet • <ussd> (USSD string) <ul style="list-style-type: none"> • Hex string • <DCS2> (Data coding scheme for <alphald>) <ul style="list-style-type: none"> • 0—7-bit GSM default alphabet (packed) • 4—8-bit GSM default alphabet (unpacked) • 8—UCS2 alphabet • <alphald> (Alpha identifier for user confirmation) <ul style="list-style-type: none"> • Hex string • <iconId> (Numeric tag (index) of icon image file on SIM to be displayed) <ul style="list-style-type: none"> • 0—No icon • 1–255—Icon tag • <dispMode> (Icon image usage) <ul style="list-style-type: none"> • 0—Display icon only (replaces <alphald>) • 1—Display with <alphald> • If <cmdId>="13" (Send Short Message), then <data> format is: <pack>, <tpdu>, <TON>, <NPI>, <address>, <DCS>, <alphald>, <iconId>, <dispMode> <ul style="list-style-type: none"> • <pack> (Packing flag) <ul style="list-style-type: none"> • 0—Packing not required • 1—Packing required • <tpdu> (TPDU string) <ul style="list-style-type: none"> • Hex string • <TON> (Type of number) <ul style="list-style-type: none"> • 0—Unknown • 1—International • 2—National • 3—Network-specific • <NPI> (Numbering Plan Identifier) <ul style="list-style-type: none"> • 0—Unknown • 1—ISDN Telephony • 3—Data • 4—Telex • 9—Private • <address> (Destination address) <ul style="list-style-type: none"> • Hex string <p>(Continued on next page)</p>

Table 4-2: SIM Toolkit Command Details (Continued)

Command	Description
!STKGC (continued)	<p>Get (retrieve) data for last unsolicited proactive SIM command notification (continued)</p> <ul style="list-style-type: none"> • <DCS> (Data coding scheme for <alphaId>) <ul style="list-style-type: none"> • 0—7-bit GSM default alphabet (packed) • 4—8-bit GSM default alphabet (unpacked) • 8—UCS2 alphabet • <alphaId> (Alpha identifier for user confirmation) <ul style="list-style-type: none"> • Hex string • <iconId> (Numeric tag (index) of icon image file on SIM to be displayed) <ul style="list-style-type: none"> • 0—No icon • 1–255—Icon tag • <dispMode> (Icon image usage) <ul style="list-style-type: none"> • 0—Display icon only (replaces <alphaId>) • 1—Display with <alphaId> • If <cmdId>="14" (Send DTMF), then <data> format is: <dtmf>, <DCS>, <alphaId>, <iconId>, <dispMode> <ul style="list-style-type: none"> • <dtmf> (DTMF string) <ul style="list-style-type: none"> • Hex string • <DCS> (Data coding scheme for <alphaId>) <ul style="list-style-type: none"> • 0—7-bit GSM default alphabet (packed) • 4—8-bit GSM default alphabet (unpacked) • 8—UCS2 alphabet • <alphaId> (Alpha identifier for user confirmation) <ul style="list-style-type: none"> • Hex string • <iconId> (Numeric tag (index) of icon image file on SIM to be displayed) <ul style="list-style-type: none"> • 0—No icon • 1–255—Icon tag • <dispMode> (Icon image usage) <ul style="list-style-type: none"> • 0—Display icon only (replaces <alphaId>) • 1—Display with <alphaId> • If <cmdId>="15" (Launch Browser), then <data> format is: <comQual>, <url>, <browserId>, <bearer>, <DCS1>, <gateway>, <DCS2>, <alphaId>, <iconId>, <dispMode>, <numFiles>[, <provFiles>, [...]] <ul style="list-style-type: none"> • <comQual> (Command qualifier) <ul style="list-style-type: none"> • 0—Launch browser if not already launched • 2—Use existing browser • 3—Close existing browser and launch new browser • <url> (URL to connect to in browser) <ul style="list-style-type: none"> • Format: 8-bit data using GSM default 7-bit alphabet • Special case: If <url>="" (Null string), use the default URL. • <browserId> (Browser ID to use) <ul style="list-style-type: none"> • "00"—Use default browser <p>(Continued on next page)</p>

Table 4-2: SIM Toolkit Command Details (Continued)

Command	Description
!STKGC (continued)	<p>Get (retrieve) data for last unsolicited proactive SIM command notification (continued)</p> <ul style="list-style-type: none"> • <bearer> (Allowed bearers) <ul style="list-style-type: none"> • List of allowed bearers in priority order • "00"—SMS • "01"—CSD • "02"—USSD • "03"—GPRS • Example: 01030200 (CSD, GPRS, USSD, SMS) • <DCS1> (Data coding scheme for <gateway>) <ul style="list-style-type: none"> • 0—7-bit GSM default alphabet (packed) • 4—8-bit GSM default alphabet (unpacked) • 8—UCS2 alphabet • <gateway> (Gateway address) <ul style="list-style-type: none"> • Hex string • <DCS2> (Data coding scheme for <alphaId>) <ul style="list-style-type: none"> • 0—7-bit GSM default alphabet (packed) • 4—8-bit GSM default alphabet (unpacked) • 8—UCS2 alphabet • <alphaId> (Alpha identifier for user confirmation) <ul style="list-style-type: none"> • Hex string • <iconId> (Numeric tag (index) of icon image file on SIM to be displayed) <ul style="list-style-type: none"> • 0—No icon • 1–255—Icon tag • <dispMode> (Icon image usage) <ul style="list-style-type: none"> • 0—Display icon only (replaces <alphaId>) • 1—Display with <alphaId> • <numFiles> (Number of <provFiles> following this parameter) <ul style="list-style-type: none"> • Integer • <provFile> (Provisioning File reference) <ul style="list-style-type: none"> • 0 or more provisioning file pathnames, separated by commas • Full pathnames are provided • If <cmdId>="20" (Play Tone), then <data> format is: <DCS>, <alphaId>, <tone>, <duration> <ul style="list-style-type: none"> • <DCS> (Data coding scheme for <alphaId>) <ul style="list-style-type: none"> • 0—7-bit GSM default alphabet (packed) • 4—8-bit GSM default alphabet (unpacked) • 8—UCS2 alphabet • <alphaId> (Alpha identifier for user confirmation) <ul style="list-style-type: none"> • Hex string <p>(Continued on next page)</p>

Table 4-2: SIM Toolkit Command Details (Continued)

Command	Description
!STKGC (continued)	<p>Get (retrieve) data for last unsolicited proactive SIM command notification (continued)</p> <ul style="list-style-type: none"> • <tone> (Requested SST (Standard Supervisory Tone) or MPT (ME Proprietary Tone) type) <ul style="list-style-type: none"> • Hex value • 01—Dial (SST) • 02—Called subscriber busy (SST) • 03—Congestion (SST) • 04—Radio path acknowledge (SST) • 05—Radio path not available/Call dropped (SST) • 06—Error/Special information (SST) • 07—Call waiting (SST) • 08—Ringing tone (SST) • 10—General beep (MPT) • 11—Positive ack (MPT) • 12—Negative ack or Error (MPT) • If no tone is specified, default to General beep. • <duration> (Tone duration, in ms) <ul style="list-style-type: none"> • Integer • 0—Use the ME default value • 100–15300000—Duration ranging from 0.1 second to 255 minutes • If <cmdId>="21" (Display Text), then <data> format is: <ul style="list-style-type: none"> • <DCS>, <text>, <priority>, <clear>, <iconId>, <dispMode>, <response> <ul style="list-style-type: none"> • <DCS> (Data coding scheme for <text>) <ul style="list-style-type: none"> • 0—7-bit GSM default alphabet (packed) • 4—8-bit GSM default alphabet (unpacked) • 8—UCS2 alphabet • <text> (Text string in <DCS> format) <ul style="list-style-type: none"> • Hex string • <priority> (Display priority information) <ul style="list-style-type: none"> • 0—Do not display information • 1—Display information • <clear> (Allow message to be cleared) <ul style="list-style-type: none"> • 0—Clear message automatically after a delay • 1—Allow user to clear message • <iconId> (Numeric tag (index) of icon image file on SIM to be displayed) <ul style="list-style-type: none"> • 0—No icon • 1–255—Icon tag • <dispMode> (Icon image usage) <ul style="list-style-type: none"> • 0—Display icon only (replaces <text>) • 1—Display with <text> • <response> (Response requirement) <ul style="list-style-type: none"> • 0—Normal response expected • 1—Immediate response expected <p>(Continued on next page)</p>

Table 4-2: SIM Toolkit Command Details (Continued)

Command	Description
!STKGC (continued)	<p>Get (retrieve) data for last unsolicited proactive SIM command notification (continued)</p> <ul style="list-style-type: none"> • If <cmdId>="22" (Get Inkey), then <data> format is: <DCS>, <text>, <response>, <helpInfo>, <iconId>, <dispMode> • <DCS> (Data coding scheme for <text>) <ul style="list-style-type: none"> • 0—7-bit GSM default alphabet (packed) • 4—8-bit GSM default alphabet (unpacked) • 8—UCS2 alphabet • <text> (Text string in <DCS> format) <ul style="list-style-type: none"> • Hex string • <response> (Expected response character format) <ul style="list-style-type: none"> • 0—SMS default alphabet • 1—Yes/No response only • 2—Digits (0–9, *, #, +) only • 3—UCS2 alphabet • <helpInfo> (Help information availability) <ul style="list-style-type: none"> • 0—Not available • 1—Available • <iconId> (Numeric tag (index) of icon image file on SIM to be displayed) <ul style="list-style-type: none"> • 0—No icon • 1–255—Icon tag • <dispMode> (Icon image usage) <ul style="list-style-type: none"> • 0—Display icon only (replaces <text>) • 1—Display with <text> • If <cmdId>="23" (Get Input), then <data> format is: <DCS1>, <text>, <response>, <echo>, <helpInfo>, <minLgth>, <maxLgth>, <DCS2>, <default>, <iconId>, <dispMode> • <DCS1> (Data coding scheme for <text>) <ul style="list-style-type: none"> • 0—7-bit GSM default alphabet (packed) • 4—8-bit GSM default alphabet (unpacked) • 8—UCS2 alphabet • <text> (Text string in <DCS1> format) <ul style="list-style-type: none"> • Hex string • <response> (Expected response character format) <ul style="list-style-type: none"> • 0—SMS default alphabet • 1—Yes/No response only • 2—Digits (0–9, *, #, +) only • 3—UCS2 alphabet • <echo> (Echo input availability) <ul style="list-style-type: none"> • 0—Echo not allowed. Actual string entered by user cannot be displayed, but can be 'masked' to indicate key entry using characters from the set (0–9, *, #, +). • 1—Echo input to display • <helpInfo> (Help information availability) <ul style="list-style-type: none"> • 0—Not available • 1—Available • <minLgth> (Minimum length of expected response) <ul style="list-style-type: none"> • 0–255 <p>(Continued on next page)</p>

Table 4-2: SIM Toolkit Command Details (Continued)

Command	Description
!STKGC (continued)	<p>Get (retrieve) data for last unsolicited proactive SIM command notification (continued)</p> <ul style="list-style-type: none"> • <maxLgth> (Maximum length of expected response) <ul style="list-style-type: none"> • 0–254 • 255—No maximum length (can be ≥ 255 bytes) • <DCS2> (Data coding scheme for <default>) <ul style="list-style-type: none"> • 0—7-bit GSM default alphabet (packed) • 4—8-bit GSM default alphabet (unpacked) • 8—UCS2 alphabet • <default> (Text string in <DCS2> format) <ul style="list-style-type: none"> • Hex string • If string is provided, ME will display this text for the user to accept, reject, or edit as appropriate. • <iconId> (Numeric tag (index) of icon image file on SIM to be displayed) <ul style="list-style-type: none"> • 0—No icon • 1–255—Icon tag • <dispMode> (Icon image usage) <ul style="list-style-type: none"> • 0—Display icon only (replaces any text string or <alphald>) • 1—Display with <alphald> or text string • If <cmdId>="24" (Select Item), then <data> format is: <numItems>, <selection>, <default>, <helpInfo>, <DCS>, <alphald>, <iconId>, <dispMode> <CR><LF> [<itemId>, <itemText>, <iconId>, <dispMode>, <nai>] <CR><LF> [...] <ul style="list-style-type: none"> • <numItems> (Number of items that are accessible in the menu structure) <ul style="list-style-type: none"> • 0—Remove existing menu from the ME's menu structure • 1–255—Number of items in menu structure • <selection> (Preferred user selection method) <ul style="list-style-type: none"> • 0—No selection preference • 1—Soft key selection preferred • <default> (Default selection item) <ul style="list-style-type: none"> • Integer value corresponding to one of the <itemId>s in the menu • <helpInfo> (Help information availability) <ul style="list-style-type: none"> • 0—Not available • 1—Available • <DCS> (Data coding scheme for <alphald>) <ul style="list-style-type: none"> • 0—7-bit GSM default alphabet (packed) • 4—8-bit GSM default alphabet (unpacked) • 8—UCS2 alphabet • <alphald> (Alpha identifier for user confirmation, in <DCS> format) <ul style="list-style-type: none"> • Hex string • <iconId> (Numeric tag (index) of icon image file on SIM to be displayed) <ul style="list-style-type: none"> • 0—No icon • 1–255—Icon tag • <dispMode> (Icon image usage) <ul style="list-style-type: none"> • 0—Display icon only (replaces any text string or <alphald>) • 1—Display with <alphald> or text string <p>(Continued on next page)</p>

Table 4-2: SIM Toolkit Command Details (Continued)

Command	Description
!STKGC (continued)	<p>Get (retrieve) data for last unsolicited proactive SIM command notification (continued)</p> <ul style="list-style-type: none"> • <itemId> (Menu item identifier) <ul style="list-style-type: none"> • Integer value • <itemText> (Menu item text) <ul style="list-style-type: none"> • Hex string • <nai> (Next Action Indicator) <ul style="list-style-type: none"> • Action that SIM can initiate if selected by the user. For a list of available values, refer to TS 31.111 Section 9.4 and TS 102 223 Section 9.4. • Hex value • Example: 13 (Send Short Message) • If <cmdId>="25" (Set Up Menu), then <data> format is: <numItems>, <selection>, <helpInfo>, <DCS>, <alphaId>, <iconId>, <dispMode>[, <itemId>, <itemText>, <iconId>, <dispMode>, <nai>] [<itemId>, <itemText>, <iconId>, <dispMode>, <nai>] [...] • <numItems> (Number of items that are accessible in the menu structure) <ul style="list-style-type: none"> • 0—Remove existing menu from the ME's menu structure • 1–255—Number of items in menu structure • <selection> (Preferred user selection method) <ul style="list-style-type: none"> • 0—No selection preference • 1—Soft key selection preferred • <helpInfo> (Help information availability) <ul style="list-style-type: none"> • 0—Not available • 1—Available • <DCS> (Data coding scheme for <alphaId>) <ul style="list-style-type: none"> • 0—7-bit GSM default alphabet (packed) • 4—8-bit GSM default alphabet (unpacked) • 8—UCS2 alphabet • <alphaId> (Alpha identifier for user confirmation, in <DCS> format) <ul style="list-style-type: none"> • Hex string • <iconId> (Numeric tag (index) of icon image file on SIM to be displayed) <ul style="list-style-type: none"> • 0—No icon • 1–255—Icon tag • <dispMode> (Icon image usage) <ul style="list-style-type: none"> • 0—Display icon only (replaces any text string or <alphaId>) • 1—Display with <alphaId> or text string • <itemId> (Menu item identifier) <ul style="list-style-type: none"> • Integer value • <itemText> (Menu item text) <ul style="list-style-type: none"> • Hex string • <nai> (Next Action Indicator) <ul style="list-style-type: none"> • Action that SIM can initiate if selected by the user. For a list of available values, refer to TS 31.111 Section 9.4 and TS 102 223 Section 9.4. • Hex value • Example: 13 (Send Short Message) <p>(Continued on next page)</p>

Table 4-2: SIM Toolkit Command Details (Continued)

Command	Description
!STKGC (continued)	<p>Get (retrieve) data for last unsolicited proactive SIM command notification (continued)</p> <ul style="list-style-type: none"> • If <cmdId>="26" (Set Up Idle Mode Text), then <data> format is: <DCS>, <text>, <iconId>, <dispMode> • <DCS> (Data coding scheme for <text>) <ul style="list-style-type: none"> • 0—7-bit GSM default alphabet (packed) • 4—8-bit GSM default alphabet (unpacked) • 8—UCS2 alphabet • <text> (Idle Mode text string, in <DCS> format) <ul style="list-style-type: none"> • Hex string • <iconId> (Numeric tag (index) of icon image file on SIM to be displayed) <ul style="list-style-type: none"> • 0—No icon • 1–255—Icon tag • <dispMode> (Icon image usage) <ul style="list-style-type: none"> • 0—Display icon only (replaces any text string or <alphald>) • 1—Display with <alphald> or text string • If <cmdId>="35" (Language Notification), then <data> format is: <spec>, <lang> • <spec> (Language notification type) <ul style="list-style-type: none"> • 0—Non-specific language notification • 1—Specific language notification • <lang> (List of language codes) <ul style="list-style-type: none"> • Hex string • Example: 656E ("en"—English. Refer to ISO 639 for complete list of language codes.) • If <cmdId>="40" (Open Channel), then <data> format is: <onDemand>, <alphald>, <iconId>, <dispMode>, <bearerType>, <bearer>, <bufSize>, <apn>, <localAddrType>, <localAddr>, <login>, <pwd>, <transProtocol>, <portNum>, <destAddrType>, <destAddr> • <onDemand> (Link establishment method) <ul style="list-style-type: none"> • 0—On-demand link establishment • 1—Immediate link establishment • <alphald> (Alpha identifier for user confirmation) <ul style="list-style-type: none"> • Hex string, 7-bit GSM format or UCS2 • <iconId> (Numeric tag (index) of icon image file on SIM to be displayed) <ul style="list-style-type: none"> • 0—No icon • 1–255—Icon tag • <dispMode> (Icon image usage) <ul style="list-style-type: none"> • 0—Display icon only (replaces any text string or <alphald>) • 1—Display with <alphald> or text string • <bearerType> (Bearer type) <ul style="list-style-type: none"> • Integer value • 1—CSD • 3—GPRS • 4—Default bearer • All other values are reserved <p>(Continued on next page)</p>

Table 4-2: SIM Toolkit Command Details (Continued)

Command	Description
!STKGC (continued)	<p>Get (retrieve) data for last unsolicited proactive SIM command notification (continued)</p> <ul style="list-style-type: none"> • <bearer> (Encoded bearer description (QoS and packet data protocol type)) <ul style="list-style-type: none"> • Hex string (byte order: B1B2B3B4B5B6) • B1—Precedence class • B2—Delay class • B3—Reliability class • B4—Peak throughput • B5—Mean throughput • B6—Packet data protocol type • Example: 020405051602 (e.g. "04" is the Delay class (B2)) • <bufSize> (Buffer size requested) <ul style="list-style-type: none"> • Integer value • <apn> (Access point name) <ul style="list-style-type: none"> • Hex string • <localAddrType> (Local address type) <ul style="list-style-type: none"> • Integer value • 0—No address given • 1—Dynamic address • 2—IPv4 address • 3—IPv6 address • <localAddr> (Local address) <ul style="list-style-type: none"> • Hex string • <login> (User login name) <ul style="list-style-type: none"> • Hex string • <pwd> (User password) <ul style="list-style-type: none"> • Hex string • <transProtocol> (Transport protocol) <ul style="list-style-type: none"> • Integer value • 0—Not present • 1—UDP • 2—TCP • 3—TCP server • <portNum> (Port number) <ul style="list-style-type: none"> • Integer value • 0–65535 • <destAddrType> (Data destination address type) <ul style="list-style-type: none"> • Integer value • 0—No address given • 1—Dynamic address • 2—IPv4 address • 3—IPv6 address • <destAddr> (Data destination address) <ul style="list-style-type: none"> • Hex string

Table 4-2: SIM Toolkit Command Details (Continued)

Command	Description
!STKMS	<p>Inform SIM of menu item selection or provide help information</p> <p>Host uses this command to tell the SIM which menu item was selected, or to request that the SIM provide help information for a menu item.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: ATISTKMS=<item>[, <help>] Response: OK <i>or</i> ERROR <i>or</i> Error code: <error> • Purpose: Indicate to the SIM that menu <item> was selected, or that the SIM must provide help information for the menu <item>. • Query List: ATISTKMS=? Purpose: Return the execution command format. See the parameter descriptions below for details. <p>Parameters:</p> <p><item> (Menu item)</p> <ul style="list-style-type: none"> • Integer value <p><help> (Request help text or menu selection)</p> <ul style="list-style-type: none"> • 0 (Default)—Request SIM to select menu item • 1—Request SIM to provide help info to the host for the specified <item> by issuing a DISPLAY TEXT proactive SIM command. <p><error> (Error reason)</p> <ul style="list-style-type: none"> • 1—SIM card busy • 2—General failure

Table 4-2: SIM Toolkit Command Details (Continued)

Command	Description
!STKN (notification)	<p>Response to mobile-originated Call or SMS control request (notification)</p> <p>Unsolicited notification indicating the result of a mobile-originated call control or SMS control request.</p> <p>No host response is required to this notification.</p> <p>Notification format: +STKN: <cmdId>, <data></p> <p>Parameters:</p> <p><cmdId> (Notification type)</p> <ul style="list-style-type: none"> • Hexadecimal ID as ASCII string (without quotation marks): <ul style="list-style-type: none"> • "D4"—Response to mobile-originating Call Control request • "D5"—Response to mobile-originating SMS Control request <p><data> (Notification content)</p> <ul style="list-style-type: none"> • Content format depends on <cmdId> type: <ul style="list-style-type: none"> • If <cmdId>="D4", then <data> format depends on call type: <ul style="list-style-type: none"> For Voice: <result>, <repeatInd>, <alphaId>, 0, <TON>, <NPI>, <address>, <subaddress>, <ccp1>, <ccp2> For SS: <result>, <repeatInd>, <alphaId>, 1, <TON>, <NPI>, <address> For USSD: <result>, <repeatInd>, <alphaId>, 2, <dcS>, <ussd> For PDP context: <result>, <repeatInd>, <alphaId>, 3, <pdp> None: <result>, <repeatInd>, <alphaId>, 4 <ul style="list-style-type: none"> • <result> (Call control result) <ul style="list-style-type: none"> • 0—Allowed with no modifications • 1—Not allowed • 2—Allowed with modifications • <repeatInd> (BC repeat indicator) <ul style="list-style-type: none"> • 1—Alternate mode • 3—Sequential mode • <alphaId> (Alpha identifier) <ul style="list-style-type: none"> • Hex string • <TON> (Type of number) <ul style="list-style-type: none"> • 0—Unknown • 1—International • 2—National • 3—Network specific <p>(Continued on next page)</p>

Table 4-2: SIM Toolkit Command Details (Continued)

Command	Description
!STKN (notification) (continued)	<p>Response to mobile-originated Call or SMS control request (notification) (continued)</p> <ul style="list-style-type: none"> • <NPI> (Numbering Plan Identifier) <ul style="list-style-type: none"> • 0—Unknown • 1—ISDN Telephony • 3—Data • 4—Telex • 9—Private • <address> (New dialing address) <ul style="list-style-type: none"> • Hex string • <subaddress> (New dialing sub-address) <ul style="list-style-type: none"> • Hex string • <ccp1> (First capability configuration parameters) <ul style="list-style-type: none"> • Hex string • <ccp2> (Second capability configuration parameters) <ul style="list-style-type: none"> • Hex string • <dcs> (Data coding scheme) <ul style="list-style-type: none"> • 0—7-bit GSM default alphabet (packed) • 4—8-bit GSM default alphabet (unpaced) • 8—UCS2 alphabet • <ussd> (USSD control string) <ul style="list-style-type: none"> • Hex string • If <cmdId>="D5", then <data> format is: <result>, <alphaId>, <TON>, <NPI>, <rpaddress>, <TON>, <NPI>, <tpaddress> <result>, <repeatInd>, <alphaId>, 4 • <result> (SMS control result) <ul style="list-style-type: none"> • 0—Allowed with no modifications • 1—Not allowed • 2—Allowed with modifications • <alphaId> (Alpha identifier) <ul style="list-style-type: none"> • Hex string • <TON> (Type of number) <ul style="list-style-type: none"> • 0—Unknown • 1—International • 2—National • 3—Network specific • <NPI> (Numbering Plan Identifier) <ul style="list-style-type: none"> • 0—Unknown • 1—ISDN Telephony • 3—Data • 4—Telex • 9—Private • <rpaddress> (RP address) <ul style="list-style-type: none"> • Hex string

Table 4-2: SIM Toolkit Command Details (Continued)

Command	Description
!STKPD	<p>Select host-supported STK features</p> <p>Host uses this command to select the set of STK features the host will support and inform the SIM of the set. The module must be reset for the selected set of features to take effect.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!STKPD=<bitmask> Response: OK <i>or</i> ERROR • Purpose: Indicate to the SIM which STK features the host will support after the next reset. • Query: AT!STKPD? Response: Profile config=<bitmask> OK • Purpose: Report the current set of host-supported STK features by displaying the <bitmask>. Refer to the parameter description below to decode the settings. • Query List: AT!STKPD=? Purpose: Return the execution command format. See the parameter descriptions below for details. <p>Parameters:</p> <p><bitmask> (Host-supported STK features)</p> <ul style="list-style-type: none"> • 7-byte Hex string, big-endian format. Example: Byte order: 07060504030201; Bit order: 76543210 • Bit value 1=Supported; Bit value 0=Not supported • Note: Feature descriptions below include a code in brackets (e.g. "(B16b2)". This refers to the position of the bit in the terminal profile message according to 3GPP TS 11.14, using the following encoding: BX = Byte X bY = Bit Y • Byte 01: <ul style="list-style-type: none"> • Bit 0—Menu selection support (B1b4) • Bit 1—Support for alpha in call control (B2b5) • Bit 2—UCS2 entry support (B2b6) • Bit 3—UCS2 display support (B2b7) • Bit 4—Display Text command support (B3b1) • Bit 5—Get Inkey command support (B3b2) • Bit 6—Get Input command support (B3b3) • Bit 7—Play Tone command support (B3b5) <p>(Continued on next page)</p>

Table 4-2: SIM Toolkit Command Details (Continued)

Command	Description
!STKPD (continued)	<p>Select host-supported STK features (continued)</p> <ul style="list-style-type: none"> • Byte 02: <ul style="list-style-type: none"> • Bit 0—Select Item command support (B4b1) • Bit 1—Send SMS command support (B4b2) • Bit 2—Send SS command support (B4b3) • Bit 3—Send USSD command support (B4b4) • Bit 4—Set Up Call command support (B4b5) • Bit 5—Set Up Menu command support (B4b6) • Bit 6—Set Up Idle Mode Text command support (B8b5) • Bit 7—Second alpha in setup call support (B8b7) • Byte 03: <ul style="list-style-type: none"> • Bit 0—Second capability configuration parameter support (B8b8) • Bit 1—Sustained display text support (B9b1) • Bit 2—Send DTMF command support (B9b2) • Bit 3—Language notification command support (B9b6) • Bit 4—Launch Browser command support (B9b7) • Bit 5—Softkey support in select item command (B10b1) • Bit 6—Softkey support in setup menu command (B10b2) • Bit 7—Screen size support (B14b8) • Byte 04: <ul style="list-style-type: none"> • Bit 0—Variable font size support (B15b8) • Bit 1—Display resized support (B16b1) • Bit 2—Text wrapping support (B16b2) • Bit 3—Text scrolling support (B16b3) • Bit 4—Not used • Bit 5—Not used • Bit 6—Not used • Bit 7—Not used • Byte 05: <ul style="list-style-type: none"> • Bit 0–7—Maximum softkey size (B11b1–B11b8) • Byte 06: <ul style="list-style-type: none"> • Bit 0–4—Number of character support down ME (screen height) (B14b1–B14b5) • Bit 5–7—Reduce width of menu support (B16b6–B16b8) • Byte 07: <ul style="list-style-type: none"> • Bit 0–6—Number of character support across ME (screen width) (B15b1–B15b7) • Bit 7—Not used

>> 5: Diagnostic Commands

Introduction

This chapter describes commands used to diagnose modem problems.

Command summary

The table below lists the commands described in this chapter.

Table 5-1: Diagnostic Commands

Command	Description	Page
!BCFWUPDATESTATUS	Report status of most recent firmware update attempt	142
!BCRESETTYPE	Report module reset type and cause	143
!ERR	Display/clear diagnostic information	144
!GCCLR	Clear crash dump data	144
!GCDUMP	Display crash dump data	144
!RXDEN	Enable/disable WCDMA/LTE receive diversity	145

Command reference

Table 5-2: Diagnostic Command Details

Command	Description
!BCFWUPDATESTATUS	<p>Report status of most recent firmware update attempt</p> <p>Return the status of the most recent firmware update attempt made since the last cold restart.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!BCFWUPDATESTATUS Response: !BCFWUPDATESTATUS: <result> <i>or</i> !BCFWUPDATESTATUS: <result> Failed IMG TYPE <type>, DATA <data>, PART <part> OK <p>Purpose: Return the status of the most recent firmware update attempt. The second response format appears only if <result> = "FAILED".</p> <p>Parameters:</p> <p><result> (Status of last firmware update attempt)</p> <ul style="list-style-type: none"> • ASCII string: <ul style="list-style-type: none"> • "UNKNOWN"—Status of last attempt is unknown. • "SUCCESS"—Last update was successful. • "FAILED"—Last update failed. <p><type> (Firmware image type that failed to update)</p> <ul style="list-style-type: none"> • ASCII string <p><data> (Reference data for failed image)</p> <ul style="list-style-type: none"> • Location of the reference data as an offset in the CWE image • Valid range: 0–(2³²-1) <p><part> (Partition associated with the failed image)</p> <ul style="list-style-type: none"> • ASCII string

Table 5-2: Diagnostic Command Details (Continued)

Command	Description
!BCRESETTYPE	<p>Report module reset type and cause</p> <p>Display the reason (type and cause) for the module's most recent reset.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Query: AT!BCRESETTYPE? Response: !BCRESETTYPE: reset type <reset_type>, source <source_type> OK • Purpose: Return the type and cause of the module's most recent reset. • Query List: AT!BCRESETTYPE=? Purpose: No details returned. <p>Parameters:</p> <p><reset_type> (Type of reset that occurred)</p> <ul style="list-style-type: none"> • 0—Unknown reset • 1—Warm reset • 2—Hardware reset • 3—Unexpected reset/crash • 4—Controlled power-down <p><source_type> (Reset cause)</p> <ul style="list-style-type: none"> • 0—Unknown reset • 1—User requested • 2—Hardware input • 3—Temperature critical • 4—Voltage critical • 5—Configuration update • 6—LWM2M requested • 7—OMADM requested • 8—FOTA requested

Table 5-2: Diagnostic Command Details (Continued)

Command	Description
!ERR	<p>Display/clear diagnostic information</p> <p>This command is used to display or clear diagnostic information (logged error conditions) that Sierra Wireless uses to assist in resolving technical issues.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: ATIERR=0 Response: OK Purpose: Clear the logged error conditions. Use this command before running tests to make sure that details displayed using ATIERR are relevant to the tests being performed. • Query: ATIERR Response: 00 [F] <count> <file> <line> ... nn [F] <count> <file> <line> OK Purpose: Return all logged error conditions that are stored in NVRAM. <p>Parameters:</p> <p><count> (Number of occurrences)</p> <ul style="list-style-type: none"> • Valid range: 0x00–0xFF <p><file> (Log file name)</p> <ul style="list-style-type: none"> • Name of log file using ASCII characters <p><line> (Line number in log file)</p> <ul style="list-style-type: none"> • Valid range: 1–99999
!GCCLR	<p>Clear crash dump data</p> <p>Clear crash dump data.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: ATIGCCLR Response: Crash data cleared OK Purpose: Clear crash dump data. <p>Parameters:</p> <p>None</p>
!GCDUMP	<p>Display crash dump data</p> <p>Display crash dump data.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: ATIGCDUMP Response: (crash dump data) OK or No crash data available OK Purpose: Display crash dump data.

Table 5-2: Diagnostic Command Details (Continued)

Command	Description
!RXDEN	<p>Enable/disable WCDMA/LTE receive diversity</p> <p>Enable or disable WCDMA/LTE receive diversity, or establish receive diversity as the primary path. The new state takes effect the next time the modem is reset.</p> <hr/> <p><i>Note: To change from <state=0> to <state=2> (or from <state=2> to <state=0>), you must issue AT!RXDEN=1, reset the modem, and then make the final state change.</i></p> <hr/> <p>Password required: Yes—Execution format only Reset required to apply changes: Yes Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!RXDEN=<state> Response: OK Purpose: Set the current receive diversity state. • Query: AT!RXDEN? Response: !RXDEN: <state> OK Purpose: Return the current receive diversity <state>. • Query List: AT!RXDEN=? Purpose: Return a list of available <state> values to use in this command. <p>Parameters:</p> <p><state> (Current/ requested receive diversity state)</p> <ul style="list-style-type: none"> • 0 = Rx diversity disabled • 1 = Rx diversity enabled • 2 = Rx diversity is primary path

>> 6: Test Commands

Introduction

To obtain regulatory approval and carrier approvals for your product, you may be required to perform tests on the radio component of the embedded modem. This chapter describes AT commands used to perform those tests.

Warning: *These commands are intended for use by developers, not end-users. The commands should be used only in a controlled network environment.*

In most cases the modem must be in a particular mode before you can issue the AT commands to perform particular tests. Therefore, the order in which you issue certain commands is important. Three AT commands are important in setting the mode:

- **IDAFTMACT**—puts the modem in factory test mode (a non-signaling mode). You must issue **ATIDAFTMACT** before issuing any other command that starts with “!DA”.
- **IDASBAND**—selects the frequency band.
- **IDASCHAN**—selects the channel. This command must be run after you have selected the band with **IDASBAND**. (If you don’t select a channel, the modem uses a default.)

Command summary

The table below lists the commands described in this chapter.

Table 6-1: Test Commands

Command	Description	Page
!DACGPSCTON	Return CGPS C/N and frequency	149
!DACGPSMASKON	Set CGPS log mask	149
!DACGPSSTANDALONE	Enter/exit Stand Alone RF mode	150
!DACGPSTESTMODE	Start/stop CGPS diagnostic task	150
!DAFTMACT	Put modem into Factory Test Mode	151
!DAFTMDEACT	Put modem into Online Mode from Factory Test Mode	151
!DAGGAVGRSSI	Return averaged RSSI value in dBm (GSM only)	152
!DAGSRXBURST	Set GSM receiver to burst mode (GSM only)	152
!DAGSTXFRAME	Set GSM Tx frame structure (GSM only)	153
!DALGAVGAGC	Return averaged Rx AGC value (LTE only)	154
!DALSNSVAL	Configure LTE Net Sig value (LTE only)	155
!DALSPARANGE	Set LTE PA range (LTE only)	155
!DALSRXBW	Set LTE Rx bandwidth (LTE only)	156
!DALSTXBW	Set LTE Tx bandwidth (LTE only)	156
!DALSTXMOD	Set LTE Tx modulation type (LTE only)	157
!DALSTXPWR	Set LTE Tx power level (LTE only)	158
!DALSWAVEFORM	Set LTE TX waveform (LTE only)	159
!DASBAND	Set frequency band	160
!DASCALSTATE	Enter/exit modem calibration state	161
!DASCHAN	Set modem channel (frequency)	162
!DASLNAGAIN	Set LNA gain state	163
!DASPDM	Set PDM value (WCDMA and GSM only)	164
!DASTXOFF	Turn Tx PA off	164
!DASTXON	Turn Tx PA on	165
!DAWGAVGAGC	Return averaged Rx AGC value (WCDMA only)	165
!DAWGRXAGC	Return Rx AGC value (WCDMA only)	166
!DAWSCONFIGRX	Configure receiver (WCDMA only)	167
!DAWSPARANGE	Set PA range state machine (WCDMA only)	168

Table 6-1: Test Commands (Continued)

Command	Description	Page
!DAWSSCHAIN	Enable secondary receive chain (WCDMA only)	168
!DAWSTXCW	Set waveform used by the transmitter (WCDMA only)	169
!DAWSTXPWR	Set desired Tx power level (WCDMA mode only)	169
!LEDTEST	Test LED	170

Command reference

Table 6-2: Test Command Details

Command	Description
!DACGPSCTON	<p>Return CGPS C/N and frequency</p> <p>Return the CGPS C/N (signal strength) and frequency measurement.</p> <p>Requirements: Before this command can be used:</p> <ul style="list-style-type: none"> Use !DACGPSTESTMODE=1 to start the CGPS diagnostic task Use !DACGPSSTANDALONE=1 to enter standalone RF mode Use !DACGPSMASKON to enable the CGPS log mask <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT!DACGPSCTON Response: CtoN=<CtoN>,Freq=<freq> OK Purpose: Return the current CGPS signal strength and frequency. <p>Parameters:</p> <p><CtoN> (Signal strength)</p> <ul style="list-style-type: none"> 0.0–99.0—Signal strength calculated in 0.1 dBHz. <p><freq> (Frequency offset)</p> <ul style="list-style-type: none"> 0–4294967295—Frequency offset in Hz.
!DACGPSMASKON	<p>Set CGPS log mask</p> <p>Set the CGPS IQ log mask.</p> <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT!DACGPSMASKON Response: <logmask> OK Purpose: Enter or exit Stand Alone RF mode. <p>Parameters:</p> <p><logmask> (CGPS IQ log mask)</p> <ul style="list-style-type: none"> 288-character hexadecimal string The <logmask> is the raw data returned by the Qualcomm GPS Diag module. This value does not affect the GPS test and can be ignored.

Table 6-2: Test Command Details (Continued)

Command	Description
!DACGPSSTANDALONE	<p>Enter/exit Stand Alone RF mode Enter or exit stand alone (SA) RF mode.</p> <p>Requirements: Before this command can be used:</p> <ul style="list-style-type: none"> Use IDACGPSTESTMODE=1 to start the CGPS diagnostic task. <p>Password required: Yes (see IINTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT!DACGPSSTANDALONE=<state> Response: <status> OK <i>or</i> ERROR Purpose: Enter or exit Stand Alone RF mode. <p>Parameters:</p> <p><state> (Requested SA RF mode)</p> <ul style="list-style-type: none"> 0—Exit 1—Enter <p><status> (Return value indicating requested <state> change)</p> <ul style="list-style-type: none"> Appears only if <state> change is successful. 4B0D65001400—Successfully changed state.
!DACGPSTESTMODE	<p>Start/stop CGPS diagnostic task Start or stop the CGPS diagnostic task. This command allows the GNSS engine to be tested without obtaining a GNSS position fix.</p> <p>Password required: Yes (see IINTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT!DACGPSTESTMODE=<mode> Response: <status> OK <i>or</i> ERROR Purpose: Start or stop the CGPS diagnostic task. <p>Parameters:</p> <p><mode> (Start/stop CGPS diagnostic task)</p> <ul style="list-style-type: none"> 0—Stop 1—Start <p><status> (Return value indicating requested <mode> change)</p> <ul style="list-style-type: none"> Appears only if <mode> change is successful. 4B0D0800—Successfully started the CGPS diagnostic task 4B0D0C00—Successfully stopped the CGPS diagnostic task

Table 6-2: Test Command Details (Continued)

Command	Description
!DAFTMACT	<p>Put modem into Factory Test Mode</p> <p>Place the modem in FTM (Factory Test Mode). FTM is a non-signaling mode that allows the radio component to be manually configured to conduct certain types of tests. The modem must be in FTM mode to use the test commands described in this chapter (except for commands that start with “!DACGPS”</p> <hr/> <p><i>Note: When this command executes successfully, the modem responds with the value 290300. Any other response indicates an error.</i></p> <hr/> <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Query: ATIDAFTMACT Response: 290300 (Success. Any other response indicates an error.) OK Purpose: Place modem in FTM mode (from online mode)
!DAFTMDEACT	<p>Put modem into Online Mode from Factory Test Mode</p> <p>Take the modem out of FTM and put it back into online mode. (!DAFTMACT puts the modem into FTM.)</p> <hr/> <p><i>Note: When this command executes successfully, the modem responds with the value 290400. Any other response indicates an error.</i></p> <hr/> <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Query: ATIDAFTMDEACT Response: 290400 (Success. Any other response indicates an error.) OK Purpose: Place modem in online mode (from FTM mode).

Table 6-2: Test Command Details (Continued)

Command	Description
!DAGGAVGRSSI	<p>Return averaged RSSI value in dBm (GSM only) Return an averaged RSSI (Received Signal Strength Indicator) value in dBm.</p> <p>Requirements: Before this command can be used:</p> <ul style="list-style-type: none"> • Use !DAFTMACT to enter FTM mode. • Use !DASBAND to set the device to a GSM band. <p>Password required: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!DAGGAVGRSSI=<channel>, <LNA Index> Response: OK Purpose: Return the averaged RSSI for the specified channel and LNA offset index. <p>Parameters:</p> <p><channel> (Channel number for the band specified using !DASBAND)</p> <ul style="list-style-type: none"> • Valid values depend on the selected band <p><LNA Index> (LNA offset index)</p> <ul style="list-style-type: none"> • 0=R0 (highest gain) • 1=R1 • 2=R2 • 3=R3 (lowest gain)
!DAGSRXBURST	<p>Set GSM receiver to burst mode (GSM only) Set the receiver to start or stop sending bursts. (The receiver must be in burst mode to read the RSSI.)</p> <p>Requirements: Before this command can be used:</p> <ul style="list-style-type: none"> • Use !DAFTMACT to enter FTM mode. • Use !DASBAND to set the device to a GSM band. • Use !DASCHAN to set the uplink channel for the selected band. <p>Password required: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!DAGSRXBURST=<function> Response: <function> OK Purpose: Set the receiver to burst mode <p>Parameters:</p> <p><function></p> <ul style="list-style-type: none"> • 0=Get RSSI (Burst mode) • 2=Stop continuous Rx

Table 6-2: Test Command Details (Continued)

Command	Description
!DAGSTXFRAME	<p>Set GSM Tx frame structure (GSM only)</p> <p>This command configures the Tx slots for GSM operation. It must be issued eight times to set all eight slots.</p> <p>Requirements: Before this command can be used:</p> <ul style="list-style-type: none"> • Use !DAFTMACT to enter FTM mode. • Use !DASBAND to set the device to a GSM band. • Use !DASCHAN to set the uplink channel for the selected band. <p>Password required: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!DAGSTXFRAME=<slotnum>, <onoff>, <pwr>, <mcs> Response: <slotnum> <onoff> <pwr> <mcs> OK Purpose: Set the Tx frame structure. <p>Parameters:</p> <p><slotnum> (Slot number)</p> <ul style="list-style-type: none"> • Valid range: 0–7 (eight available Tx slots) <p><onoff> (Enable/disable the specified slot)</p> <ul style="list-style-type: none"> • 0=Off (disable) • 1=On (enable) <p><pwr> (Slot power level)</p> <ul style="list-style-type: none"> • Measured in dB*100 • Maximum values: <ul style="list-style-type: none"> • GMSK Mode <ul style="list-style-type: none"> 850/900 bands: 3200 (32 dBm) 1800/1900 bands: 2900 (29 dBm) • 8PSK (EDGE) Mode <ul style="list-style-type: none"> 850/900 bands: 2700 (27 dBm) 1800/1900 bands: 2600 (26 dBm) <p><mcs> (Modulation code scheme)</p> <ul style="list-style-type: none"> • Valid range: 0–8 (MCS1 to MCS9)

Table 6-2: Test Command Details (Continued)

Command	Description
!DALGAVGAGC	<p>Return averaged Rx AGC value (LTE only)</p> <p>Return the averaged AGC (Automatic Gain Control) readings for a specific uplink channel on the main and diversity paths.</p> <p>Requirements: Before this command can be used:</p> <ul style="list-style-type: none"> • Use !DAFTMACT to enter FTM mode. • Use !DASBAND to set the device to an LTE band. • Use !DALSRXBW to set the LTE Rx bandwidth. <p>Password required: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!DALGAVGAGC=<channel>, <LNA Index> <p>Response: Paths: <paths> Rx<n>: AGC: <agc> dBm LNA: <lina> Chain: <chain> Rx<n>: AGC: <agc> dBm LNA: <lina> Chain: <chain> OK</p> <p>Purpose: Return the averaged AGC for <channel> on the main and diversity paths.</p> <p>Parameters:</p> <p><channel> (Uplink channel number (UARFCN) for the band specified using !DASBAND)</p> <ul style="list-style-type: none"> • Valid values depend on the selected band <p><LNA Index> (LNA offset index)</p> <ul style="list-style-type: none"> • 0—R0 (Highest gain) • 1—R1 • 2—R2 • 3—R3 (Lowest gain) <p><paths> (Number of receive paths)</p> <ul style="list-style-type: none"> • 2 <p><agc> (AGC value in dBm)</p> <ul style="list-style-type: none"> • Valid values: Dynamic Rx range <p><chain> (Receive paths)</p> <ul style="list-style-type: none"> • 0—Rx Main • 1—Rx Diversity

Table 6-2: Test Command Details (Continued)

Command	Description
!DALSNSVAL	<p>Configure LTE Net Sig value (LTE only)</p> <p>Configure the LTE Net Sig (NS) value, which will be used to configure Tx power. The NS value is used to determine the additional max power backoff to reduce spectrum emissions.</p> <p>Command Availability: WP76, WP77. Valid in WP75xx/WP85xx Release 16 and later.</p> <p>Requirements: Before this command can be used:</p> <ul style="list-style-type: none"> • Use !DAFTMACT to enter FTM mode. • Use !DASBAND to set the device to an LTE band. • Use !DASCHAN to set the uplink channel for the selected band. • Use !DALSRXBW to set the LTE Rx bandwidth. • Use !DALSTXBW to set the LTE Tx bandwidth. • Use !DALSTXMOD to set the LTE Tx modulation type. • Use !DALSWAVEFORM to set the LTE Tx waveform characteristics. <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!DALSNSVAL=<ns_val> Response: OK Purpose: Set the LTE Net Sig value. <p>Parameters:</p> <p><ns_val> (Net Sig value)</p> <ul style="list-style-type: none"> • 1–32
!DALSPARANGE	<p>Set LTE PA range (LTE only)</p> <p>Set the LTE PA (Power Amplifier) range.</p> <p>Requirements: Before this command can be used:</p> <ul style="list-style-type: none"> • Use !DAFTMACT to enter FTM mode. • Use !DASBAND to set the device to an LTE band. • Use !DALSTXBW to set the LTE Tx bandwidth. • Use !DASCHAN to set the uplink channel for the selected band. <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!DALSPARANGE=<pa_range> Response: OK Purpose: Set the LTE PA range. <p>Parameters:</p> <p><pa_range> (PA range)</p> <ul style="list-style-type: none"> • 0–3

Table 6-2: Test Command Details (Continued)

Command	Description
!DALSRXBW	<p>Set LTE Rx bandwidth (LTE only) Set the LTE Rx bandwidth.</p> <p>Requirements: Before this command can be used:</p> <ul style="list-style-type: none"> • Use !DAFTMACT to enter FTM mode. • Use !DASBAND to set the device to an LTE band. <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!DALSRXBW=<bw> Response: OK Purpose: Set the LTE Rx bandwidth. <p>Parameters: <bw> (LTE bandwidth)</p> <ul style="list-style-type: none"> • 0=1.4 MHz • 1=3 MHz • 2=5 MHz • 3=10 MHz • 4=15 MHz • 5=20 MHz
!DALSTXBW	<p>Set LTE Tx bandwidth (LTE only) Set the LTE Tx bandwidth.</p> <p>Requirements: Before this command can be used:</p> <ul style="list-style-type: none"> • Use !DAFTMACT to enter FTM mode. • Use !DASBAND to set the device to an LTE band. <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!DALSTXBW=<bw> Response: OK Purpose: Set the LTE Tx bandwidth. <p>Parameters: <bw> (LTE bandwidth)</p> <ul style="list-style-type: none"> • 0=1.4 MHz • 1=3 MHz • 2=5 MHz • 3=10 MHz • 4=15 MHz • 5=20 MHz

Table 6-2: Test Command Details (Continued)

Command	Description
!DALSTXMOD	<p>Set LTE Tx modulation type (LTE only) Set the LTE Tx modulation type.</p> <p>Requirements: Before this command can be used:</p> <ul style="list-style-type: none"> • Use !DAFTMACT to enter FTM mode. • Use !DASBAND to set the device to an LTE band. • Use !DALSRXBW to set the LTE Rx bandwidth. • Use !DALSTXBW to set the LTE Tx bandwidth. • Use !DASCHAN to set the uplink channel for the selected band. <p>After this command is used:</p> <ul style="list-style-type: none"> • For the modulation change to have an effect, use !DALSWAVEFORM to set the LTE Tx waveform. <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!DALSTXMOD=<mod_type> Response: OK Purpose: Set the LTE Tx modulation type. <p>Parameters: <mod_type> (LTE modulation type)</p> <ul style="list-style-type: none"> • 0—QPSK • 1—16 QAM • 2—64 QAM

Table 6-2: Test Command Details (Continued)

Command	Description
<p>!DALSTXPWR</p>	<p>Set LTE Tx power level (LTE only) Set the desired LTE Tx power level.</p> <hr/> <p><i>Note: This command cannot support a PUCCH waveform. (Waveform type is set using !DALSPARANGE.)</i></p> <hr/> <p>Password required: Yes (see !ENTERCND for details)</p> <p>Requirements: Before using this command, perform the following steps:</p> <ol style="list-style-type: none"> a. Use !DAFTMACT to enter FTM mode. b. Use !DASBAND to set the device to an LTE band. c. Use !DASCHAN to set the uplink channel for the selected band. d. Use !DALSRXBW to set the LTE Rx bandwidth. e. Use !DALSTXBW to set the LTE Tx bandwidth. f. Use !DALSTXMOD to set the LTE Tx modulation type. g. Use !DALSWAVEFORM to set the LTE Tx waveform characteristics. h. Use !DALSNSVAL to set the LTE Net Sig value. i. Use !DASTXON to turn the LTE transceiver PA on. <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!DALSTXPWR=<enable>,<power_dBm> Response: OK Purpose: Set the LTE Tx modulation type. <p>Parameters:</p> <p><enable> (Enable/disable Tx power output)</p> <ul style="list-style-type: none"> • 0—Disable • 1—Enable <p><power_dBm> (Desired Tx power)</p> <ul style="list-style-type: none"> • -57 to 23—Tx power in dBm • Field is ignored if <enable>=0

Table 6-2: Test Command Details (Continued)

Command	Description														
!DALSWAVEFORM	<p>Set LTE TX waveform (LTE only) Set the LTE Tx waveform characteristics.</p> <p>Requirements: Before this command can be used:</p> <ul style="list-style-type: none"> • Use !DAFTMACT to enter FTM mode. • Use !DASBAND to set the device to an LTE band. • Use !DALSTXBW to set the LTE Tx bandwidth. • Use !DASCHAN to set the uplink channel for the selected band. <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!DALSWAVEFORM=<waveform>[,<PUSCH_RB_s>,<PUCCH_RB_s>,<PUSCH_start_RB_index>] <p>Response: OK Purpose: Set the LTE Tx waveform characteristics.</p> <p>Parameters:</p> <p><waveform> (Tx waveform)</p> <ul style="list-style-type: none"> • 0=1 MHz offset CW (Carrier Wave) • 1=LTE PUSCH (Physical Uplink Shared Channel) • 2=LTE PUCCH (Physical Uplink Control Channel) • 3=LTE PRACH (Physical Random Access Channel) • 4=LTE SRS (Signaling Reference Signal) • 5=UpPTS (Uplink Pilot Time Slot (LTE TDD)) <p><PUSCH_RB_s> (Number of PUSCH resource blocks)</p> <ul style="list-style-type: none"> • Valid range: 0–100 • Recommended number of PUSCH RBs: <table border="1"> <thead> <tr> <th>Bandwidth (MHz)</th> <th>PUSCH RBs</th> </tr> </thead> <tbody> <tr> <td>1.4</td> <td>6</td> </tr> <tr> <td>3</td> <td>15</td> </tr> <tr> <td>5</td> <td>25</td> </tr> <tr> <td>10</td> <td>50</td> </tr> <tr> <td>15</td> <td>75</td> </tr> <tr> <td>20</td> <td>100</td> </tr> </tbody> </table> <p><PUCCH_RB_s> (Number of PUCCH resource blocks)</p> <ul style="list-style-type: none"> • Valid range: 0–12 <p><PUSCH_start_RB_index> (PUSCH starting resource block index)</p> <ul style="list-style-type: none"> • Valid range: 0–255 	Bandwidth (MHz)	PUSCH RBs	1.4	6	3	15	5	25	10	50	15	75	20	100
Bandwidth (MHz)	PUSCH RBs														
1.4	6														
3	15														
5	25														
10	50														
15	75														
20	100														

Table 6-2: Test Command Details (Continued)

Command	Description
!DASBAND	<p>Set frequency band</p> <p>Set the modem to use a particular frequency band. You must use this command to select an appropriate band before running LTE, WCDMA, or GSM commands. See page 146.</p> <p>Requirements: Before this command can be used:</p> <ul style="list-style-type: none"> Use !DAFTMACT to enter FTM mode. <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT!DASBAND=<rfband> Response (GSM/WCDMA): <rfband> OK Response (LTE): 0 OK <i>(Note: For LTE frequency bands, even though the response shows 0 instead of <rfband>, the band has been set correctly if the response shows 'OK'.)</i> <p>Purpose: Set frequency band.</p> <p>Parameters: <rfband> (Unique value corresponding to an RF band and technology.)</p> <ul style="list-style-type: none"> Unique value that maps to an RF band and technology. It is not an actual 3GPP band number. For example, '18' is GSM 850, which corresponds to 3GPP band 5 (on a GSM network). Band support is product-dependent—see the device's Product Specification or Product Technical Specification document for details. Examples (for a full listing, see Table 18-1 on page 289): <ul style="list-style-type: none"> GSM <ul style="list-style-type: none"> 10=GSM 900 11=GSM 1800 12=GSM 1900 18=GSM 850 WCDMA <ul style="list-style-type: none"> 9=WCDMA 2100 16=WCDMA 1900B 22=WCDMA 850 29=WCDMA 900 (BC8) LTE <ul style="list-style-type: none"> 34=LTE B1 35=LTE B7 36=LTE B13 37=LTE B17 42=LTE B4 44=LTE B3 47=LTE B8 56=LTE B20

Table 6-2: Test Command Details (Continued)

Command	Description
!DASCALSTATE	<p>Enter/exit modem calibration state Put the modem into (or exit from) calibration state.</p> <p>Requirements: Before this command can be used:</p> <ul style="list-style-type: none"> • Use !DAFTMACT to enter FTM mode. • Use !DASBAND to set the device to an LTE, WCDMA, or GSM band. <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!DASCALSTATE=<cal_state> Response: OK Purpose: Set the modem's calibration state. <p>Parameters: <cal_state> (Calibration state)</p> <ul style="list-style-type: none"> • 0—Exit calibration state • 1—Enter calibration state

Table 6-2: Test Command Details (Continued)

Command	Description
!DASCHAN	<p>Set modem channel (frequency)</p> <p>Set the modem to operate on a particular frequency channel. Before using this command, use the command !DASBAND (described on page 160) to set the band.</p> <p>Once a channel is set, the modem continues to use that channel until the modem is reset or powered off and on.</p> <p>Requirements:</p> <ul style="list-style-type: none"> • Use !DAFTMACT to enter FTM mode. • Use !DASBAND to set the device to an LTE, WCDMA, or GSM band. • If In LTE mode (an LTE band was selected): <ul style="list-style-type: none"> • Use !DALSRXBW to set the LTE Rx bandwidth. • Use !DALSTXBW to set the LTE Tx bandwidth. • Use !DASCHAN to set the uplink channel for the selected band. <p>Password required: Yes (see !ENTERCND for details)</p> <p>Reset required to apply changes: No</p> <p>Persistent across power cycles: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!DASCHAN=<rfchannel> Response: <rfchannel> OK Purpose: Set modem channel (frequency). <p>Parameters:</p> <p><rfchannel> (Uplink channel number (ARFCN)—depends on frequency band being used)</p> <ul style="list-style-type: none"> • 128–251: GSM 850 MHz • 1–24: GSM 900 MHz • 975–1023: GSM 900 MHz • 512–885: GSM 1800 MHz • 512–810: GSM 1900 MHz • 9612–9888: WCDMA 2100 • 9262–9538: WCDMA 1900 • 4132–4233: WCDMA 850 • 2712–2863: WCDMA 900 • 18000–18599: LTE B1 • 19200–19949: LTE B3 • 19950–20399: LTE B4 • 20750–21449: LTE B7 • 21450–21799: LTE B8 • 23180–23279: LTE B13 • 23730–23849: LTE B17 • 24150–24449: LTE B20

Table 6-2: Test Command Details (Continued)

Command	Description
!DASLNAGAIN	<p>Set LNA gain state</p> <p>Set the LNA (Low Noise Amplifier) range for the main or diversity path (if applicable), in either WCDMA or GSM mode.</p> <p>Requirements:</p> <ul style="list-style-type: none"> • Use !DAFTMACT to enter FTM mode. • Use !DASBAND to set the device to a WCDMA or GSM band • Use !DASCHAN to set the uplink channel for the selected band. <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: !DASLNAGAIN=<gain index>[, <path>] Response: <gain index> OK Purpose: Set the LNA gain state for either the main or diversity paths. <p>Parameters:</p> <p><gain index></p> <ul style="list-style-type: none"> • 0=R0 (highest gain) Approximate switch from low to high gain: WCDMA (< -72 dBm); GSM (< -73 dBm) • 1=R1 Approximate switch from low to high gain: WCDMA (< -72 up to -46 dBm); GSM (< -73 up to -58 dBm) • 2=R2 Approximate switch from low to high gain: WCDMA (< -46 up to -36 dBm); GSM (< -58 up to -41 dBm) • 3=R3 (lowest gain) Approximate switch from low to high gain: WCDMA (> -36 dBm); GSM (< -41 dBm) <hr/> <p><i>Note: The LNA gain state is set based on the expected receive power level. The gain state values listed above are provided as a guideline. Values are approximations and subject to change over time.</i></p> <hr/> <p><path> (For modules supporting diversity)</p> <ul style="list-style-type: none"> • 0=Main path (Default) • 1=Secondary (diversity) path

Table 6-2: Test Command Details (Continued)

Command	Description
!DASPDM	<p>Set PDM value (WCDMA and GSM only)</p> <p>Adjust the PDM (Pulse Duration Modulation), allowing you to apply frequency offset to the LO (Local Oscillator) or Tx AGC.</p> <p>When you adjust the Tx AGC (<PDM ID> = 2), the modem does not use a calibrated result but uses the raw AGC value. The resulting change in Tx power will vary from modem to modem, so it is usually necessary to tune this value by executing the command repeatedly with different settings for the <PDMvalue> until you obtain the desired Tx power.</p> <p>When adjusting the tracking LO, you also need to execute the command repeatedly with different settings for the <PDMvalue> until you obtain the desired frequency offset.</p> <p>Requirements:</p> <ul style="list-style-type: none"> • Use !DAFTMACT to enter FTM mode. • Use !DASBAND to set the device to a WCDMA or GSM band. • Use !DASCHAN to set the uplink channel for the selected band. <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: ATIDASPDM=<PDM ID>, <PDMvalue> Response: <PDM ID> <PDMvalue> OK Purpose: Set the tracking LO and Tx AGC PDM. <p>Parameters:</p> <p><PDM ID> (LO (Local Oscillator) or Tx AGC (Automatic Gain Control) to adjust)</p> <ul style="list-style-type: none"> • 0—Tracking LO adjust (GSM only) • 2—Tx AGC adjust (WCDMA only) • 4—Tracking LO adjust (WCDMA only) <p><PDMvalue> (Frequency offset value)</p> <ul style="list-style-type: none"> • If <PDM ID>=0: 0–511 • If <PDM ID>=2: 0–511 • If <PDM ID>=4: 0–65535
!DASTXOFF	<p>Turn Tx PA off</p> <p>Turn the transceiver PA off, after it has been turned on with !DASTXON.</p> <p>Requirements:</p> <ul style="list-style-type: none"> • Use !DAFTMACT to enter FTM mode. • Use !DASBAND to set the band. • Use !DASCHAN to set the uplink channel for the selected band. <p>Password required: Yes (see !ENTERCND for details)</p> <p>Reset required to apply changes: No</p> <p>Persistent across power cycles: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: ATIDASTXOFF Response: OK Purpose: Turn the Tx PA off. <p>Parameters:</p> <p>None</p>

Table 6-2: Test Command Details (Continued)

Command	Description
!DASTXON	<p>Turn Tx PA on</p> <p>Turn the transceiver PA on. The PA remains on until you turn it off using !DASTXOFF, or until you reset or power the modem down and up.</p> <p>Requirements:</p> <ul style="list-style-type: none"> • Use !DAFTMACT to enter FTM mode. • Use !DASBAND to set the band. • Use !DASCHAN to set the uplink channel for the selected band. <p>Password required: Yes (see !ENTERCND for details)</p> <p>Reset required to apply changes: No</p> <p>Persistent across power cycles: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!DASTXON • Response: OK • Purpose: Turn the Tx PA on. <p>Parameters:</p> <ul style="list-style-type: none"> • None
!DAWGAVGAGC	<p>Return averaged Rx AGC value (WCDMA only)</p> <p>Return the averaged AGC (Automatic Gain Control) reading for a specific band for either the main path or diversity path (if applicable).</p> <p>Requirements:</p> <ul style="list-style-type: none"> • Use !DAFTMACT to enter FTM mode. • Use !DASBAND to set the device to a WCDMA band. <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!DAWGAVGAGC=<channel>, <LNA Index>[, <path>] • Response: <agc> OK • Purpose: Return the averaged AGC for <channel> on the main path or diversity path. <p>Parameters:</p> <p><channel> (Uplink channel number (UARFCN) for the band specified using !DASBAND)</p> <ul style="list-style-type: none"> • Valid values depend on the selected band <p><LNA Index> (LNA offset index)</p> <ul style="list-style-type: none"> • 0=R0 (Highest gain) • 1=R1 • 2=R2 • 3=R3 (Lowest gain) <p><path> (For modules supporting diversity)</p> <ul style="list-style-type: none"> • 0=Main path • 1=Diversity path <p><agc> (Averaged Rx AGC in dBm)</p> <ul style="list-style-type: none"> • Example: -78.9

Table 6-2: Test Command Details (Continued)

Command	Description
!DAWGRXAGC	<p>Return Rx AGC value (WCDMA only)</p> <p>Return the Rx AGC (Automatic Gain Control) reading for a specific band for either the main path or diversity path (if applicable).</p> <p>Requirements:</p> <ul style="list-style-type: none"> • Use !DAFTMACT to enter FTM mode. • Use !DASBAND to set the device to a WCDMA band. • Use !DASCHAN to set the device to a specific channel on the WCDMA band. <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!DAWGRXAGC Response: <agc> OK Purpose: Return the AGC for the current band/channel on the main path. • Query: AT!DAWGRXAGC?<path> Response: <agc> OK Purpose: Return the AGC for the current band/channel on the specified path. <p>Parameters:</p> <p><path> (For modules supporting diversity)</p> <ul style="list-style-type: none"> • 0—Main path • 1—Diversity path <p><agc> (Averaged Rx AGC)</p> <ul style="list-style-type: none"> • -512 to 511 • To convert <agc> to RxAGC value in dBm: <ul style="list-style-type: none"> • If (<agc> < 511): RxAGC = -106 + ((<agc> + 512) / 12) • If (<agc> = 511): RxAGC = -106 + (((<agc> - 1024) + 512) / 12)

Table 6-2: Test Command Details (Continued)

Command	Description
!DAWSCONFIGRX	<p>Configure receiver (WCDMA only) Configure the receiver using the calibration NV file.</p> <p>Requirements:</p> <ul style="list-style-type: none"> • Use !DAFTMACT to enter FTM mode. • Use !DASBAND to set the device to a WCDMA band. • Use !DASCHAN to set the device to a specific channel on the WCDMA band. <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!DAWSCONFIGRX=<channel>,<Rx_level_dBm> Response: <LNA_Index> <LNA_Value> OK Purpose: Configure the Rx level for the specified uplink channel. <p>Parameters:</p> <p><channel> (Uplink channel number (UARFCN) for the band specified using !DASBAND)</p> <ul style="list-style-type: none"> • Valid values depend on the selected band <p><Rx_level_dBm> (Rx level, in dBm)</p> <ul style="list-style-type: none"> • Signed integer • Valid range: -113 to 20 <p><LNA_Index> (LNA offset index)</p> <ul style="list-style-type: none"> • 0—R0 (Highest gain) • 1—R1 • 2—R2 • 3—R3 (Lowest gain) <p><LNA_Value> (LNA offset value, in 1/12 dB resolution)</p> <ul style="list-style-type: none"> • Signed integer <p>Example(s):</p> <pre>AT!DAWSCONFIGRX=9612,-100 0 0 OK</pre>

Table 6-2: Test Command Details (Continued)

Command	Description
!DAWSPARANGE	<p>Set PA range state machine (WCDMA only) Set the PA range state machine in WCDMA operation.</p> <p>Requirements:</p> <ul style="list-style-type: none"> • Use !DAFTMACT to enter FTM mode. • Use !DASBAND to set the device to a WCDMA band. • Use !DASCHAN to set the uplink channel for the selected band. <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!DAWSPARANGE=<PA range> Response: <PA range> OK Purpose: Set the PA range state machine. <p>Parameters: <PA range></p> <ul style="list-style-type: none"> • 0—Low gain state of the PA — Limited to about 16 dBm output power (R0=0, R1=0) • 1— (R0=1, R1=0) • 2— (R0=0, R1=1) • 3—High gain state of the PA — Up to the maximum output power of the modem (R0=1, R1=1)
!DAWSSCHAIN	<p>Enable secondary receive chain (WCDMA only) Enable or disable the secondary receive chain.</p> <p>Requirements:</p> <ul style="list-style-type: none"> • Use !DAFTMACT to enter FTM mode. • Use !DASBAND to set the device to a WCDMA band. • Use !DASCHAN to set the uplink channel for the selected band. <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!DAWSSCHAIN=<state> Response: OK Purpose: Enable or disable the secondary receive chain. <p>Parameters: <state> (Requested state for secondary receive chain)</p> <ul style="list-style-type: none"> • 0=Off (Disable) • 1=On (Enable)

Table 6-2: Test Command Details (Continued)

Command	Description
!DAWSTXCW	<p>Set waveform used by the transmitter (WCDMA only)</p> <p>Set the waveform used by the transmitter—the modem can transmit either in carrier wave or WCDMA modulated.</p> <p>Requirements:</p> <ul style="list-style-type: none"> • Use !DAFTMACT to enter FTM mode. • Use !DASBAND to set the device to a WCDMA band. • Use !DASCHAN to set the uplink channel for the selected band. <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!DAWSTXCW=<waveform> Response: OK Purpose: Set the transmitter waveform. <p>Parameters:</p> <p><waveform> (Waveform used by the transmitter)</p> <ul style="list-style-type: none"> • 0=WCDMA • 1=Carrier wave (no modulating signal applied)
!DAWSTXPWR	<p>Set desired Tx power level (WCDMA mode only)</p> <p>Enable/disable Tx power output and set the desired Tx power level in dBm.</p> <p>Requirements:</p> <ul style="list-style-type: none"> • The modem must be in WCDMA mode. • Use !DAFTMACT to enter FTM mode. • Use !DASBAND to set the device to a WCDMA band. • Use !DASCHAN to set the uplink channel for the selected band. • Use !DASTXON to turn the transceiver PA. <p>Password required: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!DAWSTXPWR=<enable>,<power_dBm> Response: OK Purpose: Enable/disable Tx power output and set the Tx power level to the requested <dBm> level. <p>Parameters:</p> <p><enable> (Enable/disable Tx power output)</p> <ul style="list-style-type: none"> • 0—Disable • 1—Enable <p><power_dBm> (Desired Tx power in dBm)</p> <ul style="list-style-type: none"> • -57 to 23

Table 6-2: Test Command Details (Continued)

Command	Description
!LEDTEST	<p>Test LED</p> <p>Test an LED by turning it on (light) or off (dark). When finished testing the LED, reboot the device to return to normal LED operation.</p> <hr/> <p><i>Note: Only one LED can be tested at a time.</i></p> <hr/> <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: ATILEDTEST=<led_no>,<state> Response: OK Purpose: Turn the specified LED on (light) or off (dark). • Query List: ATILEDTEST=? Purpose: Display the assignment command format and valid parameter options. <p>Parameters:</p> <p><led no> (LED to test)</p> <ul style="list-style-type: none"> • 0—WWAN_LED <p><state> (LED state)</p> <ul style="list-style-type: none"> • 0—Off (Dark) • 1—On (Light)

>> 7: Memory Management Commands

Introduction

The modem uses non-volatile memory to store:

- Factory calibration data
- Settings made in a host application such as Skylight.

The commands in this chapter allow you to back up and restore the data in non-volatile memory.

Command summary

The table below lists the commands described in this chapter:

Table 7-1: Memory Management Commands

Command	Description	Page
!RMARESET	Restore device	171

Command reference

Table 7-2: Memory Management Command Details

Command	Description
!RMARESET	<p>Restore device</p> <p>Restore the device to its original provisioned (OEM default) state, or to the latest backed-up state.</p> <hr/> <p><i>Note: The module does not reboot automatically. It must be manually rebooted to use the restored settings.</i></p> <hr/> <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!RMARESET=<level> Response: !RMARESET: DEVICE REBOOT REQUIRED Items Restored: ##### Items Deleted: ##### Items Defaulted: ##### Items Skipped: ##### OK Purpose: Restore device to the requested state. <p>Parameters:</p> <p><level> (Restoration type)</p> <ul style="list-style-type: none"> • 1=Default OEM provisioned state • 3=Latest backed-up state

>> 8: GNSS Commands

Introduction

This chapter describes commands used to access GNSS functionality in supporting modules.

When using these commands, the following considerations apply:

- GNSS is typically enabled by default; however, it may be disabled by default for some SKUs. If so, enable GNSS using **ATICUSTOM="GPSENABLE"**
- If supported by the modem, XTRA is enabled (over the NDIS interface) by default when GPS is enabled, and it generates data traffic.

Command summary

The table below lists the commands described in this chapter.

Table 8-1: GPS Commands

Command	Description	Page
!GNSSCONFIG	Configure GNSS satellite constellation support	174
!GPSAUTOSTART	Configure GPS auto-start features	175
!GPSCLRASSIST	Clear specific GPS assistance data	176
!GPSCOLDSTART	Clear all GNSS assistance data	177
!GPSEND	End an active session	177
!GPSFIX	Initiate GPS position fix	178
!GPSIDREN	Enable/disable "Info for DR" feature	179
!GPSLOC	Return last known location of the modem	180
!GPSMOMETHOD	Set/report GPS MO method	181
!GPSMTLRSETTINGS	Set/report MT location request settings	182
!GPSNMEACONFIG	Enable/disable NMEA reporting	183
!GPSNMEASENTENCE	Set/report NMEA sentence type	184
!GPSSATINFO	Request satellite information	186
!GPSSTATUS	Request current status of a position fix session	187
!GPSSUPLURL	Set/report SUPL server URL	188
!GPSSUPLVER	Set/report SUPL server version	189
!GPSTRACK	Initiate local tracking (multiple fix) session	190
!GPSTRANSSEC	Control GPS transport security	191
!GPSXTRADATAENABLE	Set/report GPS XTRA settings	192

Table 8-1: GPS Commands (Continued)

Command	Description	Page
!GPSXTRADATAURL	Set/report GPS XTRA data server URLs	193
!GPSXTRASTATUS	Return current status of XTRA	194
!GPSXTRATIME	Inject GPS or UTC time into XTRA system	195
!GPSXTRATIMEENABLE	Set/report GPS XTRA time settings	196
!GPSXTRATIMEURL	Set/report GPS XTRA SNTP server URLs	197

Command reference

Table 8-2: GPS Command Details

Command	Description
!GNSSCONFIG	<p>Configure GNSS satellite constellation support Configure GNSS engine to support various GNSS satellite systems.</p> <p>Password required: No Reset required to apply changes: Yes Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!GNSSCONFIG=<GPS>,<GLO>,<BDS>,<GAL> Response: OK Purpose: Enable or disable satellite systems. • Query: AT!GNSSCONFIG? Response: GPS: <GPS> GLONASS: <GLO> BDS: <BDS> GAL: <GAL> OK Purpose: Display state of each satellite system (enabled/disabled). • Query List: AT!GNSSCONFIG=? Purpose: Return the expected command format. <p>Parameters:</p> <p><GPS> (GPS satellite system state)</p> <ul style="list-style-type: none"> • 1—Enable • Note: GPS support cannot be disabled. <p><GLO> (GLONASS satellite system state)</p> <ul style="list-style-type: none"> • 0—Disable • 1—Enable <p><BDS> (Beidou satellite system state)</p> <ul style="list-style-type: none"> • 0—Disable • 1—Enable worldwide • 2—Enable outside US <p><GAL> (Galileo satellite system state)</p> <ul style="list-style-type: none"> • 0—Disable • 1—Enable worldwide • 2—Enable outside U.S.

Table 8-2: GPS Command Details (Continued)

Command	Description
!GPSAUTOSTART	<p>Configure GPS auto-start features</p> <p>Configure the GPS auto-start features. Any changes take effect the next time the modem is reset.</p> <hr/> <p><i>Note: If auto-start is enabled, another GPS session cannot be started.</i></p> <hr/> <p>Password required: No Reset required to apply changes: Yes Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!GPSAUTOSTART=<function>[, <fixtype>, <maxtime>, <maxdist>, <fixrate>] <ul style="list-style-type: none"> Response: OK or ERROR Purpose: Assign start values for various GPS settings • Query: AT!GPSAUTOSTART? <ul style="list-style-type: none"> Response: !GPSAUTOSTART function: <function> fixtype: <fixtype> maxtime: <maxtime> seconds maxdist: <maxdist> meters fixrate: <fixrate> seconds OK Purpose: Display the current values for auto-start features • Query List: AT!GPSAUTOSTART=? <ul style="list-style-type: none"> Purpose: Return the expected command format. <p>Parameters:</p> <p><function> (When GPS auto-start will occur)</p> <ul style="list-style-type: none"> • 0=Disabled • 1=At startup • 2=When NMEA port opened <p><fixtype> (Type of fix to establish)</p> <ul style="list-style-type: none"> • 1=Standalone (not supported by a mobile station) • 2=MS-based only • 3=MS-assisted only <p><maxtime> (Maximum time to wait for a position fix)</p> <ul style="list-style-type: none"> • Valid range: 1–255—Number of seconds to wait <p><maxdist> (Requested accuracy of fix)</p> <ul style="list-style-type: none"> • Entered in decimal format • Valid range: <ul style="list-style-type: none"> • 1–4294967279 meters • 4294967280=No preference <p><fixrate> (Time to wait between fixes)</p> <ul style="list-style-type: none"> • Valid range: 1–65535 seconds

Table 8-2: GPS Command Details (Continued)

Command	Description
!GPSCLRASSIST	<p>Clear specific GPS assistance data</p> <p>Clear one or more types of assistance data from the modem. This forces a cold start for GPS acquisition the next time a session starts.</p> <p>This command is equivalent to !GPSCOLDSTART when all four parameters are set to '1'.</p> <p>Requirements:</p> <ul style="list-style-type: none"> Device must not have an active GPS session (the GPS receiver is off and no position fix is being calculated). <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT!GPSCLRASSIST=<eph>, <alm>, <pos>, <time>, <iono> Response: OK or Command ignored OK Purpose: Clear each assistance data type that is flagged as '1'. Query List: AT!GPSCLRASSIST=? Purpose: Return the expected command format and supported values. <p>Parameters:</p> <p><eph> (Ephemeris assistance data)</p> <ul style="list-style-type: none"> 0=Ignore (Do not clear the ephemeris assistance data) 1=Clear this assistance data type—Clears GPS, GLONASS, and SBAS ephemeris assistance data. <p><alm> (Almanac assistance data)</p> <ul style="list-style-type: none"> 0=Ignore (Do not clear the almanac assistance data) 1=Clear this assistance data type—Clears GPS, GLONASS, and SBAS almanac assistance data. <p><pos> (Position assistance data)</p> <ul style="list-style-type: none"> 0=Ignore (Do not clear the position assistance data) 1=Clear this assistance data type <p><time> (Time reference)</p> <ul style="list-style-type: none"> 0=Ignore (Do not clear the time reference) 1=Clear the time reference <p><iono> (Ionosphere assistance data)</p> <ul style="list-style-type: none"> 0=Ignore (Do not clear the ionosphere assistance data) 1=Clear this assistance data type

Table 8-2: GPS Command Details (Continued)

Command	Description
!GPSCOLDSTART	<p>Clear all GNSS assistance data</p> <p>Clear all GNSS assistance details from the modem and put the modem into a coldstart state. Data cleared includes Almanac, Ephemeris, Previous Position, Ionosphere, and GPS time. This forces a cold start for GPS acquisition the next time a session starts.</p> <p>Requirements:</p> <ul style="list-style-type: none"> • Device must not have an active GPS session (the GPS receiver is off and no position fix is being calculated). <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!GPSCOLDSTART Response: OK Purpose: Clear the modem's GPS details <p>Parameters:</p> <p>None</p>
!GPSEND	<p>End an active session</p> <p>End an active position fix session.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!GPSEND=<sessType> Response: ERRCODE = <value> OK <i>or</i> OK Purpose: End the current session. <p>Parameters:</p> <p><sessType> (Type of session to end)</p> <ul style="list-style-type: none"> • 0=Position fix session <p><value> (Error code returned when command fails for any reason)</p> <ul style="list-style-type: none"> • See Table 8-3 on page 197 for a list of possible error codes.

Table 8-2: GPS Command Details (Continued)

Command	Description
!GPSFIX	<p>Initiate GPS position fix Initiate a GPS position fix.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!GPSFIX=<fixType>, <maxTime>, <maxDist> Response: OK or ERROR CODE = <value> OK Purpose: Initiate a time-limited position fix with a specified accuracy. • Query List: AT!GPSFIX=? Purpose: Return supported <fixType>, <maxTime>, and <maxDist> values. <p>Parameters:</p> <p><fixType> (Type of fix to establish)</p> <ul style="list-style-type: none"> • 1=Standalone (not supported by a mobile station) • 2=MS-based only • 3=MS-assisted only <p><maxTime> (Maximum time to wait for a position fix)</p> <ul style="list-style-type: none"> • Valid range: 1–255 seconds <p><maxDist> (Requested accuracy of fix)</p> <ul style="list-style-type: none"> • Entered in decimal format • Valid range: <ul style="list-style-type: none"> • 1–4294967279 meters • 4294967280=No preference <p><value> (Error code returned when command fails for any reason)</p> <ul style="list-style-type: none"> • See Table 8-3 on page 197 for a list of possible error codes. <p>Example(s): AT!GPSFIX=1, 15, 10 requests a standalone position fix to 10 meters accuracy. The request will fail (timeout) if the modem cannot determine a position fix within 15 seconds.</p> <p>Related commands:</p> <ul style="list-style-type: none"> • IGPSSTATUS (page 187)—Use this command while the tracking session is in progress. • IGPSLOC (page 180)—Use this command after the session completes to obtain the result.

Table 8-2: GPS Command Details (Continued)

Command	Description
!GPSIDREN	<p>Enable/disable "Info for DR" feature Enable or disable the "Info for DR" feature.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!GPSIDREN=<switch> Response: OK or ERROR OK Purpose: Enable or disable the "Info for DR" feature. • Query: AT!GPSIDREN? Response: !GPSIDREN: <switch> Purpose: Return current state of the "Info for DR" feature. • Query List: AT!GPSIDREN=? Purpose: Return supported <switch> values. <p>Parameters:</p> <p><switch> ("Info for DR" feature state)</p> <ul style="list-style-type: none"> • 0—Disabled (Default) • 1—Enabled

Table 8-2: GPS Command Details (Continued)

Command	Description
!GPSLOC	<p>Return last known location of the modem Return the details obtained during the most recent position location session, if available.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Query: AT!GPSLOC? Response: Unknown (<i>No information is available</i>) OK <li style="padding-left: 2em;">or Not Available (<i>No information is available</i>) OK <li style="padding-left: 2em;">or Lat: <latitude> Lon: <longitude> Time: <time> LocUncAngle: <luAngle> LocUncA: <luA> LocUncP: <luP> HEPE: <hepe> <fixType> Altitude: <altitude> LocUncVe: <luV> Heading: <heading> VelHoriz: <vH> VelVert: <vV> OK (<i>Altitude and heading only appear if data was collected as part of the most recent fix.</i>) <p>Purpose: Return last position location details.</p> <p>Parameters:</p> <p><latitude> (Latitude at last position fix)</p> <ul style="list-style-type: none"> • Example: "49 Deg 10 Min 21.49 Sec N (0x008BDE6C)" <p><longitude> (Longitude at last position fix)</p> <ul style="list-style-type: none"> • Example: "123 Deg 4 Min 14.76 Sec W (0xFE1EE9A)" <p><time> (Time at which last position fix was taken)</p> <ul style="list-style-type: none"> • Example: "2009 01 30 4 20:27:18 (GPS)" <p><luAngle> (Location uncertainty angle of returned position)</p> <ul style="list-style-type: none"> • Example: "11.2 deg" <p><luA> (Standard deviation of axis along <luAngle>)</p> <ul style="list-style-type: none"> • Example: "6.0 m" <p><luP> (Standard deviation of axis perpendicular to <luAngle>)</p> <ul style="list-style-type: none"> • Example: "6.0 m" <p><hepe> (Horizontal Estimated Positional Error)</p> <ul style="list-style-type: none"> • Example: "8.485 m" <p><fixType> (2D or 3D fix)</p> <ul style="list-style-type: none"> • Example: "2D Fix" or "3D Fix" <p><altitude> (Altitude in meters at which last position fix was taken)</p> <ul style="list-style-type: none"> • Only present if <fixType> is 3D • Example: "-1 m" <p><luV> (Vertical uncertainty in meters)</p> <ul style="list-style-type: none"> • Only present if <fixType> is 3D • Example: "3.0 m" <p>(Continued on next page)</p>

Table 8-2: GPS Command Details (Continued)

Command	Description
!GPSLOC (continued)	<p>Return last known location of the modem (continued)</p> <p><heading> (Direction of MS)</p> <ul style="list-style-type: none"> • Example: "0.0 deg" <p><vH> (Horizontal velocity)</p> <ul style="list-style-type: none"> • Example: "0.0 m/s" <p><vV> (Vertical velocity)</p> <ul style="list-style-type: none"> • Example: "0.0 m/s"
!GPSMOMETHOD	<p>Set/report GPS MO method</p> <p>Set or report the GPS MO (Mode of Operation).</p> <p>Password required: No Reset required to apply changes: Yes Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!GPSMOMETHOD=<MO_method> Response: OK or ERROR Purpose: Set the specified MO method. • Query: AT!GPSMOMETHOD? Response: <MO_method> OK Purpose: Return the configured MO method. <p>Parameters:</p> <p><MO_method> (Mode of Operation)</p> <ul style="list-style-type: none"> • 0—CP (Control Plane) • 1—UP (User Plane)

Table 8-2: GPS Command Details (Continued)

Command	Description
!GPSMTLRSETTINGS	<p>Set/report MT location request settings</p> <p>Set or report the current MT (mobile-terminated) Location Request settings, which control how the UE responds to network-initiated notifications.</p> <p>Password required: Yes Reset required to apply changes: Yes Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!GPSMTLRSETTINGS=<response> Response: OK or ERROR Purpose: Indicate how MT location request will be handled. • Query: AT!GPSMTLRSETTINGS? Response: Notification Response Setting: <response> OK Purpose: Return the current <response> setting. • Query List: AT!GPSMTLRSETTINGS=? Purpose: Return valid <response> values. <p>Parameters:</p> <p><response> (Notification response setting)</p> <ul style="list-style-type: none"> • 0=Default setting as defined in <i>3GPP specification 29.002</i>, 'NotificationToM-User' enumeration. • 1=Accept all MT location requests. • 2=Reject all MT location requests. • 3=Verify all—User will be asked to accept or reject every MT location request.

Table 8-2: GPS Command Details (Continued)

Command	Description
!GPSNMEACONFIG	<p>Enable/disable NMEA reporting Enable (and configure output rate) or disable NMEA reporting for tracking sessions.</p> <p>Password required: No Reset required to apply changes: Yes Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!GPSNMEACONFIG=<enable>[,<output_rate>] Response: OK or ERROR Purpose: Enable (and set the output rate) or disable NMEA reporting. • Query: AT!GPSNMEACONFIG? Response: Enabled: <enable> Output Rate: <output_rate> OK Purpose: Indicate the current NMEA reporting state. • Query List: AT!GPSNMEACONFIG=? Purpose: Return valid parameter values. <p>Parameters:</p> <p><enable> (NMEA reporting state)</p> <ul style="list-style-type: none"> • 0—Disable • 1—Enable <p><output_rate> (Reporting rate, in seconds)</p> <ul style="list-style-type: none"> • Integer • Valid range: 1–255

Table 8-2: GPS Command Details (Continued)

Command	Description
!GPSNMEASENTENCE	<p>Set/report NMEA sentence type Set or report the current GPS NMEA sentence types.</p> <p>Requirements:</p> <ul style="list-style-type: none"> NMEA streaming must be enabled using !GPSNMEA before using this command. <p>Password required: No Reset required to apply changes: Yes Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT!GPSNMEASENTENCE=<nmea type> Response: OK or ERROR Purpose: Enable or disable NMEA sentence types. Query: AT!GPSNMEASENTENCE? Response: !GPSNMEASENTENCE: <nmea type> OK Purpose: Indicate the currently enabled GPS NMEA sentence types. Query List: AT!GPSNMEASENTENCE=? Purpose: Return valid parameter values. <p>(Continued on next page)</p>

Table 8-2: GPS Command Details (Continued)

Command	Description																																																								
!GPSNMEASENCE (continued)	<p>Set/report NMEA sentence type (continued)</p> <p>Parameters:</p> <p><nmea type> (NMEA sentence types)</p> <ul style="list-style-type: none"> • 2-byte hex format mask (Note: In the execution format, do not include '0x' before the mask value) • Each bit: 0=Disabled; 1=Enabled <table border="1"> <thead> <tr> <th>Bit</th> <th>Description</th> </tr> </thead> <tbody> <tr><td>0</td><td>GPGGA (Fix information)</td></tr> <tr><td>1</td><td>GPRMC (Recommended minimum data for GPS)</td></tr> <tr><td>2</td><td>GPGSV (Detailed satellite data)</td></tr> <tr><td>3</td><td>GPGSA (Overall satellite data)</td></tr> <tr><td>4</td><td>GPVTG (Vector track and speed over the ground)</td></tr> <tr><td>5</td><td>PQXFI (Proprietary Qualcomm eXtended Fix Information)</td></tr> <tr><td>6</td><td>GLGSV (GLONASS GSV)</td></tr> <tr><td>7</td><td>GNGSA (GLONASS GSA)</td></tr> <tr><td>8</td><td>GNGNS (Time, position, fixed related data for GLONASS receiver)</td></tr> <tr><td>9</td><td>GARMC (Galileo RMC)</td></tr> <tr><td>10</td><td>GAGSV (Galileo Satellites in View)</td></tr> <tr><td>11</td><td>GAGSA (Galileo GSA)</td></tr> <tr><td>12</td><td>GAVTG (Galileo VTG)</td></tr> <tr><td>13</td><td>Reserved</td></tr> <tr><td>14</td><td>GSV_EXTENDEd (Enable/disable Extended GGSV)</td></tr> <tr><td>15</td><td>GAGGA (Galileo GGA)</td></tr> <tr><td>16</td><td>PQGSA (Beidou GSA)</td></tr> <tr><td>17</td><td>PQGSV (Beidou GSV)</td></tr> <tr><td>18</td><td>Reserved</td></tr> <tr><td>19</td><td>GAGNS (Galileo new GGA)</td></tr> <tr><td>20</td><td>GPDTM (Datum Reference)</td></tr> <tr><td>21</td><td>GNGGA (GNSS GGA)</td></tr> <tr><td>22</td><td>GNRMC (GNSS RMC)</td></tr> <tr><td>23</td><td>GNTVG (GNSS VTG)</td></tr> <tr><td>24–29</td><td>Reserved</td></tr> <tr><td>30</td><td>GPGLL (Geographic Position)</td></tr> <tr><td>31</td><td>GPGRS (GPS Range Residuals)</td></tr> </tbody> </table>	Bit	Description	0	GPGGA (Fix information)	1	GPRMC (Recommended minimum data for GPS)	2	GPGSV (Detailed satellite data)	3	GPGSA (Overall satellite data)	4	GPVTG (Vector track and speed over the ground)	5	PQXFI (Proprietary Qualcomm eXtended Fix Information)	6	GLGSV (GLONASS GSV)	7	GNGSA (GLONASS GSA)	8	GNGNS (Time, position, fixed related data for GLONASS receiver)	9	GARMC (Galileo RMC)	10	GAGSV (Galileo Satellites in View)	11	GAGSA (Galileo GSA)	12	GAVTG (Galileo VTG)	13	Reserved	14	GSV_EXTENDEd (Enable/disable Extended GGSV)	15	GAGGA (Galileo GGA)	16	PQGSA (Beidou GSA)	17	PQGSV (Beidou GSV)	18	Reserved	19	GAGNS (Galileo new GGA)	20	GPDTM (Datum Reference)	21	GNGGA (GNSS GGA)	22	GNRMC (GNSS RMC)	23	GNTVG (GNSS VTG)	24–29	Reserved	30	GPGLL (Geographic Position)	31	GPGRS (GPS Range Residuals)
Bit	Description																																																								
0	GPGGA (Fix information)																																																								
1	GPRMC (Recommended minimum data for GPS)																																																								
2	GPGSV (Detailed satellite data)																																																								
3	GPGSA (Overall satellite data)																																																								
4	GPVTG (Vector track and speed over the ground)																																																								
5	PQXFI (Proprietary Qualcomm eXtended Fix Information)																																																								
6	GLGSV (GLONASS GSV)																																																								
7	GNGSA (GLONASS GSA)																																																								
8	GNGNS (Time, position, fixed related data for GLONASS receiver)																																																								
9	GARMC (Galileo RMC)																																																								
10	GAGSV (Galileo Satellites in View)																																																								
11	GAGSA (Galileo GSA)																																																								
12	GAVTG (Galileo VTG)																																																								
13	Reserved																																																								
14	GSV_EXTENDEd (Enable/disable Extended GGSV)																																																								
15	GAGGA (Galileo GGA)																																																								
16	PQGSA (Beidou GSA)																																																								
17	PQGSV (Beidou GSV)																																																								
18	Reserved																																																								
19	GAGNS (Galileo new GGA)																																																								
20	GPDTM (Datum Reference)																																																								
21	GNGGA (GNSS GGA)																																																								
22	GNRMC (GNSS RMC)																																																								
23	GNTVG (GNSS VTG)																																																								
24–29	Reserved																																																								
30	GPGLL (Geographic Position)																																																								
31	GPGRS (GPS Range Residuals)																																																								

Table 8-2: GPS Command Details (Continued)

Command	Description
!GPSSATINFO	<p>Request satellite information</p> <p>Return the following information for all satellites in view (including those used in the latest position fix): satellite vehicle number (SV), elevation (ELEV), azimuth (AZI), and signal to noise ratio (SNR).</p> <p>The information returned is valid regardless of the current fix mode or whether the PDE or the modem performs the fix calculations.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Query: AT!GPSSATINFO? Response: NO SAT INFO OK or Satellites in view: <numSats> * SV: <SV 1> ELEV:<ELEV 1> AZI:<AZI 1> SNR:<SNR 1> ... * SV: <SV n> ELEV:<ELEV n> AZI:<AZI n> SNR:<SNR n> OK Purpose: Return the number of satellites in view (including those used in the latest position fix) and details for each satellite (or return an error message). <hr/> <p><i>Note: An asterisk (*) at the beginning of a line indicates the satellite was used in the fix location calculation.</i></p> <hr/> <p>Parameters:</p> <p><numSats> (Number of satellites in view)</p> <ul style="list-style-type: none"> • 1 or more <p><SV n> (Satellite vehicle number for the nth satellite in the list)</p> <ul style="list-style-type: none"> • 1 or more • 1-32—GPS • 65-96—GLONASS • 201-237—Beidou • 301-336—Galileo <p><ELEV n> (Satellite elevation relative to modem location, in degrees)</p> <ul style="list-style-type: none"> • Valid range: 0-90 <p><AZI n> (Satellite azimuth relative to modem location, in degrees)</p> <ul style="list-style-type: none"> • Valid range: 0-360 <p><SNR n> (Signal to noise ratio, in dB)</p> <ul style="list-style-type: none"> • Valid range: 0-99

Table 8-2: GPS Command Details (Continued)

Command	Description
!GPSSTATUS	<p>Request current status of a position fix session Return the current status of a position fix session.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Query: AT!GPSSTATUS? Response: <year> <month> <day> <day of week> <time of day> Last Fix Status = <status> <year> <month> <day> <day of week> <time of day> Fix Session Status = <status> Purpose: Return timestamps and status of a position fix session. <p>Parameters (Timestamp):</p> <p><year></p> <ul style="list-style-type: none"> • Example: "2007" <p><month></p> <ul style="list-style-type: none"> • 01–12 (Jan–Dec) <p><day></p> <ul style="list-style-type: none"> • 01–31 <p><day of week></p> <ul style="list-style-type: none"> • 0–6 (0=Monday) <p><time of day></p> <ul style="list-style-type: none"> • 24-hour clock format • Example: "13:25:48" <p>Parameters (Status):</p> <p><status> (Session status)</p> <ul style="list-style-type: none"> • "NONE": No session of this type has occurred since the modem powered up. <ul style="list-style-type: none"> • The timestamp is the current time. • "ACTIVE": A session of this type is currently active. <ul style="list-style-type: none"> • The timestamp is the time when the session entered this state. • "SUCCESS": The most recent session of this type succeeded. <ul style="list-style-type: none"> • The timestamp is the time when the previous session completed successfully. • "FAIL": The most recent session of this type failed. <ul style="list-style-type: none"> • The timestamp is the time when the previous session failed. • An error code is displayed with the "FAIL" string. See Table 8-3 on page 197 for a list of error codes. <p>Example(s): AT!GPSSTATUS? returns: 2007 01 06 6 00:25:01 Last Fix Status = SUCCESS 2007 01 06 6 00:25:02 Fix Session Status = ACTIVE</p>

Table 8-2: GPS Command Details (Continued)

Command	Description
!GPSSUPLURL	<p>Set/report SUPL server URL</p> <p>Set or return the URL and port of the SUPL server to be used when TCP/IP is used as the transport mechanism for location processing.</p> <p>Password required: Yes (see !ENTERCND for details)</p> <p>Reset required to apply changes: Yes</p> <p>Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!GPSSUPLURL="<suplURL>"[:<port ID>] Response: OK or ERROR Purpose: Identify the SUPL server URL. • Query: AT!GPSSUPLURL? Response: <suplURL> OK Purpose: Return the SUPL server's URL.. • Query List: AT!GPSSUPLURL=? Purpose: Return the execution command format. <p>Parameters:</p> <p><suplURL> (SUPL server URL)</p> <ul style="list-style-type: none"> • Must be a fully qualified domain name (FQDN) or address • Examples: "supl.url.net", "123.123.123.123" • The <suplURL> is not checked for correctness—if the string is invalid, the modem will not be able to perform MS-assisted GPS fixes. <p><port ID> (Port ID to use over TCP/IP)</p> <ul style="list-style-type: none"> • Valid range: 0–65535 <p>Example(s):</p> <pre>AT!GPSSUPLURL="supl.url.net" AT!GPSSUPLURL="123.123.123.123" AT!GPSSUPLURL="123.123.123.123":17432</pre>

Table 8-2: GPS Command Details (Continued)

Command	Description
!GPSSUPLVER	<p>Set/report SUPL server version Set or return the version of the SUPL server.</p> <p>Password required: No Reset required to apply changes: Yes Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!GPSSUPLVER=<supl ver> Response: OK or ERROR Purpose: Identify the SUPL server version. • Query: AT!GPSSUPLVER? Response: <supl ver> OK Purpose: Return the SUPL server's version. • Query List: AT!GPSSUPLVER=? Purpose: Return the execution command format. <p>Parameters:</p> <p><supl ver> (SUPL server version)</p> <ul style="list-style-type: none"> • 1—SUPL version 1 • 2—SUPL version 2

Table 8-2: GPS Command Details (Continued)

Command	Description
!GPSTRACK	<p>Initiate local tracking (multiple fix) session</p> <p>Initiate a local tracking session comprising a specific number of position fixes taken at regular time intervals.</p> <p>Password required: No Reset required to apply changes: No Persistent across power cycles: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!GPSTRACK = <fixType>, <maxTime>, <maxDist>, <fixCount>, <fixRate> Response: OK or ERROR CODE = <value> OK Purpose: Initiate a series of time-limited position fixes. • Query List: AT!GPSTRACK=? Purpose: Return supported <fixType>, <maxTime>, <maxDist>, <fixCount>, and <fixRate> values. <p>Parameters:</p> <p><fixType> (Type of fix to establish)</p> <ul style="list-style-type: none"> • 1=Standalone (not supported by a mobile station) • 2=MS-based only • 3=MS-assisted only <p><maxTime> (Maximum time to wait for satellite information)</p> <ul style="list-style-type: none"> • Valid range: 1–255 seconds <p><maxDist> (Requested accuracy of fix)</p> <ul style="list-style-type: none"> • Entered in decimal format • Valid range: <ul style="list-style-type: none"> • 1–4294967279 meters • 4294967280=No preference <p><fixCount> (Number of position fixes requested)</p> <ul style="list-style-type: none"> • Valid range: 1–1000 (1000—Take a continuous series of position fixes) <p><fixrate> (Amount of time to wait between fix attempts)</p> <ul style="list-style-type: none"> • Valid range: 1–65535 seconds <p>Failure conditions:</p> <p>The request fails if the tracking session fails to initiate.</p> <p>If the request fails, the message ERROR CODE = <value> is returned. See Table 8-3 on page 197 for a list of error codes.</p> <hr/> <p><i>Note: The 'time to first fix' may require more time than subsequent fixes, if almanac, ephemeris, or location data needs to be updated. (Almanac data is valid for 3–4 days, ephemeris for 30–120 minutes, and location data for 4 minutes). To avoid a timeout error (time spent > <maxtime>), your application could precede the !GPSTRACK call with a single position fix (AGPSFIX) with a greater <maxTime> value.</i></p> <hr/> <p>(Continued on next page)</p>

Table 8-2: GPS Command Details (Continued)

Command	Description
!GPSTRACK (continued)	<p>Initiate local tracking (multiple fix) session (continued)</p> <p>Example(s): AT!GPSTRACK=1, 15, 10, 20, 60 requests a series of 20 standalone position fixes to 10 meters accuracy — fixes are taken every 60 seconds. One of the following responses will be received:</p> <ul style="list-style-type: none"> • “OK” if the request is successful, or • “ERROR CODE = <value>” if the request fails for any reason. See Table 8-3 on page 197 for a list of error codes. <p>Related commands:</p> <ul style="list-style-type: none"> • IGPSSTATUS—Use this command while the tracking session is in progress. • IGPSLOC—Use this command after the session completes to obtain the result.
!GPSTRANSSEC	<p>Control GPS transport security</p> <p>Enable or disable GPS transport security for SUPL GPS fixes.</p> <p>Password required: Yes (see !ENTERCND for details) Reset required to apply changes: Yes Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!GPSTRANSSEC=<security> Response: OK or ERROR Purpose: Indicate if transport security is used. • Query: AT!GPSTRANSSEC? Response: Transport security: <security> OK Purpose: Return the current <security> setting. • Query List: AT!GPSTRANSSEC=? Purpose: Display the command format and valid parameter options. <p>Parameters:</p> <p><security> (Transport security state)</p> <ul style="list-style-type: none"> • Bit mask: <ul style="list-style-type: none"> • Bit 0: 0=Disabled (No security); 1=Enabled (Security) • Bit 1: 0=SSL Version TLS 1.1; 1=SSL Version TLS 1.0 • Bit 2: 0=SHA256; 1=SHA1

Table 8-2: GPS Command Details (Continued)

Command	Description
!GPSXTRADATAENABLE	<p>Set/report GPS XTRA settings Enable or disable XTRA data and set or report XTRA data configuration settings.</p> <p>Password required: Yes (see !ENTERCND for details) Reset required to apply changes: Yes Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!GPSXTRADATAENABLE= <enable>[,<retries>,<retryInt>[,<dload>,<dloadInt>[,<validityTime>]]] Response: OK or ERROR Purpose: Enable or disable XTRA data. You can set the retry parameters only if <enable> = 2, and you can set the download parameters only if the retry parameters are set. • Query: AT!GPSXTRADATAENABLE? Response: XTRA Data Enabled: <enable> XTRA Data Retry Number: <retries> XTRA Data Retry Interval: <retryInt> XTRA Data Autodownload Enabled: <dload> XTRA Data Autodownload Interval: <dloadInt> XTRA Data Validity Time: <validityTime> Purpose: Return the current GPS XTRA data settings. • Query List: AT!GPSXTRADATAENABLE=? Purpose: Display the command format and valid parameter options. <p>Parameters:</p> <p><enable> (Enable or disable XTRA data information)</p> <ul style="list-style-type: none"> • 0=Disable. To fully disable XTRA, !GPSXTRATIMEENABLE=0 must also be called to disable XTRA time functionality. • 1=Reserved • 2=Enable XTRA data information <p><retries> (Number of download retries)</p> <ul style="list-style-type: none"> • Valid range: 0–10 <p><retryInt> (Interval between download retries, in minutes)</p> <ul style="list-style-type: none"> • Valid range: 1–120 <p><dload> (Enable or disable automatic downloads)</p> <ul style="list-style-type: none"> • 0=Disable • 1=Enable <p><dloadInt> (Interval between automatic downloads, in hours)</p> <ul style="list-style-type: none"> • Valid range: 24–168 • Note: If <dload> is 0 (disable), a value must still be entered for the interval (although it will not be used) <p><validityTime> (Length of time that XTRA data is considered to be valid, in hours)</p> <ul style="list-style-type: none"> • Valid range: 1–168

Table 8-2: GPS Command Details (Continued)

Command	Description
!GPSXTRADATAURL	<p>Set/report GPS XTRA data server URLs Set or report the URLs of up to three GPS XTRA data servers.</p> <p>Password required: Yes (see !ENTERCND for details) Reset required to apply changes: Yes Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!GPSXTRADATAURL=<urlIndex>,<url> Response: OK <i>or</i> ERROR Purpose: Set the URL used for the primary, secondary, or tertiary data server. • Query: AT!GPSXTRADATAURL? Response: XTRA Primary Server: <url1> XTRA Secondary Server: <url2> XTRA Tertiary Server: <url3> OK Purpose: Return the URLs of the primary, secondary, and tertiary data servers. <p>Parameters:</p> <p><urlIndex> (Server index)</p> <ul style="list-style-type: none"> • 1=Primary server • 2=Secondary server • 3=Tertiary server <p><url> (Server URL)</p> <ul style="list-style-type: none"> • URL string includes quotes • Example: "http://xtra1.gpsoneextra.net/xtra.bin" • URL must be complete, including the "http://" • Maximum string length: 128 characters

Table 8-2: GPS Command Details (Continued)

Command	Description
!GPSXTRASTATUS	<p>Return current status of XTRA</p> <p>Return the status of the most recent time and data injection operations.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Query: AT!GPSXTRASTATUS? Response: Xtra Time status = <timeStatus> Xtra Data status = <dataStatus> Validity Start = <timeStamp> Validity End = <timeStamp> OK Purpose: Return the status of the most recent time and data injection operations. <p>Parameters:</p> <p><timeStatus></p> <ul style="list-style-type: none"> • Returned string does not include quotes (they are used in this description for clarity). • “Unknown”: Default value if time injection operation has not been performed yet, or if operation was incomplete • “Valid”: GPS time injection succeeded • “Invalid”: GPS time injection failed <p><dataStatus></p> <ul style="list-style-type: none"> • Returned string does not include quotes (they are used in this description for clarity). • “Unknown”: Default value if data injection operation has not been performed yet, or if operation was incomplete • “Valid”: GPS data injection succeeded • “Invalid”: GPS data injection failed • “xtra.bin file has bad crc” • “GPS Busy, end current session first” • “error reading xtra.bin file” • “bad TOA in xtra.bin file”: The XTRA data retrieved from the XTRA server is too old (exceeds the Time Of Applicability). <p><timeStamp> (GPS time stamp)</p> <ul style="list-style-type: none"> • Format: <year> <month> <day> <dayOfWeek> <time> • <year>: 4 digits (Example: 2008) • <month>: 2 digits (01–12) • <day>: 2 digits (01–31) • <dayOfWeek>: 1 digit (0–6) where 0=Monday • <time>: time of day (Example: 13:15:45) • Example: 2008 02 28 5 13:15:45 represents Thursday 28 Feb 2008 at 1:15:45 PM

Table 8-2: GPS Command Details (Continued)

Command	Description
!GPSXTRATIME	<p>Inject GPS or UTC time into XTRA system Inject the GPS or UTC time into the XTRA system.</p> <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!GPSXTRATIME=<YYYY>, <MM>, <DD>, <hh>, <mm>, <ss>, <utc>, <force>, <uncrtn> Response: OK or Error code = <err> OK Purpose: Inject the specified date and time into the XTRA system. If the command fails, it returns "Error code = <err>". • Query List: AT!GPSXTRATIME=? Purpose: Return supported parameter values. <p>Parameters:</p> <p><YYYY> (Year)</p> <ul style="list-style-type: none"> • 4 digits required <p><MM> (Month)</p> <ul style="list-style-type: none"> • Valid range: 1–12 <p><DD> (Day)</p> <ul style="list-style-type: none"> • Valid range: 1–31 <p><hh> (Hour)</p> <ul style="list-style-type: none"> • Valid range: 0-23 <p><mm> (Minute)</p> <ul style="list-style-type: none"> • Valid range: 0–59 <p><ss> (Second)</p> <ul style="list-style-type: none"> • Valid range: 0–59 <p><utc> (Flag indicating time type)</p> <ul style="list-style-type: none"> • 0=GPS time • 1=UTC time <p><force> (Force or allow GPS subsystem to decide to accept the time entered)</p> <ul style="list-style-type: none"> • 0=Do not force acceptance • 1=Force acceptance <p><err> (Error code returned if command fails)</p> <ul style="list-style-type: none"> • 3=Bad CRC for XTRA data file • 4=Old XTRA data file • 7=GPS subsystem busy • 8=GPS time reference entered is invalid • 9=Unknown error

Table 8-2: GPS Command Details (Continued)

Command	Description
!GPSXTRATIMEENABLE	<p>Set/report GPS XTRA time settings Enable or disable XTRA time information, and set or report specific XTRA time settings.</p> <p>Password required: Yes (see !ENTERCND for details) Reset required to apply changes: Yes Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!GPSXTRATIMEENABLE=<enable> [<thresh>, <delay>] Response: OK or ERROR Purpose: Enable or disable time information. If enabled, sets the uncertainty threshold and delay time to retry with a backup server. • Query: AT!GPSXTRATIMEENABLE? Response: XTRA Time Info Enabled: <enable> XTRA Time Uncertainty Threshold: <thresh> XTRA Time Delay Threshold: <delay> Purpose: Return the current values of GPS XTRA time parameters. • Query List: AT!GPSXTRATIMEENABLE=? Purpose: Return supported execution parameter values. <p>Parameters:</p> <p><enable> (Enable or disable XTRA time information)</p> <ul style="list-style-type: none"> • 0=Disable. To fully disable XTRA, you must also call !GPSXTRADATAENABLE=0 to disable XTRA data information. • 1=Reserved • 2=Enable XTRA time information <p><thresh> (XTRA time uncertainty threshold, in ms)</p> <ul style="list-style-type: none"> • Valid range: 100–30000 <p><delay> (Time to delay before retrying with backup server, in ms)</p> <ul style="list-style-type: none"> • Valid range: 100–10000

Table 8-2: GPS Command Details (Continued)

Command	Description
!GPSXTRATIMEURL	<p>Set/report GPS XTRA SNTP server URLs</p> <p>Set or report the URLs of up to three GPS XTRA SNTP (Simple Network Time Protocol) servers.</p> <p>Password required: Yes (see !ENTERCND for details)</p> <p>Reset required to apply changes: Yes</p> <p>Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!GPSXTRATIMEURL=<urlIndex>,<url> Response: OK or ERROR Purpose: Set the URL used for the primary, secondary, or tertiary data server. • Query: AT!GPSXTRATIMEURL? Response: XTRA SNTP Primary Server: <url 1> XTRA SNTP Secondary Server: <url 2> XTRA SNTP Tertiary Server: <url 3> Purpose: Return the URLs of the primary, secondary, and tertiary SNTP servers. <p>Parameters:</p> <p><urlIndex> (Server index)</p> <ul style="list-style-type: none"> • 1=Primary server • 2=Secondary server • 3=Tertiary server <p><url> (Server URL)</p> <ul style="list-style-type: none"> • URL string includes quotes • Example: "xtra1.gpsoneextra.net" • Maximum string length=128 characters

Error codes

[Table 8-3](#) describes error codes that can be returned by [!GPSEND](#) ([page 177](#)), [!GPSSTATUS](#) ([page 187](#)), and [!GPSTRACK](#) ([page 190](#)).

[Table 8-4](#) on [page 198](#) describes error codes that can be returned by [!GPSFIX](#) ([page 178](#)).

Table 8-3: AT Command Error Codes (!GPSEND, !GPSSTATUS, !GPSTRACK)

Error code	Description
0	Phone is offline
1	No service
2	No connection with PDE (Position Determining Entity)
3	No data available
4	Session Manager is busy
5	Reserved
6	Phone is GPS-locked

Table 8-3: AT Command Error Codes (!GPSEND, !GPSSTATUS, !GPSTRACK) (Continued)

Error code	Description
7	Connection failure with PDE
8	Session ended because of error condition
9	User ended the session
10	End key pressed from UI
11	Network session was ended
12	Timeout (for GPS search)
13	Conflicting request for session and level of privacy
14	Could not connect to the network
15	Error in fix
16	Reject from PDE
17	GPS is disabled
18	Ending session due to E911 call
19	Server error
20	Reserved
21	Reserved
22	Unknown system error
23	Unsupported service
24	Subscription violation
25	Desired fix method failed
26	Reserved
27	No fix reported because no Tx confirmation was received
28	Network indicated normal end of session
29	No error specified by the network
30	No resources left on the network
31	Position server not available
32	Network reported an unsupported version of protocol

Table 8-4: AT Command Error Codes (!GPSFIX)

Error code	Description
0	No error
1	Invalid client ID

Table 8-4: AT Command Error Codes (!GPSFIX) (Continued)

Error code	Description
2	Bad service parameter
3	Bad session type parameter
4	Incorrect privacy parameter
5	Incorrect download parameter
6	Incorrect network access parameter
7	Incorrect operation parameter
8	Incorrect number of fixes parameter
9	Incorrect server information parameter
10	Error in timeout parameter
11	Error in QOS accuracy threshold parameter
12	No active session to terminate
13	Session is active
14	Session is busy
15	Phone is offline
16	Phone is CDMA locked
17	GPS is locked
18	Command is invalid in current state
19	Connection failure with PDE
20	PDSM command buffer unavailable to queue command
21	Search communication problem
22	Temporary problem reporting position determination results
23	Error mode not supported
24	Periodic NI in progress
25	Unknown error
26	Unknown error

>> 9: SIM Commands

Introduction

This chapter describes commands used to communicate with an installed SIM.

Command summary

[Table 9-1](#) lists the commands described in this chapter:

Table 9-1: SIM Commands

Command	Description	Page
+CCID	Return SIM/eUICC ICCID and EID	201
+CCID (notification)	eUICC profile switch—Unsolicited notification	201
+CSPN	Display SIM card service provider's name (SPN)	202
!ICCID	Return SIM card's ICCID	202
+KSIMSEL	Select External SIM interface	203
!UIMS	Select active UIM interface	204

Command reference

Table 9-2: SIM Command Details

Command	Description
+CCID	<p>Return SIM/eUICC ICCID and EID</p> <p>Return the active SIM's ICCID and (if it is an eUICC) its EID, and enable/disable unsolicited notifications of eUICC profile switches.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT+CCID=<notifications> Response: +CCID: <iccid>[,<eid>] OK Purpose: Enable/disable unsolicited notifications for eUICC profile switches. Query: AT+CCID? or AT+CCID Response: +CCID: <iccid>[,<eid>] OK or +CME ERROR: <error> Purpose: Display the ICCID of the active SIM and, if the SIM is an eUICC, display its EID (eUICC-ID). <p>Parameters:</p> <p><notifications> (Unsolicited notifications):</p> <ul style="list-style-type: none"> 0—Disable eUICC profile switch unsolicited notifications 1—Enable eUICC profile switch unsolicited notifications (default) See +CCID (notification) on page 201 for details. <p><iccid> (ICCID of the SIM/eUICC currently being tested):</p> <ul style="list-style-type: none"> 20 digit decimal number—This number is often printed on the SIM card. <p><eid> (eUICC ID):</p> <ul style="list-style-type: none"> Appears in response only if SIM is an eUICC 32 digit decimal number
+CCID (notification)	<p>eUICC profile switch—Unsolicited notification</p> <p>Unsolicited notification indicating the eUICC profile has been switched.</p> <p>To enable/disable this notification, use AT+CCID. See +CCID on page 201 for details.</p> <p>Notification format:</p> <p>+CCID: <new_iccid></p> <p>Examples:</p> <ul style="list-style-type: none"> Notifications received: +CCID: 89019990001234567026 ICCID of the new profile <p>Parameters:</p> <p><new_iccid> (ICCID of the new profile)</p> <ul style="list-style-type: none"> 20 digit decimal number—This number is often printed on the SIM card.

Table 9-2: SIM Command Details (Continued)

Command	Description
+CSPN	<p>Display SIM card service provider's name (SPN) Display the service provider name for the SIM card. Password required: No</p> <p>Usage: (Note: Execution and Query formats return the same response.)</p> <ul style="list-style-type: none"> • Execution: <ul style="list-style-type: none"> AT+CSPN Response: +CSPN: <spn> OK or +ERROR Purpose: Display the SIM card's service provider name. • Query: <ul style="list-style-type: none"> AT+CSPN? Response: +CSPN: <spn> OK or +ERROR Purpose: Display the SIM card's service provider name. • Query List: AT+CSPN=? <ul style="list-style-type: none"> Response: OK Purpose: None. <p>Parameters: <spn> (Service provider name):</p> <ul style="list-style-type: none"> • ASCII string enclosed within quotes.
!ICCID	<p>Return SIM card's ICCID Return a SIM's ICCID (Integrated Circuit Card ID). Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Query: <ul style="list-style-type: none"> !ICCID? Response: !ICCID: <iccid> OK Purpose: Display the ICCID. <p>Parameters: <iccid> (ICCID of the SIM currently being tested):</p> <ul style="list-style-type: none"> • 20 digit decimal number—This number is often printed on the SIM card.

Table 9-2: SIM Command Details (Continued)

Command	Description
+KSIMSEL	<p>Select External SIM interface</p> <p>Select the external SIM slot that will be controlled via GPIO6. This command is for use with hardware designs with an external SIM multiplexer connected to the module's UIM1 interface.</p> <p>Password required: No</p> <p>Reset required to apply changes: No</p> <p>Persistent across power cycles: Yes</p> <p>Requirements:</p> <ul style="list-style-type: none"> The fast SIM switch feature must be enabled using the !CUSTOM EXTUIMSWITCHEN customization before +KSIMSEL can be used. See !CUSTOM on page 48. <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT+KSIMSEL=<sim_slot> Response: OK Purpose: Set the active external SIM interface. Query: AT+KSIMSEL? Response:! +KSIMSEL: <sim_slot> OK Purpose: Indicate the active external SIM interface. Query list: AT+KSIMSEL=? Purpose: Return a list of supported <sim_slot> values. <p>Parameters:</p> <p><sim_slot> (External SIM being used)</p> <ul style="list-style-type: none"> 0—(Query only) External SIM select feature disabled. This value is returned when the !CUSTOM EXTUIMSWITCHEN customization is 0. 1—External SIM slot 1 (GPIO6 low) 2—External SIM slot 2 (GPIO6 high)

Table 9-2: SIM Command Details (Continued)

Command	Description
!UIMS	<p>Select active UIM interface</p> <p>On a module that supports multiple UIM interfaces, select the active UIM interface.</p> <p>Password required: No</p> <p>Persistent across power cycles: Yes, unless overridden by !CUSTOM="UIMAUTOSWITCH", which, when enabled, sets the preferred UIM interface when the module boots.</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!UIMS=<uim> Response: OK Purpose: Configure the module to use the selected UIM interface. • Query: AT!UIMS? Response: !UIMS: <uim>[,<used uim>] OK Purpose: Display the currently selected interface. • Query List: AT!UIMS=? Purpose: Return the command format and the supported parameter values. <p>Parameters:</p> <p><uim> (SIM interface):</p> <ul style="list-style-type: none"> • 0—UIM1. External UIM interface #1 • 1—UIM2. eSIM (embedded SIM) • 2—Reserved. Do not use. • 3—Auto-SIM-Switch activated. Refer to !CUSTOM="UIMAUTOSWITCH" for details. <p><used uim> (UIM slot used when Auto-SIM-Switch is activated):</p> <ul style="list-style-type: none"> • 0—UIM1. External UIM interface #1 • 1—UIM2. eSIM (embedded SIM)

>> 10: SD Commands

Introduction

This chapter describes commands used to communicate with an installed SD card.

Command summary

[Table 10-1](#) lists the commands described in this chapter:

Table 10-1: SD Commands

Command	Description	Page
!SDINFO	Display SD card status	206

Command reference

Table 10-2: SD Command Details

Command	Description
!SDINFO	<p>Display SD card status</p> <p>Check whether an SD card is present or not.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none">• Execution: ATISDINFO <p>Response: !SDINFO: Card is Present OK</p> <p>or</p> <p>!SDINFO: Card is not present OK</p> <p>Purpose: Check whether an SD card is present.</p> <p>Parameters: None</p>

>> 11: OMA-DM Commands

Introduction

Note: The commands in this chapter are provided to satisfy AT&T carrier requirements.

This chapter describes commands used to configure DM (Device Management) accounts, sessions, and host–device–server interactions.

Command summary

The table below lists the commands described in this chapter.

Table 11-1: OMA-DM Commands

Command	Description	Page
!IDSDEBUGPRINT	Enable/disable debug (detailed message) printing	207
!IMSTESTMODE	Enable/disable IMS test mode	208

Command reference

Table 11-2: OMA-DM Command Details

Command	Description
!IDSDEBUGPRINT	<p>Enable/disable debug (detailed message) printing</p> <p>Enable/disable the printing of all transmitted and received HTTP traffic to the AT command port during a session with a DM server (typically for debugging purposes).</p> <p>Password required: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!IDSDEBUGPRINT=<enable> Response: OK or ERROR Purpose: Enable or disable printing of HTTP traffic to AT the AT command port. • Query List: AT!IDSDEBUGPRINT=? Purpose: Display the execution command format and parameter values. <p>Parameters:</p> <p><enable> (Enable/disable debug printing)</p> <ul style="list-style-type: none"> • 0—Disable debug printing to AT command port • 1—Enable debug printing to AT command port

Table 11-2: OMA-DM Command Details (Continued)

Command	Description
!IMSTESTMODE	<p>Enable/disable IMS test mode</p> <p>Enable/disable IMS (IP Multimedia Subsystem) test mode.</p> <p>If IMS test mode is enabled:</p> <ul style="list-style-type: none"> • IMS registration attempts will not occur • SMS over IMS is not supported <p>Password required: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!IMSTESTMODE=<mode> Response: OK Purpose: Enable/disable IMS test mode. • Query: AT!IMSTESTMODE? Response: IMS Test Mode Enabled or IMS Test Mode Disabled Purpose: Return the current state of IMS Test Mode. <p>Parameters:</p> <p><mode> (IMS Test Mode state)</p> <ul style="list-style-type: none"> • 0=Disable • 1=Enable

>> 12: SAR Backoff Commands

Introduction

This chapter describes:

- SAR-related commands (Specific Absorption Rate) — SAR commands are used to meet regulatory requirements for the OEM host device by managing the modem's SAR backoff state. OEMs should carefully evaluate their use of these commands and their impact on device operation.

Note: Operators may require OEMs to disclose SAR settings and theory of operation for applicable certifications.

Command summary

The table below lists the commands described in this chapter.

Table 12-1: SAR Backoff and Thermal Control Commands

Command	Description	Page
+KRFMUTE	Enable/disable RAT-specific Tx muting	210
+KRFMUTE (notification)	RAT Tx mute mode status change (unsolicited notification)	211
!MAXPWR	Set/report maximum Tx power	212
!SARBACKOFF	Set/report offset from maximum Tx power	214
!SARGPIO	Set/report External GPIO controlling SAR	217
!SARINTGPIOMODE	Set/report default pull mode for SAR interrupt GPIOs	218
!SARSTATE	Set/report SAR backoff state	218
!SARSTATEDFLT	Set/report default SAR backoff state	219

Command reference

Table 12-2: SAR Backoff and Thermal Control Command Details

Command	Description
+KRFMUTE	<p>Enable/disable RAT-specific Tx muting</p> <p>Enable or disable RF Tx muting a combination of RATs for a specific duration, and enable/disable unsolicited notifications for this command.</p> <p>If enabled, unsolicited notifications (+KRFMUTE (notification)) will be received when:</p> <ul style="list-style-type: none"> The mute duration is enabled or expired. This command is used to disable RF Tx muting while Tx muting is in progress (that is, sometime during the mute duration). <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT+KRFMUTE=<mode>[,<duration>[,<indication>]] Response: OK Purpose: Enable or disable Tx muting for the RATs specified by the <mode>. Query: AT+KRFMUTE? Response: +KRFMUTE: <mode>,<duration>,<indication> OK Purpose: Display the current RF Tx mute state. Query list: AT+KRFMUTE=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><mode> (RF mute mode)</p> <ul style="list-style-type: none"> 0 (Default)—Disable 1—Mute GSM only 2—Mute UMTS only 3—Mute GSM and UMTS 4—Mute LTE only 5—Mute GSM and LTE 6—Mute UMTS and LTE 7—Mute GSM, UMTS, and LTE <p><duration> (Mute duration in seconds)</p> <ul style="list-style-type: none"> 0.5—120 Default: 30.0 <p><indication> (Enable/disable mute mode unsolicited notifications)</p> <ul style="list-style-type: none"> 0 (Default)—Disable 1—Enable

Table 12-2: SAR Backoff and Thermal Control Command Details (Continued)

Command	Description
+KRFMUTE (notification)	<p>RAT Tx mute mode status change (unsolicited notification)</p> <p>Notification received when RAT Tx mute mode is enabled, expires, or is disabled while in progress.</p> <hr/> <p><i>Note: This notification is enabled/disabled using +KRFMUTE.</i></p> <hr/> <p>Usage:</p> <ul style="list-style-type: none"> Notification: +KRFMUTE: <mode>[,<duration>] Purpose: Indicates RAT Tx muting has begun (been enabled) or stopped (mute period expired, or muting disabled). <p>Parameters:</p> <p><mode> (RF mute mode)</p> <ul style="list-style-type: none"> 0 (Default)—Disable 1—Mute GSM only 2—Mute UMTS only 3—Mute GSM and UMTS 4—Mute LTE only 5—Mute GSM and LTE 6—Mute UMTS and LTE 7—Mute GSM, UMTS, and LTE <p><duration> (Mute duration in seconds)</p> <ul style="list-style-type: none"> 0.5—120 This parameter is included when mute is enabled. If mute is disabled/expired, this parameter does not appear. <p>Examples:</p> <ul style="list-style-type: none"> Notification received when RAT Tx mute is set to Enabled: +KRFMUTE: 1, 30.0 Notification received when RAT Tx mute is expired, or is disabled while in progress: +KRFMUTE: 0

Table 12-2: SAR Backoff and Thermal Control Command Details (Continued)

Command	Description
!MAXPWR	<p>Set/report maximum Tx power Set or report the maximum Tx power for a specific technology/band combination.</p> <hr/> <p>Caution: Any adjustments of Tx power may impact regulatory certification of the module in the host platform. The OEM is responsible for ensuring that the final module configuration in the host platform meets all regulatory requirements.</p> <hr/> <p><i>Note:</i> Increasing Tx power affects the module’s current consumption and thermal performance.</p> <hr/> <p>Password required: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution (WCDMA/LTE): AT!MAXPWR=<band>,<tech>,<max_tx_pwr> Response: OK Purpose: Set the maximum Tx power for the specified technology/band combination. • Execution (CDMA): AT!MAXPWR=<band>,<tech>,<temperature_bin>,<max_tx_pwr> Response: OK Purpose: Set the maximum Tx power for the specified technology/band/temperature bin combination. • Query (WCDMA/LTE): AT!MAXPWR?<band>,<tech> Response: <max_tx_pwr> dBm OK Purpose: Indicate the maximum Tx power for the specified technology/band combination. • Query (CDMA): AT!MAXPWR?<band>,<tech> Response: Max Tx value for temperature bin 0 = <Max Tx power> dBm ... Max Tx value for temperature bin 7 = <Max Tx power> dBm OK Purpose: For the specified tech/band combination, display the offset from maximum Tx power for the tech/band combination and the SAR limits for each temperature bin. (For ‘bin’ definition, see <temperature_bin> description.) <p>Continued on next page)</p>

Table 12-2: SAR Backoff and Thermal Control Command Details (Continued)

Command	Description
!MAXPWR (continued)	<p>Set/report maximum Tx power (continued)</p> <ul style="list-style-type: none"> Query list: AT!MAXPWR=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><band> (RF band)</p> <ul style="list-style-type: none"> 3GPP band number. For a full listing of 3GPP band numbers, see Table 18-2 on page 290. Band support is product specific—see the device's Product Specification or Product Technical Specification document for details. Valid range: 0–88 <p>(<tech> (Network technology))</p> <ul style="list-style-type: none"> 0=WCDMA 1=CDMA 2=LTE <p><temperature_bin> (Temperature bin identifier. CDMA only)</p> <ul style="list-style-type: none"> Valid range: 0–7 The module has minimum and maximum operating temperature thresholds and throughout the temperature range, eight different temperatures are defined during calibration and stored as temperature bins. Temperature values stored correspond to bin boundaries, which map to seven temperature ranges. <p><max_tx_pwr> (Maximum Tx power in dB)</p> <ul style="list-style-type: none"> Valid range: 20.0–24.5

Table 12-2: SAR Backoff and Thermal Control Command Details (Continued)

Command	Description
!SARBACKOFF	<p>Set/report offset from maximum Tx power</p> <p>Set or report the offset from maximum Tx power limit for a specific technology/band combination. Changes take place after the next modem reset.</p> <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution (WCDMA, CDMA, LTE): ATISARBACKOFF=<Technology>,<Band>,<State>,<Backoff offset> Response: OK Purpose: Set the maximum Tx power for the tech/band/state combination. • Execution (GSM): ATISARBACKOFF=<Technology>,<Band>,<Slot>,<State>,<Modulation>,<Backoff offset> Response: OK Purpose: Set the maximum Tx power for the tech/band/state combination. • Query (WCDMA, LTE): ATISARBACKOFF?<Technology>,<Band>,<State> Response: SAR Backoff: <offset> dBm SAR Limit: <SAR limit> dBm <i>or</i> NV Not Set OK Purpose: For the specified tech/band/state combination, display the offset from maximum Tx power and the SAR limit. <p>(Continued on next page)</p>

Table 12-2: SAR Backoff and Thermal Control Command Details (Continued)

Command	Description
!SARBACKOFF (continued)	<p>Set/report offset from maximum Tx power (continued)</p> <ul style="list-style-type: none"> • Query (CDMA): ATISARBACKOFF?<Technology>,<Band>,<State> Response: SAR Backoff: <offset> dBm Max Tx value for temperature bin 0 = <SAR limit> dBm ... Max Tx value for temperature bin 7 = <SAR limit> dBm <i>or</i> NV Not Set OK Purpose: For the specified tech/band/state combination, display the offset from maximum Tx power for the tech/band/state combination and the SAR limits for each temperature bin. (For 'bin' definition, see <temperature_bin> in IMAXPWR.) • Query (GSM): ATISARBACKOFF?<Technology>,<Band>,<Slot>,<State>,<Modulation> Response: SAR Backoff: <offset> dBm SAR Limit: <SAR limit> dBm <i>or</i> NV Not Set OK Purpose: For the specified tech/band/slot/state/modulation combination, display the offset from maximum Tx power and the SAR limit. • Query list: ATISARBACKOFF=?<Technology> Purpose: Display valid execution format and parameter values for LTE/WCDMA/CDMA and GSM queries. <p>Parameters:</p> <p><Technology> (Network technology)</p> <ul style="list-style-type: none"> • 0=WCDMA • 1=CDMA • 2=LTE • 3=GSM <p><Band> (RF band)</p> <ul style="list-style-type: none"> • Valid values (Absolute ranges shown below for convenience. Use the Query list format to display full details.): <ul style="list-style-type: none"> • LTE: 1–41 • WCDMA: 1–19 • GSM: 0–3 • CDMA: 0–15 • Band support is device-dependent. See the device's Product Technical Specification for details. <p><Slot> (Tx slot. GSM only)</p> <ul style="list-style-type: none"> • 1–5 <p>(Continued on next page)</p>

Table 12-2: SAR Backoff and Thermal Control Command Details (Continued)

Command	Description
!SARBACKOFF (continued)	<p>Set/report offset from maximum Tx power (continued)</p> <p><State> (SAR backoff state)</p> <ul style="list-style-type: none"> • 0=No backoff • 1–8=Backoff state 1 to 8 <p><Modulation> (Modulation method. GSM only.)</p> <ul style="list-style-type: none"> • 0=GMSK (GPRS) • 1=8PSK (EDGE) <p><Backoff offset> (Offset from max Tx power, in dBm)</p> <ul style="list-style-type: none"> • Valid values: use the Query List command to display valid values. • Value may be integer or decimal. (For example, “4” or “6.8”) <p><SAR limit> (SAR limit, in dBm)</p> <ul style="list-style-type: none"> • Integer or decimal (e.g. “4” or “6.8”) • Valid values: Use the Query List command to display valid values. Values will be in the range 0–MaxPower.

Table 12-2: SAR Backoff and Thermal Control Command Details (Continued)

Command	Description
!SARGPIO	<p>Set/report External GPIO controlling SAR</p> <p>Set or report the external GPIO used to control SAR. This command can be used to set any unallocated external GPIO to control SAR.</p> <p>To check the configuration of a GPIO (e.g. pull mode or function), use +WIOCFG.</p> <p>Requirements: Before this command can be used:</p> <ul style="list-style-type: none"> Use <code>!CUSTOM="GPIOSARENABLE"</code> to enable SAR customization. <p>Notes:</p> <ul style="list-style-type: none"> If a GPIO is currently set to control SAR and <code>!CUSTOM="GPIOSARENABLE"</code> is used to disable SAR customization, the GPIO will be deallocated when the device resets. If the GPIO pull mode must be changed, use !SARINTGPIOMODE to set the mode, and then reset the device. If a GPIO is currently set to control SAR and is to be replaced with a different GPIO, use this command to disable the current GPIO and then use it again to set the new GPIO. <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: ATISARGPIO=<GPIO>,<mode> Response: OK <i>or</i> ERROR <i>(If any GPIO is currently set to control SAR)</i> Response: OK Purpose: Set the external GPIO to be used for controlling SAR. Query: ATISARGPIO? Response: <GPIO>,<mode> OK Purpose: Indicate the external GPIO used to control SAR, and its state (disabled/enabled). Query list: ATISARGPIO=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><GPIO> (External GPIO used to control SAR)</p> <ul style="list-style-type: none"> Valid values: 2, 7, 8, 13, 21, 22, 23, 24, 25, 28, 29, 30, 31, 32, 42 <p><mode> (SAR GPIO mode)</p> <ul style="list-style-type: none"> 0—Disabled 1—Enabled

Table 12-2: SAR Backoff and Thermal Control Command Details (Continued)

Command	Description
!SARINTGPIOMODE	<p>Set/report default pull mode for SAR interrupt GPIOs</p> <p>Set or report the default pull mode (high/low) for SAR interrupt GPIOs. This setting applies to all SAR interrupt GPIOs.</p> <p>Password required: Yes (see !ENTERCND for details)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: ATISARINTGPIOMODE=<mode> Response: OK Purpose: Set the default pull mode for all SAR interrupt GPIOs. • Query: ATISARINTGPIOMODE? Response: <mode> OK Purpose: Indicate the default pull mode. • Query list: ATISARINTGPIOMODE=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><mode> (SAR GPIO interrupt pull mode default setting)</p> <ul style="list-style-type: none"> • 0=Standard mode—Default pull is HIGH/DAL_GPIO_PULL_UP • 1=Inverse mode—Default pull is LOW/DAL_GPIO_PULL_DOWN
!SARSTATE	<p>Set/report SAR backoff state</p> <p>Set or report the current SAR (Specific Absorption Rate) backoff state.</p> <hr/> <p><i>Note: This setting is not persistent. To change the default backoff state (persistent), use !SARSTATEDFLT.</i></p> <hr/> <p>Password required: No</p> <p>Persistent across power cycles: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: ATISARSTATE=<state> Response: OK Purpose: Temporarily set the SAR backoff state. • Query: ATISARSTATE? Response: !SARSTATE: <state> OK Purpose: Indicate the current SAR backoff state. • Query list: ATISARSTATE=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><state> (SAR backoff state)</p> <ul style="list-style-type: none"> • 0=No backoff • 1–8=Backoff state 1 to 8

Table 12-2: SAR Backoff and Thermal Control Command Details (Continued)

Command	Description
!SARSTATEDFLT	<p>Set/report default SAR backoff state</p> <p>Set or report the default (persistent) SAR (Specific Absorption Rate) backoff state.</p> <hr/> <p><i>Note: This setting is persistent. To temporarily change the backoff state, use !SARSTATE.</i></p> <hr/> <p>Password required: No Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!SARSTATEDFLT=<state> Response: OK Purpose: Set the default SAR backoff state. • Query: AT!SARSTATEDFLT? Response: <state> OK Purpose: Indicate the default SAR backoff state. • Query list: AT!SARSTATEDFLT=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><state> (SAR backoff state)</p> <ul style="list-style-type: none"> • 0=No backoff • 1–8=Backoff state 1 to 8

>> 13: Audio Commands

Introduction

This chapter describes commands used to configure and manage audio-capable RC76xx devices.

Command summary

Table 13-1 lists the commands described in this chapter.

Table 13-1: Audio Commands

Command	Description	Page
!AVCFG	Bind audio profile to device/physical interface	221
!AVDEF	Reset configurable audio parameters to default settings	223
!AVRXG	Query/Set audio profile decoder gain	223
!AVSETPROFILE	Select/configure audio profile for CS call	224
!AVSTG	Configure AFE side tone gain	224
!AVTXG	Query/Set audio profile encoder gain	225
+CLVL	Set active audio profile's Rx volume	225
+VTS	Send DTMF tone	226

Command reference

Table 13-2: Audio Command Details

Command	Description
!AVCFG	<p>Bind audio profile to device/physical interface</p> <p>Bind an audio profile to a specific ACDB (Audio Calibration Database) device/physical interface combination and, depending on the interface that is chosen, configure the physical interface.</p> <p>Supporting devices: Audio-capable RC76xx devices</p> <p>Password required: No</p> <p>Reset required to apply changes: No</p> <p>Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: ATI!AVCFG=<profile>,<device>,<interface>[,<param1>[,...<paramN>]] Response: OK Purpose: Bind the specified <profile> to a <device>/<interface> combination. If applicable, specify required parameters. • Query: ATI!AVCFG? Response: !AVCFG: <profile0>,<device>,<interface> [<param1> [...<paramN>]] ... <profile5>,<device>,<interface> [<param1> [...<paramN>]] OK Purpose: Show current bindings for all audio profiles. • Query List: ATI!AVCFG=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><profile> (Audio profile)</p> <ul style="list-style-type: none"> • 0–9=Audio profile number (10 profiles are supported) <p><device> (ACDB device type)</p> <ul style="list-style-type: none"> • 0=Vehicle hands-free device • 1=Handset • 2=TTY device • 3=USB device <p><interface> (Physical interface type)</p> <ul style="list-style-type: none"> • 0=PCM (Use <param> options to configure the interface.) • 1=I2S (No <param> required.) • 2=Internal codec (No <param> required.) • 3=USB (No <param> required.) <p>(Continued on next page)</p>

Table 13-2: Audio Command Details (Continued)

Command	Description
!AVCFG (continued)	<p>Bind audio profile to device/physical interface (continued)</p> <p><param> (Interface configuration parameters)</p> <ul style="list-style-type: none"> • For <interface>=0 (PCM): <ul style="list-style-type: none"> • <param1> (Mode) <ul style="list-style-type: none"> • 0=Slave • 1=Master • 2=Auxiliary PCM • <param2> (Rate) <ul style="list-style-type: none"> • 0=8K • 1=16K • <param3> (Format) <ul style="list-style-type: none"> • 0=Linear • 1=μ-law • 2=A-law • <param4> (Padding) <ul style="list-style-type: none"> • 0=Disable • 1=Enable • <param5> (Bits per frame (bpf)) <ul style="list-style-type: none"> • 0=8 bpf • 1=16 bpf • 2=32 bpf • 3=64 bpf • 4=128 bpf • 5=256 bpf <p>Example(s):</p> <ul style="list-style-type: none"> • AT!AVCFG=1,1,0,1 (Bind profile 1 to the handset device via PCM, and set PCM as master mode.)

Table 13-2: Audio Command Details (Continued)

Command	Description
!AVDEF	<p>Reset configurable audio parameters to default settings</p> <p>Reset all of the configurable audio parameters that are stored in non-volatile (NV) memory to default values.</p> <hr/> <p><i>Note: Some values that affect ACDB (Audio Calibration Database) devices are stored in NV, and some are stored on the device. Values that are stored on the device are not affected by this command.</i></p> <hr/> <p>Supporting devices: Audio-capable RC76xx devices Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: ATI!AVDEF[=<profile>] Response: OK Purpose: Reset all parameters for the specified <profile> (or all profiles if "=<profile>" is not used) to default values. <p>Parameters:</p> <p><profile> (Audio profile)</p> <ul style="list-style-type: none"> • Valid values: <ul style="list-style-type: none"> • No value (e.g. "ATI!AVDEF")—Reset parameters for all profiles to default values. • 0–9—Audio profile number (10 profiles are supported). Resets parameters for the specified profile number.
!AVRXG	<p>Query/Set audio profile decoder gain</p> <p>Query/set the decoder gain for a specified audio profile. This setting is stored in NV memory.</p> <p>Password required: Yes Reset required to apply changes: Yes Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: ATI!AVRXG=<profile>,<value> Response: OK Purpose: Set decoder gain for the specified profile. • Query: ATI!AVRXG?<profile> Response: !AVRXG: <value> OK Purpose: Display the specified profile's decoder gain. • Query List: ATI!AVRXG=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><profile> (Audio profile number)</p> <ul style="list-style-type: none"> • Valid range: 0–9 <p><value> (Decoder gain, in 1 dB steps)</p> <ul style="list-style-type: none"> • Hexadecimal • Gain calculation: $20 \times \text{LOG}(\text{<value>} / 0x2000)$ • Valid range: 0001–FE2F (-78 to +18) • Recommended range: 2000–FE2F (0 to +18)

Table 13-2: Audio Command Details (Continued)

Command	Description
!AVSETPROFILE	<p>Select/configure audio profile for CS call</p> <p>Select and configure an audio profile to be used for a circuit-switched call. (To view the current audio profile configurations, use ATIAVCFG?).</p> <p>Supporting devices: Audio-capable RC76xx devices Password required: No Reset required to apply changes: No Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: ATIAVSETPROFILE=<profile>[,<earmute>,<micmute>,<generator>,<volume>[,<cwtmute>]] Response: OK Purpose: Select the profile to use for a circuit switched call and, if needed, configure the mute and volume settings for the profile. • Query: ATIAVSETPROFILE?{<generator>} Response: !AVSETPROFILE: <profile>,<earmute>,<micmute>,[<generator>,<volume>,<cwtmute>] Purpose: Show the profile that has been selected for circuit switched calls, and its configuration parameters. (The <generator> field does not appear if <generator> is used in the query.) • Query List: ATIAVSETPROFILE=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><profile> (Audio profile used for CS call)</p> <ul style="list-style-type: none"> • 0–9=Audio profile number (10 profiles are supported) <p><earmute> (Earpiece mute state)</p> <ul style="list-style-type: none"> • 0=Unmuted • 1=Muted <p><micmute> (Microphone mute state)</p> <ul style="list-style-type: none"> • 0=Unmuted • 1=Muted <p><generator></p> <ul style="list-style-type: none"> • 0=Voice synthesizer (Note: This is the only option at this time.) <p><volume> (Rx volume level)</p> <ul style="list-style-type: none"> • Valid range: 0 (quietest) – 5 (loudest) NOTE: The Query List format incorrectly indicates valid range as 0–8. <p><cwtmute> (Call waiting tone mute state)</p> <ul style="list-style-type: none"> • 0=Unmuted • 1=Muted
!AVSTG	<p>Configure AFE side tone gain</p> <p>This command is not implemented and has no effect.</p>

Table 13-2: Audio Command Details (Continued)

Command	Description
!AVTXG	<p>Query/Set audio profile encoder gain</p> <p>Query/set the encoder gain for a specified audio profile. This setting is stored in NV memory.</p> <p>Password required: Yes</p> <p>Reset required to apply changes: No</p> <p>Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT!AVTXG=<profile>,<value> Response: OK Purpose: Set encoder gain for the specified profile. • Query: AT!AVTXG?<profile> Response: !AVTXG: <value> OK Purpose: Display the specified profile's encoder gain. • Query List: AT!AVTXG=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><profile> (Audio profile number)</p> <ul style="list-style-type: none"> • Valid range: 0–9 <p><value> (encoder gain, in 1 dB steps)</p> <ul style="list-style-type: none"> • Hexadecimal • Gain calculation: $20 \times \text{LOG}(\text{<value>}/0x2000)$ • Valid range: 0–FFFF (-78 to +18) • Recommended range: 0 to +18
+CLVL	<p>Set active audio profile's Rx volume</p> <p>Set the Rx volume for the active audio profile.</p> <p>Supporting devices: Audio-capable RC76xx devices</p> <p>Password required: No</p> <p>Reset required to apply changes: No</p> <p>Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+CLVL=<level> Response: OK Purpose: Set the Rx volume gain for the active profile. • Query: AT+CLVL? Response: +CLVL: <level> Purpose: Show the Rx volume for the active profile. • Query List: AT+CLVL=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><level> (Rx level for the active profile)</p> <ul style="list-style-type: none"> • Valid range: 0–5 (Level 0–Level 5)

Table 13-2: Audio Command Details (Continued)

Command	Description
+VTS	<p>Send DTMF tone</p> <p>Send continuous in-band DTMF tones (for UMTS and CDMA networks) while on an active call.</p> <p>Use AT+VTD to set the tone duration.</p> <p>Supporting devices: Audio-capable RC76xx devices</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+VTS=<tone> Response: OK Purpose: Send the specified DTMF tone. • Query List: AT+VTS=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><tone> (DTMF tone)</p> <ul style="list-style-type: none"> • UMTS networks: 0–9, A–D, a–d, *, # • CDMA networks: 0–9, *, # • Examples: <ul style="list-style-type: none"> • AT+VTS=1 (Send the DTMF tone for '1'.) • AT+VTS=# (Send the DTMF tone for '#'.)

>> 14: I/O Commands

Introduction

This chapter describes commands used to configure and manage GPIOs, ADCs and other IOs.

Command summary

[Table 14-1](#) lists the commands described in this chapter.

Table 14-1: I/O Commands

Command	Description	Page
+WEXTCLK	Enable/Disable user clock mode	228
+WIOCFG	GPIO Configuration	229
+WRID	Set/query Ring Indicator Duration	231
+WWAKESET	Set/query Wake Up Event Mask	232

Command reference

Table 14-2: I/O Command Details

Command	Description
+WEXTCLK	<p>Enable/Disable user clock mode</p> <p>Enable/disable generation of 19.2 MHz on the user output clock pins.</p> <p>Password required: No</p> <p>Reset required to apply changes: No</p> <p>Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+WEXTCLK=<port>,<mode_select> Response: OK Purpose: Enable or disable the user clock pin. • Query: AT+WEXTCLK? Response: +WEXTCLK: <port>,<mode_select> Purpose: Display the current clock mode setting. • Query List: AT+WEXTCLK=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><port> (Output port)</p> <ul style="list-style-type: none"> • 1 <p><mode_select> (Enable/disable output)</p> <ul style="list-style-type: none"> • 0—Off (disable) • 1—On (enable)

Table 14-2: I/O Command Details (Continued)

Command	Description
+WIOCFG	<p>GPIO Configuration</p> <p>Configure a specific GPIO (I/O port) for one of the following uses (indicated by the <func> parameter):</p> <ul style="list-style-type: none"> • GPIO, accessible via AT commands (<func> = 4) • Usage by the embedded Linux host (<func> = 16) • Deallocate port (<func> = 0) • Antenna select using GPIOs 28–31 (<func> = 0, then !ANTSEL can be used) <hr/> <p><i>Note: To enable 'Reset Out', set <gpio>=6 and <func>=0. Refer to the AirPrime RC76xx Product Technical Specification for details.</i></p> <hr/> <p>Password required: No Reset required to apply changes: No Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution (for <func>=0; Mark GPIO as unallocated): AT+WIOCFG=<gpio>,<func> Response: OK (If the port configuration works as requested) Purpose: Deallocate a GPIO. (Note: This must be done for GPIO28–GPIO31 if !ANTSEL is to be used for antenna select.) • Execution (for <func>=4 or 16; Allocate GPIO for General use or for Embedded Host use: AT+WIOCFG=<gpio>,<func>[,<dir>,<state>,<pull>,<trigger>,<intrvl>] Response: OK (If the port configuration works as requested) or ERROR (If the port is already allocated—the current <func> value is not 0) Purpose: Allocate the requested port (<idx>) for use as a GPIO or for control by the embedded host. • Query: AT+WIOCFG?[<gpio>] Response: (if <gpio> is specified) +WIOCFG:<gpio>,<func>,<dir>,<state>,<pull>,<trigger>,<intrvl> OK or (if <gpio> is not specified, shows all ports (<gpio> values)) +WIOCFG:<gpio>,<func>,<dir>,<state>,<pull>,<trigger>,<intrvl> ... +WIOCFG:<gpio>,<func>,<dir>,<state>,<pull>,<trigger>,<intrvl> OK Purpose: Report the configuration for the specified port (<gpio>), or for all ports (no <gpio> specified) • Query List: AT+WIOCFG=? Purpose: Display valid execution format and parameter values. <p>(Continued on next page)</p>

Table 14-2: I/O Command Details (Continued)

Command	Description
+WIOCFG (continued)	<p>GPIO Configuration (continued)</p> <p>Parameters:</p> <p><gpio> (Index of I/O port to be configured)</p> <ul style="list-style-type: none"> Valid range: 1–46. Use AT+WIOCFG? to view supported <gpio> values. Example: AT+WIOCFG? +WIOCFG: 2,16,0,0,1,0,0 +WIOCFG: 7,16,0,0,1,0,0 ... <p>The first parameters of each line of output are the valid <gpio> values (e.g. 2, 7, ...).</p> <ul style="list-style-type: none"> Note: To enable 'Reset Out', set <gpio> = 6 and <func> = 0. Refer to the RC76xx Product Technical Specification document for details. <p><func> (I/O port usage)</p> <ul style="list-style-type: none"> Valid values for Execution format: <ul style="list-style-type: none"> 0—Unallocated 4—General GPIO 16—Embedded host Valid values for Query format: <ul style="list-style-type: none"> 0—Unallocated 2—Antenna Select (applies only to GPIO28–31). GPIO28–GPIO31 can be allocated for external antenna selection using !ANTSEL. 3—External SIM2_DET Applies only to GPIO4, allocated for external SIM2 detection when "EXTUIM-SWITCHEN" customization is enabled. 4—General GPIO 8—External SIM Switch (applies only to GPIO6, when EXTUIMSWITCHEN customization is enabled) 9—SAR DPR (set by AT!SARGPIO) 16—Embedded host 26—Wi-Fi/LTE Coexistence control UART (applies only to GPIO35) Note: To enable 'Reset Out', set <gpio> = 6 and <func> = 0. <p><dir> (GPIO direction)</p> <ul style="list-style-type: none"> 0—Input 1—Output <p><state> (Power-up state for external GPIO configured as an output)</p> <ul style="list-style-type: none"> 0—Output low level at power-up 1—Output high level at power-up <p><pull> (Internal pull type for the I/O port)</p> <ul style="list-style-type: none"> 0—No pull 1—Pull down 2—Keeper 3—Pull up <p>(Continued on next page)</p>

Table 14-2: I/O Command Details (Continued)

Command	Description
+WIOCFG (continued)	<p>GPIO Configuration (continued)</p> <p><trigger> (Trigger type for I/O port configured as an input)</p> <ul style="list-style-type: none"> • Note: <trigger> is not supported if <gpio>=6 (GPIO6) • 0—No trigger • 1—Trigger high • 2—Trigger low • 3—Trigger rising • 4—Trigger falling <p><intrvl> (Interval at which the I/O port is checked for the specified level trigger (<trig>))</p> <ul style="list-style-type: none"> • Note: <intrvl> is not supported if <gpio>=6 (GPIO6) • 0—50 ms • 1—1000 ms <hr style="border: 1px solid red;"/> <p><i>Note: For edge interrupt, the module can only respond one time per 10 ms per GPIO.</i></p>
+WRID	<p>Set/query Ring Indicator Duration</p> <p>Set or return the duration of the pulse that is asserted on the Ring Indicator line (pin RI1). (The pulse may be asserted under several different event conditions, but the pulse duration is the same.)</p> <p>Make sure to set the duration appropriately. While long durations may make sense for some events, it is possible that shorter events may expire before the pulse finishes (for example, an incoming call could expire or be re-routed to voicemail).</p> <p>The design is such that if an event expires before the pulse finishes, the wakeup reason and ring indicator will not be reset.</p> <p>Password required: No</p> <p>Reset required to apply changes: No</p> <p>Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+WRID[=<n>] Response: OK, or ERROR (<i>If invalid assignment</i>) Purpose: Set the ring indicator pulse duration. If "=<n>" is not entered, the default pulse duration value (50 ms) is used. • Query: AT+WRID? Response: +WRID: <n> Purpose: Display the ring indicator pulse duration. • Query List: AT+WRID=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><n> (Ring indicator pulse duration, in ms units)</p> <ul style="list-style-type: none"> • 50–10000 (Default=50 ms). Range equates to 0.05–10.0 seconds. • Integer values only (pulse is set in 1 ms steps)

Table 14-2: I/O Command Details (Continued)

Command	Description
+WWAKESET	<p>Set/query Wake Up Event Mask</p> <p>Set or query the WAKE mask setting, which indicates the actions that will generate a pulse on the Ring Indicator (RI) output signal to "wake up" an application.</p> <p>The WAKE mask indicates all events that can generate the wake pulse. When an event occurs, the RI is asserted for the duration defined via AT+WRID and then de-asserts.</p> <p>If additional events occur while the RI is asserted, the RI is not re-asserted and the duration is not extended; it is assumed that the external processor is awakened by the first assertion.</p> <hr/> <p><i>Note: Each time this command is used to set the mask, the previous setting is replaced. That is, the mask value must indicate all the events that will generate a pulse.</i></p> <hr/> <p>Password required: No Reset required to apply changes: No Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+WWAKESET[=<bitmask>] Response: OK, or ERROR (if an invalid mask value is entered) Purpose: Indicate which events pulse the RI pin. If "=<bitmask>" is not entered, the default mask value (4—Incoming voice call) is used. • Query: AT+WWAKESET? Response: +WWAKESET: <bitmask> Purpose: Display the current mask value. • Query List: AT+WWAKESET=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><bitmask> (Events that will assert (pulse) the RI signal)</p> <ul style="list-style-type: none"> • If more than one event will assert the signal, add the values. For example, to get notifications for both lost service and incoming voice calls, the <bitmask> value is 5. • 0—No notifications • 1—Lost service (for example, going from digital service to no service)—If the module is in deep sleep (32 kHz), the RI will assert and the module will remain asleep • 2—Service regained (going from no service to service)—If the module is in deep sleep (32 kHz), the RI will assert and the module will remain asleep. NOTE: Changing the SID and remaining on the same service type will NOT trigger the RI signal. • 4—Incoming voice call (Default setting) • 8—Incoming data call • 16—Incoming SMS message • 32—Reserved • 64—Module restart (includes the first power up) • 128—Module has undergone Sudden Momentary Power Loss • 256—Reserved • 512—Antenna status change • 1024—Reserved • 2048—Legato application event • 4095—All events as listed above

>> 15: AirVantage Commands

Introduction

This chapter describes AirVantage (AV) related commands.

Command summary

[Table 15-1](#) lists the commands described in this chapter.

Table 15-1: AirVantage Device Services Commands

Command	Description	Page
+WDSC	Configure AirVantage Management Services	234
+WDSE	Display most recent AirVantage Management Services error	236
+WDSG	Display AirVantage Management Services status information	237
+WDSI	Activate/deactivate AirVantage Management Services unsolicited notifications	238
+WDSR	Reply to AirVantage server request	241
+WDSS	Configure/connect AirVantage Management Services session	242

Command reference

Table 15-2: AirVantage Device Services Command Details

Command	Description
<p>+WDSC</p>	<p>Configure AirVantage Management Services</p> <p>Configure the following AirVantage Management Services parameters:</p> <ul style="list-style-type: none"> • User agreement for connection, package download, package install, and package uninstall • Polling mode to make a connection to the AirVantage server • Retry mode to attempt a new connection to the AirVantage server when the WWAN DATA service is temporarily out of order or when an http/CoAP error occurs <p>SIM card requirement: Not required</p> <p>Password required: No</p> <p>Persistent across power cycles: Yes (<State>, <Timer_1>, <Timer_n>)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution (<Mode> = 0, 1, 2, 3, 5, 6): AT+WDSC=<Mode>,<State> Response: OK Purpose: Enable or disable the selected <Mode>. • Execution (<Mode> = 4): AT+WDSC=<Mode>,<Timer_1>[[,<Timer_2>]...[,<Timer_n>]] Response: OK Purpose: Set interval timers for successive connection attempts. • Query: AT+WDSC? Response: +WDSC: 0,<State> +WDSC: 1,<State> +WDSC: 2,<State> +WDSC: 3,<State> +WDSC: 4,<Timer_1>[[,<Timer_2>]...[,<Timer_n>]] +WDSC: 5,<State> +WDSC: 6,<State> OK Purpose: Show the current <Mode> configurations. • Query List: AT+WDSC=? Purpose: Display valid execution format and parameter values. <p>(Continued on next page)</p>

Table 15-2: AirVantage Device Services Command Details (Continued)

Command	Description
+WDSC (continued)	<p>Configure AirVantage Management Services (continued)</p> <p>Parameters:</p> <p><Mode> (Mode being configured)</p> <ul style="list-style-type: none"> • 0—User agreement for AVMS connection. When enabled, the module returns an unsolicited notification to request an agreement before connecting to the server. See +WDSI on page 238 for details. <p>Note: If a FOTA session begins and user agreement for package download (<mode> 1) is disabled, an AVMS connection is initiated, regardless of whether user agreement for AVMS connection (<mode> 0) is enabled or disabled.</p> <ul style="list-style-type: none"> • 1—User agreement for package download. When enabled, the module returns an unsolicited notification to request an agreement before downloading any package. See +WDSI on page 238 for details. • 2—User agreement for package install. When enabled, the module returns an unsolicited notification to request an agreement before installing any package. See +WDSI on page 238 for details. • 3—Polling mode. When enabled (<State> > 0), the module waits for the number of minutes specified in <State>, then will initiate a connection to the AirVantage server based if the device is registered on the network. • 4—Retry mode. If an error occurs during a connection to the AirVantage server (e.g. WWAN DATA establishment failed, http error code received), the module will initiate a new connection according to the defined timers. (Note: This is a persistent setting.) • 5—User agreement for device reboot. When enabled, the module returns an unsolicited notification to request an agreement before rebooting the device. See +WDSI on page 238 for details. • 6—User agreement for application uninstall (software update). When enabled, the module returns an unsolicited notification to request an agreement before uninstalling an application. See +WDSI on page 238 for details. <p><State> (For <Mode> = 0, 1, 2, 5, 6: Activation state of <Mode>)</p> <ul style="list-style-type: none"> • 0=Disabled • 1=Enabled <p><State> (For <Mode> = 3: Activation state/timer of <Mode>)</p> <ul style="list-style-type: none"> • 0=Disabled • 1–525600=Polling timer (in minutes) <p><Timer_1>..<Timer_n> (Connection attempt interval timers)</p> <ul style="list-style-type: none"> • The number of minutes to wait after connection attempt (n-1) before making connection attempt (n). (Note: There is a maximum of 8 connection attempts.) • Valid range: 1–20160 • Default values: <ul style="list-style-type: none"> • <Timer_1>=15 (Time to wait after first failed connection attempt.) • <Timer_2>=60 (Time to wait after second failed connection attempt.) • <Timer_3>=240 (Time to wait after third failed connection attempt.) • <Timer_4>=960 (Time to wait after fourth failed connection attempt.) • <Timer_5>=2880 (Time to wait after fifth failed connection attempt.) • <Timer_6>=10080 (Time to wait after sixth failed connection attempt.) • <Timer_7>=10080 (Time to wait after seventh failed connection attempt.)

Table 15-2: AirVantage Device Services Command Details (Continued)

Command	Description
+WDSE	<p>Display most recent AirVantage Management Services error Display the most recent HTTP(S) response received by the device for the package download.</p> <p>Requirements:</p> <ul style="list-style-type: none"> AirVantage Management Services must be activated (See +WDSG on page 237 for details). Session must be initiated using AT+WDS=1,1. (See +WDSS on page 242 for details). <p>SIM card requirement: Not required Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT+WDSE Response: [+WDSE: <HTTP_Status>] OK <i>or</i> +CME ERROR: 3 <i>(If AirVantage Management services are not in the Activated state.)</i> Purpose: Display most recent response. (If HTTP/HTTPS is not yet used, return only OK.) <p>Parameters: <HTTP_Status> (Standard HTTP status code)</p> <ul style="list-style-type: none"> none—No response shown if HTTP/HTTPS has not yet been used. Supported statuses: <ul style="list-style-type: none"> 1xx Informational: <ul style="list-style-type: none"> 100 (Continue) 101 (Switching protocols) 2xx Success: <ul style="list-style-type: none"> 200 (OK) 201 (Created) 202 (Accepted) 203 (Non-authoritative information) 204 (No content) 205 (Reset content) 206 (Partial content) 3xx Redirection: <ul style="list-style-type: none"> 300 (Multiple choices) 301 (Moved permanently) 302 (Found) 303 (See other) 304 (Not modified) 305 (Use proxy) 307 (Temporary redirect) 4xx Client Error: <ul style="list-style-type: none"> 400 (Bad request) 401 (Unauthorized) 402 (Payment required) 403 (Forbidden) 404 (Not found) 405 (Method not allowed) 406 (Not acceptable) 407 (Proxy authentication required) 408 (Request time-out) 409 (Conflict) 410 (Gone) 411 (Length required) 412 (Precondition failed) 413 (Request entity too large) 414 (Request URI too large) 415 (Unsupported media type) 416 (Requested range not satisfiable) 417 (Expectation failed) 5xx Server Error: <ul style="list-style-type: none"> 500 (Internal server error) 501 (Not implemented) 502 (Bad gateway) 503 (Service unavailable) 504 (Gateway time-out) 505 (HTTP version not supported)

Table 15-2: AirVantage Device Services Command Details (Continued)

Command	Description
+WDSG	<p>Display AirVantage Management Services status information</p> <p>Display general AirVantage Management Services status details.</p> <p>SIM card requirement: Not required</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+WDSG Response: +WDSG: <Status>, <Value> +WDSG: <Status>, <Value> OK Purpose: Returns the current <Value>s for <Status>=1 and <Status>=2. <p>Parameters:</p> <p><Status> (Information type to display)</p> <ul style="list-style-type: none"> • 0—AirVantage Management Services activation state <ul style="list-style-type: none"> • For <Value>=2 and <Value>=3, connection parameters are automatically provisioned and no actions are required by the user. • Device is activated (<Value>=3) when a dedicated APN (Access Point Name) is set manually or automatically in the first session. See +WDSS on page 242 for details. • 1—Session and package indication <p><Value> (Detail for the <Status>)</p> <ul style="list-style-type: none"> • For <Status>=0: <ul style="list-style-type: none"> • 0—AirVantage Management Services prohibited. Management Services will never be activated. • 1—AirVantage Management Services deactivated. Connection parameters to an AirVantage server must be provisioned. This is the default state when a device has never been activated (first use of device services on this device). • 2—AirVantage Management Services must be provisioned. A bootstrap session is required. • 3—AirVantage Management Services are activated. • For <Status>=1: <ul style="list-style-type: none"> • 0—No session or package. • 1—A session is under treatment. • 2—A package is available on the server. • 3—A package was downloaded and ready to install. • Note: If a package is downloaded unsuccessfully, the <Value> is set to 0. If it downloads successfully, the <Value> is set to 3.

Table 15-2: AirVantage Device Services Command Details (Continued)

Command	Description
+WDSI	<p>Activate/deactivate AirVantage Management Services unsolicited notifications</p> <p>Activate/deactivate specific AirVantage Management Services unsolicited notifications.</p> <p>Requirements:</p> <ul style="list-style-type: none"> To receive unsolicited notifications, AirVantage Management Services must be activated (see +WDSG on page 237 for details). <p>SIM card requirement: Not required</p> <p>Password required: No</p> <p>Reset required to apply changes: No</p> <p>Persistent across power cycles: Yes</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT+WDSI=<Level> Response: OK Purpose: Activate/deactivate identifications as specified in the <Level> bitmask parameter. Query: AT+WDSI? Response: +WDSI: <Level> OK Purpose: Indicates the current state (activated/deactivated) of indications using the <Level> bitmask parameter. Query List: AT+WDSI=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><Level> (Unsolicited AirVantage Management Services notifications bit mask)</p> <ul style="list-style-type: none"> Bit mask indicating which notifications to enable/disable entered as integer value Default: 0= No indications activated Bit value: <ul style="list-style-type: none"> 0=Indication deactivated 1=Indication activated Valid ranges: 0-127, 256-383, 4096-4223, 4352-4479. Add the values of each bit listed below. (See +WDSI (notification) on page 239 for <Event> details.) Note that bit combinations must add up to values in the valid ranges—combinations outside the ranges are not valid. <ul style="list-style-type: none"> 1 (Bit 0)—Initialization end indication (<Event> = 0) 2 (Bit 1)—Server request for user agreement indication (<Event> = 1, 2, 3, 24) 4 (Bit 2)—Authentication indications (<Event> = 4, 5) 8 (Bit 3)—Session indication (<Event> = 6, 7, 8) 16 (Bit 4)—Package download indications (<Event> = 9, 10, 11) 32 (Bit 5)—Certified downloaded package indication (<Event> = 12, 13) 64 (Bit 6)—Update indications (<Event> = 14, 15, 16) 128 (Bit 7)—Fallback indication (<Event> = 17) 256 (Bit 8)—Download progress indication (<Event> = 18) 512 (Bit 9)—Memory preemption indication (<Event> = 19) 1024 (Bit 10)—User PIN request indication for bootstrap (<Event> = 20) 2048 (Bit 11)—Reserved 4096 (Bit 12)—Bootstrap event indication (<Event> = 23)

Table 15-2: AirVantage Device Services Command Details (Continued)

Command	Description
+WDSI (notification)	<p>AirVantage Management Services events—Unsolicited notification Unsolicited notification received for various AirVantage Management Services events.</p> <p>Requirements:</p> <ul style="list-style-type: none"> To receive unsolicited notifications, AirVantage Management Services must be activated (see +WDSG on page 237 for details). <p>Notification format: +WDSI: <Event>[,<Data>]</p> <hr/> <p><i>Note: <Event> parameter descriptions below indicate when a <Data> parameter is included in the response.</i></p> <hr/> <p>Examples:</p> <ul style="list-style-type: none"> +WDSI: 9,1000 <i>Package will be downloaded, size is 1000 bytes</i> +WDSI: 18,1 <i>1% of package has been downloaded</i> +WDSI: 18, 100 <i>Entire package (100%) has been downloaded</i> +WDSI: 11,2 <i>Package download failue due to HTTP(S) error (see +WDSE on page 236 for error values)</i> <p>Parameters:</p> <p><Event> (AirVantage Management Services event)</p> <ul style="list-style-type: none"> 0—AirVantage Management Services are initialized and can be used. (Note: Management Services are initialized when the SIM PIN code is entered and a dedicated NAP is configured. See +WDSS on page 242 for details.) 1—AirVantage server requests that the device make a connection. The device requests a user agreement to allow the module to make the connection. The response can be sent using +WDSR (see +WDSR on page 241) and this indication can be returned by the device if the user has activated the user agreement for connection (see +WDSC (continued) on page 235 for details). 2—AirVantage server requests that the device make a package download. The device requests a user agreement to allow the module to make the download. The response can be sent using +WDSR (see +WDSR on page 241) and this indication can be returned by the device if the user has activated the user agreement for download (see +WDSC (continued) on page 235 for details). 3—Device has downloaded a package. The device requests a user agreement to install the downloaded package. The response can be sent using +WDSR (see +WDSR on page 241) and this indication can be returned by the device if the user has activated the user agreement for install (see +WDSC (continued) on page 235 for details). 4—Module starts authentication with the server. 5—Authentication with the server failed. 6—Authentication has succeeded and session with the server has started. 7—Session with the server failed. 8—Session with the server is finished. 9—Package is available on the server and can be downloaded by the module. A <Data> parameter is returned indicating the package size in kBd. <p>(Continued on next page)</p>

Table 15-2: AirVantage Device Services Command Details (Continued)

Command	Description
+WDSI (notification) (continued)	<p>AirVantage Management Services events—Unsolicited notification (continued)</p> <ul style="list-style-type: none"> • 10—Package was successfully downloaded and stored in flash. • 11—One of the following issues happened during the package download: <ul style="list-style-type: none"> • If the download did not start (a +WDSI <Event>=9 indication has not been received), there is not enough space in the device to download the package. • If the download started (a +WDSI <Event>=9 indication has been received), a flash problem implies that the package has not been saved in the device. • 12—Downloaded package is certified to be sent by the AirVantage server. • 13—Downloaded package is not certified to be sent by the AirVantage server. • 14—Update will be launched. • 15—OTA update client has finished unsuccessfully. • 16—OTA update client has finished successfully. • 17—Reserved • 18—Download progress: <ul style="list-style-type: none"> • No <Data> parameter—Download start • <Data> parameter—Percentage progress • 19–22—Reserved • 23—Session type (only in LWM2M protocol) • 24—AirVantage server requests that the device make a reboot. The device requests a user agreement to allow the module to reboot. The response can be sent using +WDSR (see +WDSR on page 241) and this indication can be returned by the device if the user has activated the user agreement for connection (see +WDSC (continued) on page 235 for details). • 25—AirVantage server requests that the device make an application uninstall (software update). The device requests a user agreement before uninstalling. The response can be sent using +WDSR (see +WDSR on page 241) and this indication can be returned by the device if the user has activated the user agreement for connection (see +WDSC (continued) on page 235 for details). <p><Data> (Additional data for specific <Event>s)</p> <ul style="list-style-type: none"> • (<Event>=5) To be defined • (<Event>=9) Package size: <ul style="list-style-type: none"> • Package size in bytes, which will be downloaded • Preempted DOTA area size needed to download an update package • If preemption is not made, this parameter is not returned for this event. • If a reverse package is not downloaded and stored, the preempted area will be released after the installation. • (<Event>=11) Download failure reason: <ul style="list-style-type: none"> • 0=Insufficient memory in device to save firmware update package. Package was not downloaded. • 1=HTTP/HTTPS error occurred. See +WDSE on page 236 for possible error values. • 2=Corrupted firmware update package, did not store correctly. Reasons include (or example), mismatched CRCs between actual and expected, or signature check error. • (<Event>=18) Download progress: <ul style="list-style-type: none"> • Integer value (% complete) • (<Event>=23) Session event type: <ul style="list-style-type: none"> • 0=Bootstrap session • 1=Device management session

Table 15-2: AirVantage Device Services Command Details (Continued)

Command	Description
+WDSR	<p>Reply to AirVantage server request</p> <p>Reply to a user agreement request (see +WDSI (notification) on page 239 for details) from the module.</p> <p>SIM card requirement: Required, and PIN 1/CHV 1 code must be entered.</p> <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+WDSR=<Reply>[,<Timer>] Response: OK Purpose: Send <Reply> to a user agreement request from the module. For specific <Reply> types, include a <Timer> to have the module send a new user agreement request after the specified delay. • Query List: AT+WDSR=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><Reply> (Reply type)</p> <ul style="list-style-type: none"> • 0—Delay the connection to server (Connect later) • 1—Accept the connection to server (Connect now) • 2—Delay or refuse to download. New user agreement request to be sent by module after <Timer> minutes: <ul style="list-style-type: none"> • Delay—<Timer> must be > 0, or blank (Default 30). New user agreement request to be sent by module after <Timer> minutes. • Refuse—<Timer>=0. Usage restrictions include: <ul style="list-style-type: none"> • Option available only if OMA DM protocol is used. • Not supported for install request (AT+WDSR=5,0). Returns +CME ERROR: 3 • Not supported for device reboot request (AT+WDSR=7,0). Returns +CME_ERROR: 3 • Not supported for uninstall request (AT+WDSR=9,0). Returns +CME_ERROR: 3 • 3—Accept the download (download it now) • 4—Accept the install (install it now) • 5—Delay the install. New user agreement request to be sent by module after <Timer> minutes. • 6—Accept the device reboot (reboot now) • 7—Delay the device reboot. New user agreement request to be sent by module after <Timer> minutes. • 8—Accept the application uninstall (uninstall it now) • 9—Delay the application uninstall (uninstall it later after <Timer> minutes) • Note: If the module is powered down before a delay (install, download, or reboot) finishes, the new user agreement request will be returned during the next start up. <p><Timer> (Interval before new user agreement request to be sent by module)</p> <ul style="list-style-type: none"> • Applies to <Reply> types 2, 5, 7, 9 • Valid values: <ul style="list-style-type: none"> • Valid range: 0–1440 (minutes) • 0—If <Reply>=2 and OMA DM protocol is used, refuse the user agreement request. • Default (if not specified): 30 (minutes)

Table 15-2: AirVantage Device Services Command Details (Continued)

Command	Description
+WDSS	<p>Configure/connect AirVantage Management Services session</p> <p>Initiate or terminate a connection to the AirVantage server, and set the PDP context for the connection.</p> <p>After setting the PDP context ID for the connection, configure the PDP context using AT+CGDCONT.</p> <hr/> <p><i>Note: If AT+WDSS is used to change the current PDP context, the new ID is not guaranteed to have a valid configuration (AT+CGDCONT must be used to configure the context).</i></p> <hr/> <p>SIM card requirement: Required, and PIN 1/CHV 1 code must be entered. Password required: No Persistent across power cycles: Yes (<Apn> only)</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution (<Mode> = 1): AT+WDSS=<Mode>,<Action> Response: OK Purpose: Connect to/disconnect from the AirVantage server • Execution (<Mode> = 2): AT+WDSS=<Mode>[,<Cid>] Response: OK Purpose: Set the PDP context ID for the AirVantage server connection. If no <Cid> is entered, the default PDP context ID is used. • Query: AT+WDSS? Response: [+WDSS: 1,<Action>] [+WDSS: 2,<Cid>] OK Purpose: Display the current AirVantage server connection state, and the PDP context ID for the connection. • Query List: AT+WDSS=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><Mode> (Connection method)</p> <ul style="list-style-type: none"> • 1—User-initiated connection to the AirVantage server • 2—PDP context configuration for AirVantage server • Note: Mode 0 is deprecated; use Mode 2 instead. <p><Cid> (PDP context identifier)</p> <ul style="list-style-type: none"> • Integer value • Valid range: 1–16 <p><Action> (Connect to/disconnect from AirVantage server)</p> <ul style="list-style-type: none"> • 0—Release connection (Default) • 1—Establish connection

>> 16: Protocol Commands

Introduction

This chapter describes Internet Protocol (TCP, UDP, HTTP) related commands.

Usage Notes

The following general usage notes apply to the AT commands described in this chapter:

- Session IDs — These protocol-specific AT commands share the same range of session IDs. Each session ID (<session_id>) is a unique number in the range 1–32.
- IP address format — Unless otherwise specified, IP address parameters in the AT commands described in this chapter use the following formats:
 - IPv4 — Dot-separated decimal (0–255) values using the format a1.a2.a3.a4
 - IPv6 — Colon-separated hexadecimal (0–FFFF) values in the format a1:a2:a3:a4:a5:a6:a7:a8. Abbreviations are supported (e.g. 2001:0db8:3c4d:0015:0000:0000:1a2f:1a2b can be abbreviated as 2001:db8:3c4d:15::1a2f:1a2b)
- PDP context connection
 - A PDP connection starts when a session becomes active (e.g. using +KTCPCNX) and stops only if all sessions are closed or all sessions request to stop the connection.
 - By default, a PDP connection is requested to stop only when a session is closed by an Internet AT command (e.g. +KTCPCLOSE).
 - To configure the PDP connection deactivation behavior with respect to session errors, use +KIPOPT with <option_id>=3.
 - When a context is active, its configuration (+KCNXCFG) must be consistent with the +CGDCONT configuration, otherwise an error will be returned when creating a connection with +KCNXUP, +KCTPCNX or +KUDPCFG. Therefore, an active PDP context must include the following +KCNXCFG configurations:
 - <af> must be consistent with +CGDCONT <PDP_type>, and
 - <APN> must be identical to +CGDCONT <APN> or must be set to the empty string ("").
- Buffer length — The maximum length of an AT command in AT command mode is 513 characters. Any AT command input longer than this will produce an error response. If the maximum length of a parameter is not specified in this document, it may vary but is still bound by this limit.

Command summary

Table 16-1 lists the commands described in this chapter:

Table 16-1: Protocol Commands

Command	Description	Page
+KCGPADDR	Display module's PDP context addresses	245
+KCNX_IND (notification)	Connection Status Notification—Unsolicited notification	246
+KCNXCFG	Configure GPRS Connection	247

Table 16-1: Protocol Commands

Command	Description	Page
+KCNXDOWN	Bring down PDP connection	249
+KCNXPROFILE	Query/Set default PDP context	249
+KCNXTIMER	Configure TCP/UDP Connection Timer	250
+KCNXUP	Bring up PDP connection	251
+KHTTPCFG	Configure HTTP connection	252
+KHTTPCLOSE	Close HTTP connection	253
+KHTTPEL	Delete configured HTTP session	254
+KHTTGET	Get HTTP server information	255
+KIPOPT	Configure general protocol options	256
+KPATTERN	Set/query the custom end of data/file pattern	258
+KSSLCRYPTO	Cipher suite configuration	259
+KSSLCFG	SSL Configuration	261
+KTCP_DATA (notification)	Incoming Data through TCP connection—Unsolicited notification	262
+KTCP_IND (notification)	TCP status—Unsolicited notification	262
+KTCP_SRVREQ (notification)	Incoming client connection request—Unsolicited notification	263
+KTCPCFG	Configure TCP connection	265
+KTCPCLOSE	Close current TCP connection	267
+KTCPCNX	Start TCP connection	268
+KTCPDEL	Delete configured TCP session	269
+KTCPRCV	Receive data through TCP connection	270
+KTCPSEND	Send data through TCP connection	271
+KTCPSTART	Start TCP connection in Direct Data Flow	272
+KTCPSTAT	Get TCP socket status	273
+KUDP_DATA (notification)	Incoming Data through UDP connection—Unsolicited notification	274
+KUDP_IND (notification)	UDP status—Unsolicited notification	274
+KUDPCFG	Configure UDP connection	275
+KUDPCLOSE	Close current UDP connection	277
+KUDPDEL	Delete configured UDP session	277
+KUDPRCV	Receive data through UDP connection	278
+KUDPSEND	Send data through UDP connection	279
+KURCCFG	Enable/Disable Protocol Notifications (URCs)	280

Command reference

Table 16-2: Protocol Command Details

Command	Description
+KCGPADDR	<p>Display module's PDP context addresses</p> <p>Display the module's address for a specific PDP context, or all contexts. Password required: No</p> <p>Notes:</p> <ul style="list-style-type: none"> Command can be used after +KTCCPNX, +KUDPCFG, etc., to display the local IP address of the module. For IPv6, more than one PDP address corresponding to the interface may be displayed. <p>Usage:</p> <ul style="list-style-type: none"> Execution (one context): AT+KCGPADDR=<cnx_cnf> Response: +KCGPADDR: <cnx_cnf>, <PDP_addr₁> OK Purpose: Display the address for the specified context. Execution (all contexts): AT+KCGPADDR Response: +KCGPADDR: <cnx_cnf₁>, <PDP_addr₁> [+KCGPADDR: <cnx_cnf₂>, <PDP_addr₂>] [...] OK Purpose: Display the addresses for all contexts. Query List: AT+KCGPADDR=? Purpose: Display valid parameter values. <p>Parameters:</p> <p><cnx_cnf> (PDP context configuration)</p> <ul style="list-style-type: none"> Specifies a particular PDP context configuration that has been defined by +CGDCONT. (e.g. <cnx_cnf=3> corresponds to CID=3 in +CGDCONT and +CGACT) <p><PDP_addr> (IP Address of module in PDP address space)</p> <ul style="list-style-type: none"> ASCII string

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KCNX_IND (notification)	<p>Connection Status Notification—Unsolicited notification</p> <p>Unsolicited notification indicating the status of a connection attempt. To enable this notification, use +KURCCFG on page 280.</p> <p>Notification format:</p> <ul style="list-style-type: none"> • For <status> = 0 or 1: +KCNX_IND: <cnx_cnf>, <status>, <af> • For <status> = 2: +KCNX_IND: <cnx_cnf>, <status>, <attempt>, <nbtrial>, <tim1> • For <status> = 3 or 6: +KCNX_IND: <cnx_cnf>, <status> • For <status> = 4: +KCNX_IND: <cnx_cnf>, <status>, <attempt> • For <status> = 5: +KCNX_IND: <cnx_cnf>, <status>, <idletime> <p>Parameters:</p> <p><cnx_cnf> (PDP context configuration)</p> <ul style="list-style-type: none"> • Specifies a particular PDP context configuration that has been defined by +CGDCONT. (e.g. <cnx_cnf=3> corresponds to CID=3 in +CGDCONT and +CGACT) <p><status> (PDP connection status)</p> <ul style="list-style-type: none"> • 0—Disconnected due to network • 1—Connected • 2—Failed to connect. <tim1> timer is started if <attempt> is less than <nbtrial>. • 3—Closed • 4—Connecting • 5—Idle time down counting started for disconnection • 6—Idle time down counting canceled <p><af> (IP address family type used for connection, compliant up to 3GPP Release 7)</p> <ul style="list-style-type: none"> • Valid values: <ul style="list-style-type: none"> • 0—IPv4 • 1—IPv6 <p><tim1> (PDP activation reattempt timer, in seconds)</p> <ul style="list-style-type: none"> • Integer • Valid range: 1–120 • See +KCNTXTIMER for details <p><attempt> (PDP connection attempt number)</p> <ul style="list-style-type: none"> • Integer <p><nbtrial> (Max number of PDP activation attempts)</p> <ul style="list-style-type: none"> • Integer • Valid range: 1–4 • See +KCNTXTIMER for details <p><idletime> (Max idle time, in seconds)</p> <ul style="list-style-type: none"> • Integer • Valid range: 0–1800 • See +KCNTXTIMER for details

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KCNXCFG	<p>Configure GPRS Connection Password required: No</p> <p>Notes:</p> <ul style="list-style-type: none"> • Command is used to configure the bearer to be used for future IP services. • By default, the IP and DNS addresses are dynamic (values would be affected by the network during the PDP connection). • Connection will be used by the module to access IP services. +KCNXCFG defines only the parameters for the specified connection. The defined connection will be opened automatically when needed by the IP services (e.g. UDP service). • The use of IPv4 and/or IPv6 addresses is configured by PDP context configuration. • <ip>—Static IP addresses are not supported. • When the connection is up, the query command returns the actual values used by the connection interface. When the connection is down, it returns the configured values. • If reuse of existing activated PDP context is required, <apn> can be set as an empty string or as the existing APN string returned by the +CGDCONT query command. <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+KCNXCFG=<cnx_cnf>, "GPRS", <apn> [,<login>] [,<password>] [,<af> [,<ip>] [,<dns1>] [,<dns2>]]] [,<ip_v6>] [,<dns1_v6>] [,<dns2_v6>]]]]] Response: OK Purpose: Set the GPS connection parameters for the specified connection. • Query: AT+KCNXCFG? Response: +KCNXCFG: <cnx_cnf>,"GPRS",<apn>,<login>,<password>,<af>,<ip>,<dns1>,<dns2>[,<ip_v6>,<dns1_v6>,<dns2_v6>],<state> [...] OK Purpose: Display the actual values used by the connection interface (if the connection is up), or the configured values (if the connection is down). • Query List: AT+KCNXCFG=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><cnx_cnf> (PDP context configuration)</p> <ul style="list-style-type: none"> • Specifies a particular PDP context configuration that has been defined by +CGDCONT. (e.g. <cnx_cnv=3> corresponds to CID=3 in +CGDCONT and +CGACT) <p><apn> (Access Point Name)</p> <ul style="list-style-type: none"> • ASCII string, max. length = 63 bytes • Logical name used to select the GGSN or the external packet data network. <p><login> (cnx user name)</p> <ul style="list-style-type: none"> • ASCII string, max. length = 24 bytes <p>(Continued on next page)</p>

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KCNXCFG (continued)	<p>Configure GPS Connection (continued)</p> <p><password> (cnx password)</p> <ul style="list-style-type: none"> • ASCII string, max. length = 24 bytes <p><af> (IP address family type used for connection, compliant up to 3GPP Release 7)</p> <ul style="list-style-type: none"> • ASCII string • Valid values: <ul style="list-style-type: none"> • IPV4—IPv4 only • IPV6—IPv6 only • IPV4V6—IPv4 and IPv6 <p><ip> (IPv4 address)</p> <ul style="list-style-type: none"> • ASCII string • Format: #.#.#.# (e.g. 192.168.0.1) • If the module is to work with a dynamic address, use 0.0.0.0 or an empty string. • Static IP is not supported <p><dns1>, <dns2> (IPv4 DNS addresses)</p> <ul style="list-style-type: none"> • ASCII string • Format: #.#.#.# (e.g. 192.168.0.1) • If the module is to work with dynamic DNS addresses, use 0.0.0.0 or an empty string. <p><ip_v6> (IPv6 address)</p> <ul style="list-style-type: none"> • ASCII string • Format: #####.#####.#####.#####.#####.#####.#####.##### (e.g. 2001:0db8:85a3:0000:0000:8a2e:0370:7334) • If the module is to work with a dynamic address, use "::" or an empty string. <p><dns1_v6>, <dns2_v6> (IPv6 addresses)</p> <ul style="list-style-type: none"> • ASCII string • Format: #####.#####.#####.#####.#####.#####.#####.##### (e.g. 2001:0db8:85a3:0000:0000:8a2e:0370:7334) • If the module is to work with a dynamic address, use "::" or an empty string. <p><state> (Connection state)</p> <ul style="list-style-type: none"> • 0—Disconnected • 1—Connecting • 2—Connected • 3—Idle, down counting for disconnection • 4—Disconnecting

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KCNXDOWN	<p>Bring down PDP connection Bring down a specific PDP connection. Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+KCNXDOWN=<cnx_cnf>[,<mode>] Response: OK Purpose: Bring down the specified connection. • Query List: AT+KCNXDOWN=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><cnx_cnf> (PDP context configuration)</p> <ul style="list-style-type: none"> • Specifies a particular PDP context configuration that has been defined by +CGDCONT. (e.g. <cnx_cnv=3> corresponds to CID=3 in +CGDCONT and +CGACT) <p><mode> (Effect of bring down connection)</p> <ul style="list-style-type: none"> • 0—Cancels the reservation of the activated PDP connection that was previously configured by +KCNXUP. • 1—Similar to <mode>=0, but deactivates the PDP connection even if the active session exists.
+KCNXPROFILE	<p>Query/Set default PDP context Display or set the default PDP profile that will be used by +KTCPCFG and +KUDPCFG if those commands do not specify a context. Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+KCNXPROFILE=<cnx_cnf> Response: OK Purpose: Set the current profile. • Query: AT+KCNXPROFILE? Response: +KCNXPROFILE: <cnx_cnf> OK Purpose: Display the current profile. • Query List: AT+KCNXPROFILE=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><cnx_cnf> (PDP context configuration)</p> <ul style="list-style-type: none"> • Specifies a particular PDP context configuration that has been defined by +CGDCONT. (e.g. <cnx_cnv=3> corresponds to CID=3 in +CGDCONT and +CGACT)

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KCNXTIMER	<p>Configure TCP/UDP Connection Timer Configure the connection timer for TCP/UDP connections. Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+KCNXTIMER=<cnx_cnf> [,<tim1>][,<nbtrial>][,<tim2>][,<idletime>]]] Response: OK Purpose: Configure the timer for the specified connection. • Query: AT+KCNXTIMER? Response: +KCNXTIMER: <cnx_cnf>, <tim1>, <nbtrial>, <tim2>, <idletime> [...] OK Purpose: Display configured connection timers. • Query List: AT+KCNXTIMER=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><cnx_cnf> (PDP context configuration)</p> <ul style="list-style-type: none"> • Specifies a particular PDP context configuration that has been defined by +CGDCONT. (e.g. <cnx_cnf=3> corresponds to CID=3 in +CGDCONT and +CGACT) <p><tim1> (PDP activation reattempt timer, in seconds)</p> <ul style="list-style-type: none"> • Integer • Valid range: 1–120 • Default: 30 seconds • If the module fails to activate the PDP context, this timer starts. When this timer expires, the module will try again to activate the PDP context. <p><nbtrial> (Max number of PDP activation attempts)</p> <ul style="list-style-type: none"> • Integer • Valid range: 1–4 • Default: 2 <p><tim2> (Connection attempt timer, in seconds)</p> <ul style="list-style-type: none"> • Integer • Valid range: 1–300 • Default: 60 seconds • 0—Deactivated (connection will not close by itself) • For client sockets, the module will try to connect to the server within <tim2> seconds. If <tim2> expires, the module gives up the connection. <p><idletime> (Max idle time, in seconds)</p> <ul style="list-style-type: none"> • Integer • Valid range: 0–1800 • Default: 30 seconds • When all sessions are closed, module can stay idle for <idletime> while waiting for another session to connect and reuse the PDP context. If this timer expires, the module tries to deactivate the PDP context.

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KCNXUP	<p>Bring up PDP connection Bring up a specific PDP connection.</p> <p>Notes:</p> <ul style="list-style-type: none"> • The activated connection is reserved—it remains up even after the last session is closed. • If this command is not used to reserve the connection, the context will be brought down after the last session is closed unless +KCNXDOWN is used. • The specified connection will not be requested if the +KCNXCFG and +CGDCONT configurations are different. • When the connection is brought up, it sets the PDP into modemData and writes it back into the modem. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+KCNXUP=<cnx_cnf> Response: OK Purpose: Bring up the specified connection. • Query List: AT+KCNXUP=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><cnx_cnf> (PDP context configuration)</p> <ul style="list-style-type: none"> • Specifies a particular PDP context configuration that has been defined by +CGDCONT. (e.g. <cnx_cnf=3> corresponds to CID=3 in +CGDCONT and +CGACT)

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KHTTPCFG	<p>Configure HTTP connection Set or display HTTP connection configuration.</p> <p>Notes:</p> <ul style="list-style-type: none"> • <http_port> and <http_server> define the port and the IP address of the remote server one wants to connect • This command can be used before setting up +KCNXCFG. Note however that the latter is required to start the connection properly • For <af> = 1 (IPV6), server address (<http_server>) in IP address string format can be optionally quoted with square brackets "[]", e.g. [FEDC:BA98:7654:3210:FEDC:BA98:7654:3210] <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+KHTTPCFG=<cnx_cnf>, <http_server>[, <http_port>[, <http_version>[, <login>[, <password>[, <start>[, <af>[, <cipher_index>]]]]]]] Response: +KHTTPCFG: <session_id> OK or +CME ERROR: <err> • Purpose: Configure a connection and receive an HTTP session ID. • Query: AT+KHTTPCFG? Response: +KHTTPCFG: <session_id>, <cnx_cnf>, <http_server>, <http_port>, <http_version>, <login>, <password>, <started>, <af>, <cipher_index> OK Purpose: Display the configurations for all HTTP sessions. • Query List: AT+KHTTPCFG=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><cnx_cnf> (PDP context configuration)</p> <ul style="list-style-type: none"> • Specifies a particular PDP context configuration that has been defined by +KCNXCFG. (e.g. <cnx_cnf=3> corresponds to CID=3 in +CGDCONT and +CGACT) • Index of set of parameters for configuring one HTTP connection (see +KCNXCFG) • Note—Maximum number of simultaneous connections is 2. <p><session_id> (HTTP session index)</p> <ul style="list-style-type: none"> • Integer <p><http_server> (IP address string or explicit name of the remote server)</p> <ul style="list-style-type: none"> • String <p><http_port> (Port on remote server)</p> <ul style="list-style-type: none"> • Valid range: 1–65535 • Default: 80 <p><http_version> (HTTP version)</p> <ul style="list-style-type: none"> • 0—HTTP 1.1 (Default) • 2—HTTP 1.1 over TLS (HTTPS) <p><login> (User name to be used during the HTTP connection)</p> <ul style="list-style-type: none"> • String <p>(Continued on next page)</p>

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KHTTPCFG (continued)	<p>Configure HTTP connection (continued)</p> <p><password> (Password to be used during the HTTP connection)</p> <ul style="list-style-type: none"> String <p><start> (When to start the HTTP connection)</p> <ul style="list-style-type: none"> 0—Start the HTTP connection later using +KHTTPCNX 1—Start the HTTP connection immediately <p><started> (HTTP connectdion start status)</p> <ul style="list-style-type: none"> 0—Connection has not started yet 1—Connection has started <p><af> (IP address family type used for connection)</p> <ul style="list-style-type: none"> Valid values: <ul style="list-style-type: none"> 0—IPv4 (Default) 1—IPv6 <p><cipher_suite> (Cipher suite profile index to use for a secured socket)</p> <ul style="list-style-type: none"> Integer value Defined by +KSSLCRYPTO
+KHTTPCLOSE	<p>Close HTTP connection</p> <p>Close an HTTP session.</p> <p>Notes:</p> <ul style="list-style-type: none"> This command has been developed to provide the IMEI SV and Serial Number through an AT command and it can work without a SIM. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT+KHTTPCLOSE=<session_id>[,<keep_cfg>] Response: OK or CME ERROR: <err> Purpose: Close the specified HTTP connection. Query List: AT+KHTTPCLOSE=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><session_id> (HTTP session index)</p> <ul style="list-style-type: none"> Integer <p><keep_cfg> (Delete/keep session configuration after closing)</p> <ul style="list-style-type: none"> 0—Delete the session configuration 1—Keep the session configuration

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KHTTPDEL	<p>Delete configured HTTP session</p> <p>Notes:</p> <ul style="list-style-type: none"> Session must be closed using +KHTTPCLOSE before using this command. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT+KHTTPDEL=<session_id> Response: OK or +CME ERROR: <err> Purpose: Delete the specified HTTP connection. Query List: AT+KHTTPDEL=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><session_id> (HTTP session index)</p> <ul style="list-style-type: none"> Integer

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KHTTPGET	<p>Get HTTP server information Get the server information for an HTTP session.</p> <p>Notes:</p> <ul style="list-style-type: none"> The user can abort the download by sending "End of Data pattern" from the host. In this case, the module will end the transfer by transmitting the EOF followed by NO CARRIER. Download can also be aborted (disconnected) by +++ or DTR. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT+KHTTPGET=<session_id>,<request_uri>[, <show_resp>] Response: CONNECT ...<EOF_pattern> OK or NO CARRIER +CME ERROR: <err> +KHTTP_ERROR: <session_id>,<http_notif> Purpose: Get server information for the specified HTTP session. Query List: AT+KHTTPGET=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><session_id> (HTTP session index)</p> <ul style="list-style-type: none"> Integer <p><request_uri> (Information URL to get during the HTTP connection)</p> <ul style="list-style-type: none"> String <p><http_notif> (Cause of HTTP connection failure)</p> <ul style="list-style-type: none"> 4—DNS error 5—HTTP connection error due to internal trouble 6—HTTP connection timeout 7—Flash access trouble 8—Flash memory full 9—Triple-plus (+++) error (switch to command mode) 10—HTTP got no data 11—HTTP got partial data <p><show_resp> (Show or hide HTTP response and HTTP headers)</p> <ul style="list-style-type: none"> 0—Do not show response and headers 1—Show response and headers (Default)

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KIOPT	<p>Configure general protocol options General IP protocol option configuration.</p> <p>Notes:</p> <ul style="list-style-type: none"> • Default setting of <option_id>=3 is (<stop_on_error>=0; <stop_on_peer>=0) after module boot-up. This means a PDP connection is requested to stop only when a session is closed by an AT command (e.g. +KTCPCLOSE). • Threshold values (<send_size_v4>, <send_size_v6>) control the minimum size of data received from the AT terminal to be buffered within the <wait_time> timeout period. When the threshold is reached or after timeout, the buffered data is sent to the socket layer for transmission. For UDP, data is sent as a UDP packet. For TCP, data is copied to the socket first-in-first-out buffer for transmission, but packet segmentation is not guaranteed to be <send_size>. • By default, the maximum transmission unit (MTU) for <send_size_v4> and <send_size_v6> is 1500 bytes. The network operator can set a lower value, in which case the upper limit of the minimum data packet size is the one set by the operator (e.g. if the network operator MTU is 1318, then the maximum <send_size_v4> for TCP is 1318). • <send_size_v4> and <send_size_v6> impact the detection of <EOF_pattern>. For details, refer to +KPATTERN notes. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution (<option_id> = 0): AT+KIOPT=<option_id>, <proto>, <wait_time>[, <send_size_v4>[, <send_size_v6>]] Response: OK or CME ERROR <err> Purpose: Configure wait time, and data packet size thresholds • Execution (<option_id> = 1 or 2): AT+KIOPT=<option_id> Response: OK or CME ERROR <err> Purpose: Not for general use. Provided for internal use or compatibility purposes. • Execution (<option_id> = 3): AT+KIOPT=<option_id>, <stop_on_error>, <stop_on_peer> Response: OK or CME ERROR <err> Purpose: Configure action to take when PDP connection deactivates. • Execution (<option_id> = 4): AT+KIOPT=<option_id>,<ssl_ver> Response: OK or CME ERROR <err> Purpose: Not for general use. Provided for internal use or compatibility purposes. <p>(Continued on next page)</p>

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KIOPT (continued)	<p>Configure general options (continued)</p> <ul style="list-style-type: none"> • Query: AT+KIOPT? Response: +KIOPT: +KIOPT: 0, <proto>, <wait_time>, <send_size_v4>, <send_size_v6> ... +KIOPT: 3, <stop_on_error>, <stop_on_peer> OK • Purpose: Display the general options. • Query List: AT+KIOPT=? • Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><option_id> (Option to configure)</p> <ul style="list-style-type: none"> • 0—Wait time, send size threshold configuration • 1—Internal use or compatibility purposes • 2—Internal use or compatibility purposes • 3—PDP connection deactivated behavior • 4—Internal use or compatibility purposes <p><proto> (Protocol)</p> <ul style="list-style-type: none"> • String format • "TCPC"—TCP client session • "TCPS"—TCP server session • "UDPC"—UDP client session • "UDPS"—UDP server session • "HTTP"—HTTP client session • "HTTPS"—HTTPS client session • "TCP"—Both TCP client and server sessions • "UDP"—Both UDP client and server sessions <p><wait_time> (Timeout, in 100 ms units)</p> <ul style="list-style-type: none"> • Timeout for configuring the packet segmentation on the IP network side. After timeout, buffered data will be sent to the peer regardless of data packet size. • Valid range: <ul style="list-style-type: none"> • UDP: 1–100. Default=2 • TCP: 0–100. Default=1 Note: <wait_time>=0 has the same effect as <wait_time>=1 due to the limitation from +KPATTERN detection timing. <p><send_size_v4> (Data packet size for IPv4 sessions)</p> <ul style="list-style-type: none"> • Specifies size of data packets to be sent to the peer. • Valid range: <ul style="list-style-type: none"> • UDP: 8–1472. Default=1020 • TCP: 0, 8–1440. Default=0 (disabled) Note: <send_size_v4>=0 uses wait time of 100 ms. <p><send_size_v6> (Data packet size for IPv6 sessions)</p> <ul style="list-style-type: none"> • Specifies size of data packets to be sent to the peer. • Valid range: <ul style="list-style-type: none"> • UDP: 8–1452. Default=1020 • TCP: 0, 8–1440. Default=0 (disabled) Note: <send_size_v4>=0 uses wait time of 100 ms. <p>(Continued on next page)</p>

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KIOPT (continued)	<p>Configure general options (continued)</p> <p><stop_on_error> (PDP connection deactivation behavior when session closed due to any error)</p> <ul style="list-style-type: none"> • 0—Do not request to stop the connection • 1—Request to stop the connection <p><stop_on_peer> (PDP connection deactivation behavior when session closed by peer/server)</p> <ul style="list-style-type: none"> • 0—Do not request to stop the connection • 1—Request to stop the connection
+KPATTERN	<p>Set/query the custom end of data/file pattern</p> <p>Display or set a custom 'end of data' pattern to be used to notify the end of data/file during data/file transfer.</p> <p>Notes:</p> <ul style="list-style-type: none"> • When setting a pattern, make sure to select a pattern that is appropriate for the data being transferred. (e.g. Numeric pattern for text files; readable string for binary files; etc.) • After the last data packet is received, the end of data pattern will be detected within 100 ms or the <wait_time> set by +KIOPT, whichever is longer. • The received data is stored with buffer size <send_size_v4> or <send_size_v6>; if the buffer is smaller than the <EOF_pattern>, the pattern will not be detected (because it will be split between packets). The user application should ensure the value of <send_size_v4> or <send_size_v6> (set using +KIOPT) is larger than the size of <EOF_pattern>. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+KPATTERN=<EOF_pattern> Response: OK or +CME ERROR <err> Purpose: Set the end of data file pattern as indicated. • Query: AT+KPATTERN? Response: +KPATTERN: <EOF_pattern> OK Purpose: Display the end of data file pattern. • Query List: AT+KPATTERN=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><EOF_pattern> (Pattern sent at end of data/file transfer)</p> <ul style="list-style-type: none"> • String format; non-printable characters are allowed • Default pattern: "--EOF--Pattern--"

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KSSLCRYPTO	<p>Cipher suite configuration</p> <p>Note: Refer to Table 16-3 for the list of cipher suites supported by the RC76xx module.</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+KSSLCRYPTO=<profile_id>,<mkey_algo>,<auth_algo>,<enc_algo>,<mac_algo>,<tls_ver>,<auth> Response: OK • Query: AT+KSSLCRYPTO? Response: +KSSLCRYPTO: <profile_id>,<mkey_algo>,<auth_algo>,<enc_algo>,<mac_algo>,<tls_ver>,<auth>[...] OK • Purpose: Display the end of data file pattern. • Query List: AT+KSSLCRYPTO=? +KSSLCRYPTO:<profile_id>,<mkey_Algo>,<auth_algo>,<enc_algo>,<mac_algo>,<tls_ver>,<auth> OK <p>Notification format: +KTCP_DATA: <session_id>,<ndata_available>[,<data>]</p> <p>Parameters:</p> <p><profile_id> (A set of parameters for configuring one SSL profile)</p> <ul style="list-style-type: none"> • Integer <p><mkey_algo> (Key exchange algorithm selection)</p> <ul style="list-style-type: none"> • Integer • 1—RSA • 8—ECDHE <p><auth_algo> (Authentication algorithm selection)</p> <ul style="list-style-type: none"> • Integer • 1—RSA • 2—ECDSA <p><enc_algo> (Encryption algorithm selection)</p> <ul style="list-style-type: none"> • Integer • 16—AES-128-CCM • 32—AES-256-CCM • 64—AES-128-CBC • 256—AES-128-CCM-8 • 512—AES-256-CCM-8 • 8192—AES-128-GCM • 16384—AES-256-GCM <p><mac_algo> (Message authentication code for the algorithm selection)</p> <ul style="list-style-type: none"> • Integer • 0—RSA • 4—ECDHE • 8—ECDHE <p>(Continue on the next page)</p>

Table 16-2: Protocol Command Details (Continued)

Command	Description
	<p data-bbox="440 310 743 338"><tls_ver> (Version selection)</p> <ul data-bbox="472 338 634 422" style="list-style-type: none"><li data-bbox="472 338 586 365">• Integer<li data-bbox="472 365 634 392">• 4—TLS 1.2<li data-bbox="472 392 488 422">• <p data-bbox="440 443 688 470"><auth> (Authentication)</p> <ul data-bbox="472 470 1154 625" style="list-style-type: none"><li data-bbox="472 470 574 497">• String<li data-bbox="472 497 732 525">• 0—No authentication<li data-bbox="472 525 753 552">• 1—Authenticate server<li data-bbox="472 552 899 579">• 2—Provide client certificate to server<li data-bbox="472 579 1154 625">• 3—Authenticate server and provide client certificate to server

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KSSLCFG	<p>SSL Configuration</p> <p>Usage:</p> <ul style="list-style-type: none"> • Assignment: AT+KSSLCFG=<option_id>,<option> <p>Response: If <option_id> = 0: AT+KSSLCFG=<option_id>,<TLS Version> OK</p> <p style="padding-left: 40px;">or If <option_id> = 1: AT+KSSLCFG=<option_id>,<Random Seed> OK</p> <p style="padding-left: 40px;">or If <option_id> = 2: AT+KSSLCFG=<option_id>,<Session Mode> OK</p> <p>Query: AT+KSSLCFG?</p> <p>Response: +KSSLCFG:0,<TLS Version> +KSSLCFG:2,<Session Mode> OK</p> <p>Purpose: Display the end of data file pattern.</p> <ul style="list-style-type: none"> • Query List: AT+KSSLCFG=? +KSSLCFG:<option id>,<option> OK <p>Parameters:</p> <p><option_id></p> <p>Integer</p> <ul style="list-style-type: none"> • 0—Specify a TLS version to be used for the hand shake • 1—Set up random seed • 2—Specify session mode <p><TLS Version></p> <ul style="list-style-type: none"> • Integer • 0—Highest possible • 3—TLS 1.2 <p><Random Seed> (String to be added into the entropy of the random number generator)</p> <ul style="list-style-type: none"> • String <p><Session Mode></p> <ul style="list-style-type: none"> • Integer • 0—Automatic • 1—Always start a new session (not supported)

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KTCP_DATA (notification)	<p>Incoming Data through TCP connection—Unsolicited notification Unsolicited notification indicating data is incoming.</p> <p>Notes:</p> <ul style="list-style-type: none"> • As soon as the connection is established, the module can receive data through the TCP socket. This notification is sent when data are available in the receive buffer. • This notification is sent for each TCP packet received sequentially. Notification of the following received packet is sent only when the current notification has been read with a +KTCP_RCV command. • When <data_mode> is set to 1, <ndata_available> will range from 1 to 1500 in the URC. If the user application sends over 1500 bytes of data to the module, the module will display those data with several URCs. <p>Notification format: +KTCP_DATA: <session_id>,<ndata_available>[,<data>]</p> <p>Parameters:</p> <p><session_id> (TCP session index)</p> <ul style="list-style-type: none"> • Integer • Maximum value: 32 <p><ndata_available> (Amount of data to be read)</p> <ul style="list-style-type: none"> • Integer • For <data_mode>=0, maximum number of bytes to be read in the TCP receive buffer. • For <data_mode>=1, maximum number of bytes to be read in <data> <p><data> (Data, in octet)</p> <ul style="list-style-type: none"> • String • Length of data is specified in <ndata_available>.
+KTCP_IND (notification)	<p>TCP status—Unsolicited notification Notification of TCP session status.</p> <p>Notification format: +KTCP_IND: <session_id>,<status></p> <p>Parameters:</p> <p><session_id> (TCP session index)</p> <ul style="list-style-type: none"> • Integer • Maximum value: 32 <p><status> (TCP session status)</p> <ul style="list-style-type: none"> • 1—Session is set up and ready for operation

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KTCP_SRVREQ (notification)	<p>Incoming client connection request—Unsolicited notification Notification received when a client requests a connection to the server.</p> <p>Notes:</p> <ul style="list-style-type: none"> • This notification is sent when a client requests a connection to the server. The connection is automatically accepted. • The created session is driven as any other TCP session with its own session ID. Use +KTCPSND, +KTCPCRV, +KTCPCLOSE, etc. to provide the service associated to this TCP server. • The TCP server corresponding to the session ID is still able to receive connection requests from other clients. These requests are notified with +KTCP_SRVREQ. • The client IP address and port can also be checked using AT+KTCPCFG? after the client is connected to the TCP server. <p>Notification format: +KTCP_SRVREQ: <session_id>, <subsession_id>, <client_ip>, <client_port></p> <p>Parameters:</p> <p><session_id> (TCP session index)</p> <ul style="list-style-type: none"> • Integer • Maximum value: 32 <p><subsession_id> (Newly created TCP session index)</p> <ul style="list-style-type: none"> • Integer • Maximum value: 32 <p><client_ip> (IP address of incoming socket)</p> <ul style="list-style-type: none"> • String <p><client_port> (Port of the incoming client)</p> <ul style="list-style-type: none"> • Valid range: 0–65535 <p>Example(s):</p> <ul style="list-style-type: none"> • Configure the module to TCP servers AT+KCNXCFG=0,"GPRS","szsjmc.gd"; +KTCPCFG=0,1,,179 +KTCPCFG: 1 OK AT+KCNXCFG=0,"GPRS","szsjmc.gd"; +KTCPCFG=0,1,,180 +KTCPCFG: 2 OK • Start the TCP servers - listen on port 179 AT+KTCPN=1 OK - listen on port 180 AT+KTCPN=2 OK <p>(Continued on next page)</p>

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KTCP_SRVREQ (notification) continued	<p>Incoming client connection request—Unsolicited notification (continued)</p> <ul style="list-style-type: none"> Show the TCP servers' IP address—Incoming connection request from remote client, shows ip address and port of remote client AT+KCGPADDR +KCGPADDR: 0,"192.168.1.49" OK <p>// incoming a connection request from "192.168.0.32" via listening port 179, the remote port is 4614 +KTCP_SRVREQ: 1,3,"192.168.0.32",4614</p> <p>// incoming a connection request from "10.10.10.110" via listening port 180, the remote port is 4665 +KTCP_SRVREQ: 2,4,"10.10.10.110",4665</p> <p>// incoming a connection request from the same ip via the same listening port, the remote port is 4668 +KTCP_SRVREQ: 2,5,"10.10.10.110",4668</p> <p>// incoming a connection request from "192.168.1.117" via listening port 179, the remote port is 1739 +KTCP_SRVREQ: 1,6,"192.168.1.117",1739</p> <p>// the connection of sub session id 4 (on listening port 180) is closed. +KTCP_NOTIF: 4,4</p> <p>// incoming a connection request from "10.10.10.8" via listening port 180, the remote port is 4672 +KTCP_SRVREQ: 2,4,"10.10.10.8",4672</p>

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KTCPCFG	<p>Configure TCP connection Set or display the TCP connection configuration.</p> <p>Notes:</p> <ul style="list-style-type: none"> If the socket is defined as a <CLIENT> socket, <tcp_port> and <tcp_remote_address> define the port and IP address of the remote server to be connected. For child session, the <data_mode> will be kept the same as the server socket's setting. This command can be used before setting up the configuration with +KCNXCFG, but the configuration command is required to start the connection properly. Connection timeout for TCP socket is ~9 seconds with 3 retransmissions with 3 seconds delay. For the <restore_on_boot> parameter, only the first server session is restored. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT+KTCPCFG=[<cnx_cnf>], <mode>, [<tcp_remote_address>], <tcp_port>[,<source_port>][,<data_mode>][,<URC_ENDTCP_enable>][,<af>][,<cipher_suite>][,<restore_on_boot>]]]]]] Response: +KTCPCFG: <session_id> OK Purpose: Configure a connection and receive a TCP session ID. Query: AT+KTCPCFG? Response: +KTCPCFG: <session_id>,<status>,<cnx_cnf>,<mode>[,<serverID>], <tcp_remote_address>, <tcp_port>[,<source_port>], <data_mode>, <URC_ENDTCP_enable>, <af>, <cipher_index>[,<restore_on_boot>][...] OK Purpose: Display the configurations for all TCP sessions. Query List: AT+KTCPCFG=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><cnx_cnf> (PDP context configuration)</p> <ul style="list-style-type: none"> Integer Index of set of parameters for configuring one TCP session (see +KCNXCFG) <p><session_id> (TCP session index)</p> <ul style="list-style-type: none"> Integer Maximum value: 32 <p><mode> (Connection mode)</p> <ul style="list-style-type: none"> 0—Client 1—Server 2—Child (generated by server sockets) 3—Secure client <p>(Continued on next page)</p>

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KTCPCFG (continued)	<p>Configure TCP connection (continued)</p> <p><tcp_remote_address> (IP address string or explicit name of remote server)</p> <ul style="list-style-type: none"> • String • For server configuration, this parameter is left blank <p><tcp_port> (TCP port number)</p> <ul style="list-style-type: none"> • Listening port for a server configuration. • Valid range: 1–65535 <p><status> (Connection state of the selected socket)</p> <ul style="list-style-type: none"> • 0—Disconnected • 1—Connected <p><serverID> (Server session ID index)</p> <ul style="list-style-type: none"> • Only for sockets in Child mode • Integer value <p><source_port> (Local TCP port number)</p> <ul style="list-style-type: none"> • Valid range: 0–65535 • For server configuration, this parameter is left blank <p><data_mode> (Enable/disable display of <data> in URC)</p> <ul style="list-style-type: none"> • 0—Do not display (Default) • 1—Display (This option is not supported.) <p><URC_ENDTCP_enable> (Enable/disable display of URC "+KTCP_ACK")</p> <ul style="list-style-type: none"> • 0—Do not display (Default) • 1—Display <p><af> (IP address family type used for connection)</p> <ul style="list-style-type: none"> • Valid values: <ul style="list-style-type: none"> • 0—IPv4 • 1—IPv6 <p><cipher_index> (Cipher suite profile index to use for a secured socket)</p> <ul style="list-style-type: none"> • Integer value • Defined by +KSSLCRYPTO <p><restore_on_boot> (Restore server session on boot (only for server socket))</p> <ul style="list-style-type: none"> • 0—First server session is not restored on boot. (Default) • 1—First server session is restored on boot.

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KTCPCLOSE	<p>Close current TCP connection</p> <p>Close a TCP socket and, if no other sessions are running, then release the PDP context.</p> <p>Notes:</p> <ul style="list-style-type: none"> • AT+KTCPDEL=<session_id> can be used to delete the socket configuration after it has been closed. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+KTCPCLOSE=<session_id>[,<closing_type>] Response: OK or +CME ERROR: <err> NO CARRIER +KTCP_NOTIF: <session_id>,<tcp_notif> • Purpose: Close the specified TCP connection. • Query List: AT+KTCPCLOSE=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><session_id> (TCP session index)</p> <ul style="list-style-type: none"> • Integer • Maximum value: 32 <p><closing_type> (Method used to close the TCP connection)</p> <ul style="list-style-type: none"> • 1—Close TCP connection properly. Data sent to the module by +KTCPSND will be sent to the TCP server and acknowledged before the socket is closed. <p><tcp_notif> (Cause of TCP connection failure)</p> <ul style="list-style-type: none"> • See +KTCPCNX for details

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KTCP CNX	<p>Start TCP connection</p> <p>Connect to a remote server or listen to a bound port, depending on the selected mode of <session_id></p> <p>Notes:</p> <ul style="list-style-type: none"> The socket connection will not be requested when the specified PDP session is active and the +KCNXCFG and +CGDCONT configurations are not the same. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT+KTCP CNX=<session_id> Response: OK or +CME ERROR: <err> +KTCP_NOTIF: <session_id>,<tcp_notif> Purpose: Start a connection on the specified TCP session. Query List: AT+KTCP CNX=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><session_id> (TCP session index)</p> <ul style="list-style-type: none"> Integer Maximum value: 32 <p><tcp_notif> (Cause of TCP connection failure)</p> <ul style="list-style-type: none"> 0—Network error 1—No more sockets available; max. number already reached 2—Memory problem 3—DNS error 4—TCP disconnection by the server or remote client 5—TCP connection error 6—Generic error 7—Fail to accept client requests 8—Data sending is OK but +KTCP SNDR was waiting more or less characters 9—Bad session ID 10—Session is already running 11—All sessions are used 12—Socket connection timeout error 13—SSL connection error 14—SSL initialization error

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KTCPDEL	<p>Delete configured TCP session</p> <p>Notes:</p> <ul style="list-style-type: none"> Session must be closed using +KTCPCLOSE before using this command. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT+KTCPDEL=<session_id> Response: OK or +CME ERROR: <err> Purpose: Delete the specified TCP connection. Query List: AT+KTCPDEL=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><session_id> (TCP session index)</p> <ul style="list-style-type: none"> Integer Maximum value: 32

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KTCPRCV	<p>Receive data through TCP connection Receive data through a previously opened TCP socket.</p> <p>Notes:</p> <ul style="list-style-type: none"> • <ndata> indicates the max data number that the terminal wishes to receive. If the TCP socket contains more data than <ndata> bytes, then only <ndata> bytes will be received. If the TCP socket contains less data than <ndata> bytes, then only TCP socket's data will be received. • <EOF pattern> would be added at the end of data automatically. • When <ndata> (max value) bytes or only available data in the TCP socket have been received, the module returns to command state and returns OK. • It is highly recommended to configure the module for hardware flow control using AT&K3 before using this command. • Refer to AT&D for the behavior of DTR drop. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+KTCPRCV=<session_id>,<ndata> Response: CONNECT ...<EOF_pattern> OK or +KTCP_NOTIF: <session_id>,<tcp_notif> • Purpose: Receive <ndata> bytes of data from the specified socket. • Query List: AT+KTCPRCV=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><session_id> (TCP session index)</p> <ul style="list-style-type: none"> • Integer • Maximum value: 32 <p><ndata> (Number of bytes that device wants to receive)</p> <ul style="list-style-type: none"> • Max value: 4294967295 <p><tcp_notif> (Cause of TCP connection failure)</p> <ul style="list-style-type: none"> • See +KTCPNMX for details

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KTCPSND	<p>Send data through TCP connection Send data through a previously opened TCP socket.</p> <p>Notes:</p> <ul style="list-style-type: none"> • All the data will be sent out ignoring <ndata>. If data sent is not equal to <ndata> then +KTCP_NOTIF will be displayed. • <ndata> is the data size without <EOF pattern>. • It is highly recommended to configure the module for hardware flow control using AT&K3 before using this command. • Refer to AT&D for the behavior of DTR drop. • The data session can be ended by <EOF pattern>, +++ or DTR. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+KTCPSND=<session_id>,<ndata> Response: CONNECT OK or NO CARRIER +CME ERROR: <err> +KTCP_NOTIF: <session_id>,<tcp_notif> • Purpose: Send <ndata> bytes of data to the specified socket. • Query List: AT+KTCPSND=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><session_id> (TCP session index)</p> <ul style="list-style-type: none"> • Integer • Maximum value: 32 <p><ndata> (Number of bytes that device will send)</p> <ul style="list-style-type: none"> • Max value: 4294967295 <p><tcp_notif> (Cause of TCP connection failure)</p> <ul style="list-style-type: none"> • See +KTCPCNX for details

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KTCPSTART	<p>Start TCP connection in Direct Data Flow Start a TCP connection in Direct Data Flow.</p> <p>Notes:</p> <ul style="list-style-type: none"> • Command is used to send and receive data bytes through a TCP socket. • It is highly recommended to configure the module for hardware flow control using AT&K3 before using this command. • Refer to AT&D for the behavior of DTR drop. • Only one +KTCPSTART session can be used. • Can be used in 07.10 multiplexer. • If the session is successfully connected by +KTCPCNX, this command does not restart the connection and the module directly enters direct data flow. • The data session can also be ended by <EOF_pattern>, +++, or DTR. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+KTCPSTART=<session_id> Response: CONNECT OK or +CME ERROR: <err> +KTCP_NOTIF: <session_id>,<tcp_notif> • Purpose: Start a TCP session in direct data flow. • Query: AT+KTCPSTART? Response: OK Purpose: • Query List: AT+KTCPSTART=? Response: OK Purpose: <p>Parameters:</p> <p><session_id> (TCP session index)</p> <ul style="list-style-type: none"> • Integer • Maximum value: 32 <p><tcp_notif> (Cause of TCP connection failure)</p> <ul style="list-style-type: none"> • See +KTCPCNX for details

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KTCPSTAT	<p>Get TCP socket status</p> <p>Notes:</p> <ul style="list-style-type: none"> Command returns +CME ERROR: 910 (Bad Session ID) for undefined <session_id>s. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution (for all TCP session IDs): <ul style="list-style-type: none"> AT+KTCPSTAT Response: +KTCPSTAT: <session_id>, <status>, <tcp_notif>, <rem_data>, <rcv_data> [...] OK Purpose: Display socket statuses for all TCP sessions. Execution (single TCP session ID): <ul style="list-style-type: none"> AT+KTCPSTAT=<session_id> Response: +KTCPSTAT: <status>, <tcp_notif>, <rem_data>, <rcv_data> OK Purpose: Display socket status for the specified TCP session. Query: AT+KTCPSTAT? Response: OK Purpose: Query List: AT+KTCPSTART=? Response: OK Purpose: <p>Parameters:</p> <p><session_id> (TCP session index)</p> <ul style="list-style-type: none"> Integer Maximum value: 32 <p><status> (TCP socket state)</p> <ul style="list-style-type: none"> 0—Socket not defined, use +KTCPCFG to create a TCP socket 1—Socket is defined, but not used 2—Socket is opening and connecting to the server, cannot be used 3—Connection is up, socket can be used to send/receive data 4—Connection is closing, cannot be used, wait for <status>=5 5—Socket is closed <p><tcp_notif> (TCP connection status)</p> <ul style="list-style-type: none"> -1—Socket/connection is OK ≥0—TCP connection failure. See +KTCPCNX for details. <p><rem_data> (Remaining bytes in socket buffer, waiting to be sent)</p> <ul style="list-style-type: none"> String <p><rcv_data> (Received bytes, can be read with +KTCPCRV)</p> <ul style="list-style-type: none"> String

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KUDP_DATA (notification)	<p>Incoming Data through UDP connection—Unsolicited notification Unsolicited notification indicating data is incoming.</p> <p>Notes:</p> <ul style="list-style-type: none"> • As soon as the UDP socket is created, the module can receive data through this socket. This notification is sent when data are available in the receive buffer. • This notification will be sent one time. When <data_mode> was set to 0 (do not display data in URC), the controlling software must read the buffer with +KUDPRCV to activate the notification again. • When <data_mode> was set to 1, <ndata_available> will range from 1 - 1500 in the URC. If the user application sends over 1500 bytes of data to the module, the module will display those data with several URCs. It is possible for other applications (e.g. from Windows) to send more than 1472 bytes UDP packets to the module but the packet will be segmented and reassembled by the network stack. • When <data_mode> is set to 1, URC +KUDP_RCV will not be displayed after +KUDP_DATA. • When <data_mode> was set to 1, the fields <udp remote address> and <udp remote port> will be displayed in URC +KUDP_DATA. When <data_mode> was set to 0, they will be displayed in URC +KUDP_RCV. <p>Notification format: +KUDP_DATA: <session_id>,<ndata_available>[,<udp_remote_address>,<udp_remote_port>,<data>]</p> <p>Parameters:</p> <p><session_id> (UDP session index)</p> <ul style="list-style-type: none"> • Integer <p><ndata_available> (Amount of data to be read)</p> <ul style="list-style-type: none"> • String <p><udp_remote_address> (IP address string of remote host)</p> <ul style="list-style-type: none"> • String <p><udp_remote_port> (Remote UDP port)</p> <ul style="list-style-type: none"> • Valid range: 0–65535 <p><data> (Data, in octet)</p> <ul style="list-style-type: none"> • String • Length of data is specified in <ndata_available>.
+KUDP_IND (notification)	<p>UDP status—Unsolicited notification Notification of UDP session status.</p> <p>Notification format: +KUDP_IND: <session_id>,<status></p> <p>Parameters:</p> <p><session_id> (UDP session index)</p> <ul style="list-style-type: none"> • Integer <p><status> (UDP session status)</p> <ul style="list-style-type: none"> • 1—Session is set up and ready for operation

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KUDPCFG	<p>Configure UDP connection Set or display UDP connection configuration.</p> <p>Notes:</p> <ul style="list-style-type: none"> For UDP socket in server mode, it is bound to a defined port number, incoming connection are notified by +KUDP_DATA. If remote address and port are given, they are saved for use in +KUDPSND. Maximum <session_id> is 32. +KCNXCFG configuration should be set up in order to start the connection properly. The socket connection will not be requested when the specified session is active and the +KCNXCFG and +CGDCONT configurations are not the same. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT+KUDPCFG=[<cnx_cnf>], <mode> [, [<port>] [, [<data_mode>] [, [<udp_remote_address>] [, [<udp_port>] [, [<af>] [, [<restore_on_boot>]]]]]]] Response: +KUDPCFG: <session_id> OK or +CME ERROR: <err> +KUDP_NOTIF: <session_id>, <udp_notif> Purpose: Configure a connection and receive a UDP session ID. Query: AT+KUDPCFG? Response: +KUDPCFG: <session_id>, <cnx_cnf>, <mode>, <port>, <data_mode>, <udp_remote_address>, <udp_port>, <af>, <restore_on_boot> [...] OK Purpose: Display the configurations for all UDP sessions. Query List: AT+KUDPCFG=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><session_id> (UDP session index)</p> <ul style="list-style-type: none"> Integer <p><mode> (Connection mode)</p> <ul style="list-style-type: none"> 0—Client 1—Server <p><port></p> <ul style="list-style-type: none"> Valid range: 0–65535 (0 = random) <p><cnx_cnf> (PDP context configuration)</p> <ul style="list-style-type: none"> Integer Index of set of parameters for configuring one UDP session (see +KCNXCFG) <p>(Continued on next page)</p>

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KUDPCFG (continued)	<p>Configure UDP connection (continued)</p> <p><udp_notif> (Cause of UDP connection failure)</p> <ul style="list-style-type: none"> • 0—Network error • 1—No more sockets available; max number already reached • 2—Memory problem • 3—DNS error • 5—UDP connection error (Host unreachable) • 6—Generic error • 8—Data sending is OK but +KUDPSND was waiting more or less characters • 9—Bad session ID • 10—Session is already running • 11—All sessions are used <p><data_mode> (Enable/disable display of <data> in URC)</p> <ul style="list-style-type: none"> • 0—Do not display (Default) <p><udp_remote_address> (IP address string or explicit name of remote server)</p> <ul style="list-style-type: none"> • String • Default is empty (given by +KUDPSND) <p><udp_port> (UDP peer port)</p> <ul style="list-style-type: none"> • Valid range: 0–65535 • Given by +KUDPSND <p><af> (IP address family type used for connection)</p> <ul style="list-style-type: none"> • Valid values: <ul style="list-style-type: none"> • 0—IPv4 • 1—IPv6 <p><restore_on_boot> (Restore server session on boot (only for server socket))</p> <ul style="list-style-type: none"> • 0—First server session is not restored on boot. (Default) • 1—First server session is restored on boot.

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KUDPCLOSE	<p>Close current UDP connection Close a UDP session and then, if no other sessions are running, release the PDP context.</p> <p>Notes:</p> <ul style="list-style-type: none"> This function will delete the session configuration if <keep_cfg> = 0 <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT+KUDPCLOSE=<session_id>[,<keep_cfg>] Response: OK or +KUDP_NOTIF: <session_id>,<udp_notif> Purpose: Close the specified UDP connection. Query List: AT+KUDPCLOSE=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><session_id> (UDP session index)</p> <ul style="list-style-type: none"> Integer <p><udp_notif> (Cause of UDP connection failure)</p> <ul style="list-style-type: none"> See +KUDPCFG for details <p><keep_cfg> (Delete/keep session configuration after closing)</p> <ul style="list-style-type: none"> 0—Delete the session configuration 1—Keep the session configuration
+KUDPDEL	<p>Delete configured UDP session</p> <p>Notes:</p> <ul style="list-style-type: none"> Session must be closed using +KUDPCLOSE before using this command. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT+KUDPDEL=<session_id> Response: OK or +CME ERROR: <err> Purpose: Delete the specified UDP connection. Query List: AT+KUDPDEL=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><session_id> (UDP session index)</p> <ul style="list-style-type: none"> Integer

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KUDPRCV	<p>Receive data through UDP connection Receive data through a previously opened UDP socket.</p> <p>Notes:</p> <ul style="list-style-type: none"> • <ndata> indicates the max data number that the terminal wishes to receive. If the UDP socket contains more data than <ndata> bytes, then only <ndata> bytes will be received and more data can be read by running this command again. • <EOF pattern> would be added at the end of data automatically. • When <ndata> (max value) bytes or only available data in the UDP socket have been received, the module returns to command mode. • It is highly recommended to configure the module for hardware flow control using AT&K3 before using this command. • Refer to AT&D for the behavior of DTR drop. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+KUDPRCV=<session_id>,<ndata> Response: CONNECT ...<EOF_pattern> OK +KUDP_RCV: <udp_remote_address>, <udp_remote_port> <p style="text-align: center;">or</p> <p>NO CARRIER +CME ERROR: <err> +KUDP_NOTIF: <session_id>,<udp_notif></p> <p>Purpose: Receive <ndata> bytes of data from the specified socket.</p> <ul style="list-style-type: none"> • Query List: AT+KUDPRCV=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><session_id> (UDP session index)</p> <ul style="list-style-type: none"> • Integer <p><ndata> (Number of bytes that device wants to receive)</p> <ul style="list-style-type: none"> • Max value: 4294967295 <p><udp_remote_address> (IP address string or explicit name of remote host)</p> <ul style="list-style-type: none"> • String <p><udp_remote_port> (Remote UDP port)</p> <ul style="list-style-type: none"> • Valid range: 0–65535 <p><udp_notif> (Cause of UDP connection failure)</p> <ul style="list-style-type: none"> • See +KUDPCFG for details

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KUDPSND	<p>Send data through UDP connection Send data through a previously opened UDP connection.</p> <p>Notes:</p> <ul style="list-style-type: none"> All data will be sent out ignoring <ndata>. If data sent is not equal to <ndata> then +KUDP_NOTIF will be displayed. <ndata> is the data size without <EOF pattern>. It is highly recommended to configure the module for hardware flow control using AT&K3 before using this command. Refer to AT&D for the behavior of DTR drop. The maximum transmission unit (MTU) is 1500 Bytes. The <udp remote address> and <udp_port> are saved internally such that they can be omitted in subsequent calls of +KUDPSND. The packet segmentation is controlled by +KIPOPT with <option_id>=0, and the maximum UDP packet size is limited by <send size v4> (1472 bytes) or <send size v6> (1452 bytes). Default value for both parameters is 1020 bytes. The data session can be ended by <EOF pattern>, +++ or DTR. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> Execution: AT+KUDPSND=<session_id>, <udp_remote_address>, <udp_port>, <ndata> Response: CONNECT OK or NO CARRIER +CME ERROR: <err> +KTCP_NOTIF: <session_id>,<udp_notif> Purpose: Send <ndata> bytes of data over the specified connection. Query List: AT+KUDPSND=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><session_id> (UDP session index)</p> <ul style="list-style-type: none"> Integer <p><udp_remote_address> (IP address string or explicit name of remote server)</p> <ul style="list-style-type: none"> String <p><udp_port> (UDP peer port)</p> <ul style="list-style-type: none"> Valid range: 1–65535 <p><ndata> (Number of bytes that device will send)</p> <ul style="list-style-type: none"> Max value: 4294967295 <p><udp_notif> (Cause of UDP connection failure)</p> <ul style="list-style-type: none"> See +KUDPCFG for details

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KURCCFG	<p>Enable/Disable Protocol Notifications (URCs) Enable or disable specific protocol notifications (URCs).</p> <p>Notes:</p> <ul style="list-style-type: none"> • Enabling/disabling +KTCP_NOTIF unsolicited notifications is only useful when in polling mode with +KTCPSTAT. • If notifications and/or indications are disabled, the URCs are discarded and not stored. • Can be used in 07.10 multiplexer. <p>Password required: No</p> <p>Usage:</p> <ul style="list-style-type: none"> • Execution: AT+KURCCFG=<protoopt>,<noti_act>[,<indi_act>] Response: OK Purpose: Enable/disable specified URC notifications and/or indications for the specified protocol. • Query: AT+KURCCFG? Response: +KURCCFG: (list of enabled <protoopt>,<noti_act>,<indi_act>) OK Purpose: Display the status of URC notifications/indications for each protocol. • Query List: AT+KURCCFG=? Purpose: Display valid execution format and parameter values. <p>Parameters:</p> <p><protoopt> (Protocol option to enable/disable URC)</p> <ul style="list-style-type: none"> • String format • "TCPC"—TCP client session • "TCPS"—TCP server session • "UDPC"—UDP client session • "UDPS"—UDP server session • "HTTP"—HTTP client session • "HTTPS"—HTTPS client session • "TCP"—Both TCP client and server sessions • "UDP"—Both UDP client and server sessions <p><noti_act> (Enable/disable URC notifications)</p> <ul style="list-style-type: none"> • 0—Disable URC • 1—Enable URC (such as +KTCP_NOTIF) <p><indi_act> (Enable/disable URC indications)</p> <ul style="list-style-type: none"> • 0—Disable URC • 1—Enable URC (such as +KTCP_SRVREQ, +KTCP_IND, +KTCP_DATA, +KUDP_DATA, +KUDP_RCV, etc.) <p>(Continued on next page)</p>

Table 16-2: Protocol Command Details (Continued)

Command	Description
+KURCCFG (continued)	Enable/Disable Protocol Notifications (URCs) (continued) Example(s): <ul style="list-style-type: none"> Disable URC notifications: AT+KURCCFG="TCP",0 OK Display enabled notifications and indications: AT+KURCCFG? +KURCCFG: "TCPC",1,1 +KURCCFG: "TCPS",1,1 +KURCCFG: "UDPC",1,1 +KURCCFG: "UDPS",1,1 +KURCCFG: "HTTP",1,1 +KURCCFG: "HTTPS",1,1

Table 16-3: Supported Cipher Suites

NIST Name	<mkey_algo>	<auth_algo>	<enc_algo>	<mac_algo>
TLS-RSA-WITH-AES-128-GCM-SHA256	RSA	RSA	AES-128-GCM	SHA256
TLS-RSA-WITH-AES-256-GCM-SHA384	RSA	RSA	AES-256-GCM	SHA384
TLS-RSA-WITH-AES-128-CCM	RSA	RSA	AES-128-CCM	NULL
TLS-RSA-WITH-AES-256-CCM	RSA	RSA	AES-256-CCM	NULL
TLS-RSA-WITH-AES-128-CCM-8	RSA	RSA	AES-128-CCM-8	NULL
TLS-RSA-WITH-AES-256-CCM-8	RSA	RSA	AES-256-CCM-8	NULL
TLS-ECDHE-RSA-WITH-AES-128-CBC-SHA256	ECDHE	RSA	AES-128-CBC	SHA256
TLS-ECDHE-RSA-WITH-AES-128-GCM-SHA256	ECDHE	RSA	AES-128-GCM	SHA256
TLS-ECDHE-ECDSA-WITH-AES-128-CBC-SHA256	ECDHE	ECDSA	AES-128-CBC	SHA256
TLS-ECDHE-ECDSA-WITH-AES-128-GCM-SHA256	ECDHE	ECDSA	AES-128-GCM	SHA256
TLS-ECDHE-ECDSA-WITH-AES-256-GCM-SHA384	ECDHE	ECDSA	AES-256-GCM	SHA384
TLS-ECDHE-ECDSA-WITH-AES-128-CCM	ECDHE	ECDSA	AES-128-CCM	NULL
TLS-ECDHE-ECDSA-WITH-AES-256-CCM	ECDHE	ECDSA	AES-256-CCM	NULL
TLS-ECDHE-ECDSA-WITH-AES-128-CCM-8	ECDHE	ECDSA	AES-128-CCM-8	NULL
TLS-ECDHE-ECDSA-WITH-AES-256-CCM-8	ECDHE	ECDSA	AES-256-CCM-8	NULL

>> 17: Supported GSM/WCDMA AT Commands

This chapter identifies standard AT commands that are supported by most Sierra Wireless AirPrime devices. These commands:

- Control serial communications over an asynchronous interface (*ITU-T Serial Asynchronous Dialling and Control (Recommendation V.250)*), available on the International Telecommunication Union web site, www.itu.int.
See [Table 17-1](#) below.
- Control SMS functions for devices on GSM/WCDMA networks (*3GPP TS 27.005*, available on the 3GPP web site, www.3gpp.org)
See [Table 17-2](#) on page 281.
- Control devices operating on GSM/WCDMA networks (*3GPP TS 27.007*, available on the 3GPP web site, www.3gpp.org)
See [Table 17-3](#) on page 283.

The tables below identify whether each command is supported on Sierra Wireless UMTS devices. An “N/A” in the Supported column of the table indicates that the command is related to a feature (such as voice) that is not available on the modems.

Commands that are partially supported include descriptions identifying any limitations on command usage. Also, some commands are described in more detail in other chapters—the descriptions for these commands link to those detailed entries (for example, [&V](#) in [Table 17-1](#) on page 279).

Table 17-1: Supported ITU-T Recommendation V.250 AT Commands

Command	Description	Supported 4=Yes; 8=No
Commands		
&C	Set Data Carrier Detected (Received line signal detector) function mode	4
&D	Set Data Terminal Ready function mode	4
&F	Set all current parameters to manufacturer's defaults	4
&K	Flow control	4 For details, see &K on page 68
&S	Set DSR signal	4
&T	Auto tests	8
&V	Return operating mode AT configuration parameters	4
&W	Store current parameter to user-defined profile	4
+++	Switch from Data Mode to Command Mode	4 For details, see +++ on page 27
+DR	V42bis data compression report	4
+DS	V42bis data compression	4
+GCAP	Request complete TA capabilities list	4

Table 17-1: Supported ITU-T Recommendation V.250 AT Commands (Continued)

Command	Description	Supported 4=Yes; 8=No
+GMI	Request manufacturer identification	4
+GMM	Request TA model identification	4
+GMR	Request TA revision identification	4
+GOI	Request global object identification	8
+GSN	Request TA serial number identification	4
+ICF	Set TE-TA control character framing	4
+IFC	Set TE-TA local data flow control	4
+ILRR	Set TE-TA local rate reporting mode	8
+IPR	<hr/> <i>Note: Set fixed local rate (default rate is 115200).</i> <hr/>	4
A	Answer incoming call	4
A/	Re-issues last AT command given	4
D	Dial	4
D><MEM><N>	Originate call to phone number in memory <MEM>	8
D><N>	Originate call to phone number in current memory	4
D><STR>	Originate call to phone number in memory which corresponds to alphanumeric field <STR>	8
DL	Redial last telephone number used	8
E	Set command echo mode	4
H	Disconnect existing connections	4
I	Display product identification information	4 For details, see !HWID on page 63
L	Set monitor speaker loudness	8
M	Set monitor speaker mode	8
O	Switch from command mode to data mode	4
P	Select pulse dialing	8
Q	Set Result code presentation mode	4
S0	Set number of rings before automatically answering the call	4
S10	Set disconnect delay after indicating the absence of data carrier	4
S3	Set command line termination character	4

Table 17-1: Supported ITU-T Recommendation V.250 AT Commands (Continued)

Command	Description	Supported 4=Yes; 8=No
S4	Set response formatting character	4
S5	Set command line editing character	4
S6	Set pause before blind dialing	4
S7	Set number of seconds to wait for connection completion	4
S8	Set number of seconds to wait when comma dial modifier used	4
S11	Query/set DTMF dialing speed	4 For details, see S11 on page 95
T	Select tone dialing	4
V	Set result code format mode	4
X	Set connect result code format and call monitoring	4
Z	Set all current parameters to user-defined profile	4
Result Codes		
OK	Acknowledges execution of a command	4
CONNECT	A connection has been established	4
RING	Unsolicited notification of an incoming call signal from the network	4
NO CARRIER	The connection has been terminated or the attempt to establish a connection failed	4
ERROR	Command not recognized, command line maximum length exceeded, parameter value invalid, or other problem with processing the command line	4
NO DIALTONE	No dial tone detected	4
BUSY	Engaged (busy) signal detected	4

Table 17-2: Supported 27.005 AT Commands

Command	Description	Supported 4=Yes; 8=No
+CBM	Cell broadcast message directly displayed	4
+CBMI	Cell broadcast message stored in memory at specified <index> location	8
+CDS	SMS status report after sending a SMS	4
+CDSI	Incoming SMS status report	4
+CMGC	Send command	4
+CMGD	Delete message	4
+CMGF	Message format	4

Table 17-2: Supported 27.005 AT Commands (Continued)

Command	Description	Supported 4=Yes; 8=No
+CMGL	List messages	4
+CMGR	Read message	4
+CMGS	Send message	4
+CMGW	Write message to memory	4
+CMMS	More messages to send	4
+CMS ERROR: <err>	SMS error (mobile or network error)	4
+CMSS	Send message from storage	4
+CMT	Incoming message directly displayed	4
+CMTI	Incoming message stored in <mem> ("SM"—SIM message storage) at location <index>	4
+CNMA	New message acknowledgment to mobile equipment	4
+CNMI	New message indications to TE <i>Note: The following parameter settings are not supported:</i> <ul style="list-style-type: none"> • <mode>=0 or 2, <mt>=2 or 3 • <mode>=0 or 2, <ds>=1 • <bm>=1 	Partial
+CPMS	Preferred message storage	4
+CRES	Restore settings	8
+CSAS	Save settings	8
+CSCA	Service center address	4
+CSCB	Select cell broadcast message types	4
+CSDH	Show text mode parameters	4
+CSMP	Set text mode parameters	4
+CSMS	Select message service	4

Table 17-3: Supported 27.007 AT Commands

Command	Description	Supported 4=Yes; 8=No
C	ITU T V.24 circuit 109 carrier detect signal behavior command Format <ul style="list-style-type: none"> C<value> Limitations <ul style="list-style-type: none"> Default <value> = 2 <value> = 2 causes the AT/Data carrier detect pin to 'wink' (briefly switch off and on) when data calls end. <value> = 0 or 1 performs as defined in the standard 	Partial
+CACM	Accumulated call meter	8
+CACSP	Voice Group or Voice Broadcast Call State Attribute Presentation	N/A
+CAEMLPP	eMLPP Priority Registration and Interrogation	8
+CAHLD	Leave an ongoing Voice Group or Voice Broadcast Call	N/A
+CAJOIN	Accept an incoming Voice Group or Voice Broadcast Call	N/A
+CALA	Alarm	N/A
+CALCC	List current Voice Group and Voice Broadcast Calls	N/A
+CALD	Delete alarm	N/A
+CALM	Alert sound mode	8
+CAMM	Accumulated call meter maximum	8
+CANCHEV	NCH Support Indication	8
+CAOC	Advice of Charge	4
+CAPD	Postpone or dismiss an alarm	N/A
+CAPTT	Talker Access for Voice Group Call	N/A
+CAREJ	Reject an incoming Voice Group or Voice Broadcast Call	N/A
+CAULEV	Voice Group Call Uplink Status Presentation	N/A
+CBC	Battery charge	4
+CBST	Select bearer service type	4
+CCCM	Current call meter value	8
+CCFC	Call forwarding number and conditions	4
+CCLK	Clock	4
+CCUG	Closed user group	4
+CCWA	Call waiting	4
+CCWE	Call Meter maximum event	8
+CDIP	Called line identification presentation	8

Table 17-3: Supported 27.007 AT Commands (Continued)

Command	Description	Supported 4=Yes; 8=No
+CDIS	Display control	8
+CEER	Extended error report	8
+CEREG	EPS network registration status Note: Command implementation based on 3GPP 27.007 rel 8.11.0.	4
+CFUN	Set phone functionality Format • +CFUN = [<fun> [, <rst>]] Limitations • Valid <fun> values: • 0 (minimum functionality, low power draw) • 1 (full functionality, high power draw)	Partial
+CGACT	PDP context activate or deactivate	4
+CGANS	Manual response to a network request for PDP context activation	8
+CGATT	PS attach or detach	4
+CGAUTO	Automatic response to a network request for PDP context activation	8
+CGCLASS	GPRS mobile station class	4
+CGCLOSP	Configure local octet stream PAD parameters	8
+CGCMOD	PDP Context Modify	4
+CGCONTRDP	PDP Context Read Dynamic Parameters	4
+CGDATA	Enter data state	4
+CGDCONT	Define PDP Context	4 For details, see +CGDCONT .
+CGDSCONT	Define Secondary PDP Context	4
+CGEQMIN	3G Quality of Service Profile (Minimum acceptable)	4
+CGEQNEG	3G Quality of Service Profile (Negotiated)	4
+CGEQOS	Define EPS Quality of Service	4
+CGEQREQ	3G Quality of Service Profile (Requested)	4
+CGEREP	Packet Domain event reporting	4
+CGEV	GPRS network event indication	4
+CGMI	Request manufacturer identification	4
+CGMM	Request model identification	4
+CGMR	Request revision identification	4
+CGPADDR	Show PDP address	4

Table 17-3: Supported 27.007 AT Commands (Continued)

Command	Description	Supported 4=Yes; 8=No
+CGQMIN	Quality of Service Profile (Minimum acceptable)	4
+CGQREQ	Quality of Service Profile (Requested)	4
+CGREG	GPRS network registration status	4
+CGSCONTRDP	Secondary PDP Context Read Dynamic Parameters	4
+CGSMS	Select service for MO SMS messages	4
+CGSN	Request product serial number identification	4
+CGTFT	Traffic Flow Template	4
+CGTFTRDP	Traffic Flow Template Read Dynamic Parameters	4
+CHLD	Call related supplementary services	4
+CHSA	HSCSD non-transparent asymmetry configuration	N/A
+CHSC	HSCSD current call parameters	N/A
+CHSD	HSCSD device parameters	N/A
+CHSR	HSCSD parameters report	N/A
+CHST	HSCSD transparent call configuration	N/A
+CHSU	HSCSD automatic user initiated upgrading	N/A
+CHUP	Hangup call	4
+CIEV	Indicator event	4
+CIMI	Request international mobile subscriber identity	4
+CIND	Indicator control	4
+CKEV	Key press or release event	8
+CKPD	Keypad control	8
+CLAC	List all available AT commands	8
+CLAE	Language Event	8
+CLAN	Set Language	8
+CLCC	List current calls	4
+CLCK	Facility lock	4
+CLIP	Calling line identification presentation	4
+CLIR	Calling line identification restriction	4
+CLVL	Set/return internal loudspeaker volume	4
+CMAR	Master Reset	8

Table 17-3: Supported 27.007 AT Commands (Continued)

Command	Description	Supported 4=Yes; 8=No
+CME ERROR: <err>	Mobile Termination error result code	4
+CMEC	Mobile Termination control mode	4
+CMEE	Report Mobile Termination error	4 For details, see +CMEE on page 42
+CMER	Mobile Termination event reporting <i>Note: The following parameter values are not supported:</i> <ul style="list-style-type: none"> • <mode> = 2 • <bfr> = 1 	Partial
+CMOD	Call mode	4
+CMUT	Enable/disable uplink voice muting	4
+CMUX	Multiplexing mode	4 (When MUX mode configured on USB or UART interface.)
+CNUM	Subscriber number	4
+COLP	Connected line identification presentation	4
+COPN	Read operator names	4
+COPS	Operator selection	4
+CPAS	Phone activity status	4
+CPBF	Find phonebook entries	4
+CPBR	Read phonebook entries	4
+CPBS	Select phonebook memory storage	4
+CPBW	Write phonebook entry	4
+CPIN	Enter PIN	4
+CPLS	Preferred PLMN list selection	4
+CPOL	Preferred operator list	4
+CPROT	Enter protocol mode	8
+CPUC	Price per unit and currency table	4
+CPWC	Power class	8
+CPWD	Change password	4
+CR	Service reporting control	4
+CRC	Cellular result codes	4

Table 17-3: Supported 27.007 AT Commands (Continued)

Command	Description	Supported 4=Yes; 8=No
+CREG	Network registration	4
+CRING	Incoming call type	4
+CRLP	Radio link protocol	4
+CRMP	Ring Melody Playback	N/A
+CRSL	Ringer sound level	N/A
+CRSM	Restricted SIM access	4
+CSCC	Secure control command	8
+CSCS	Select TE character set	4
+CSDF	Settings date format	N/A
+CSGT	Set Greeting Text	N/A
+CSIL	Silence Command	N/A
+CSIM	Generic SIM access	4
+CSNS	Single numbering scheme	8
+CSQ	Signal quality	4
+CSSN	Supplementary service notifications	4
+CSTA	Select type of address	4
+CSTF	Settings time format	4
+CSVM	Set Voice Mail Number	8
+CTFR	Call deflection	4
+CTZR	Time Zone Reporting	N/A
+CTZU	Automatic Time Zone Update	8
+CUSD	Unstructured supplementary service data	4
+CV120	V.120 rate adaptation protocol	8
+CVHU	Voice Hangup Control	8
+CVIB	Vibrator mode	N/A
D	ITU T V.25ter [14] dial command	4
D*99#	Sets up a packet data call (PDP context) based on profile ID #1	4
D*99***<n>#	Sets up a packet data call (PDP context) based on profile ID #<n> (<n> is the <cid> in the +CGDCONT command)	4
+VTD	Tone duration	4

Table 17-3: Supported 27.007 AT Commands (Continued)

Command	Description	Supported 4=Yes; 8=No
+VTS	DTMF and arbitrary tone generation	4
+WS46	PCCA STD 101 [17] select wireless network	8

>> 18: Band Definitions

Some commands described in this document include input and/or output ‘band’ parameters, where the value is one of the following:

- An enumerated value representing a network technology and band (Table 18-1).
Commands using this table:
 - **!DASBAND** on page 160
- A 3GPP band number (Table 18-2 on page 290).
Commands using this table:
 - **!ANTSEL** on page 29
 - **!MAXPWR** on page 212

Note: Band support is product-specific—see the device’s Product Specification Document or Product Technical Specification for details.

Table 18-1: Band/technology Enumerations^{a,b}

Band enum	Tech	Band enum	Tech	Band enum	Tech	Band enum	Tech
0	CDMA	22	WCDMA 800	42	LTE B4	60	LTE B24
2	Sleep	25	WCDMA B3	43	LTE B2	61	LTE B25
5	CDMA 800	26	CDMA BC14	44	LTE B3	62	LTE B26
6	CDMA 1900	27	CDMA BC11	45	LTE B5	63	LTE B27
7	HDR	28	WCDMA B4	46	LTE B6	64	LTE B28
8	CDMA 1800	29	WCDMA B8	47	LTE B8	65	LTE B29
9	WCDMA IMT	30	MF 700	48	LTE B9	66	LTE B30
10	GSM 900	31	WCDMA B9	49	LTE B10	67	LTE B31
11	GSM 1800	32	CDMA BC15	50	LTE B12	68	LTE B32
12	GSM 1900	33	CDMA BC10	51	LTE B14	69	LTE B33
14	JCDMA	34	LTE B1	52	LTE B15	70	LTE B34
15	WCDMA 1900A	35	LTE B7	53	LTE B16	71	LTE B35
16	WCDMA 1900B	36	LTE B13	54	LTE B18	72	LTE B36
17	CDMA 450	37	LTE B17	55	LTE B19	73	LTE B37
18	GSM 850	38	LTE B38	56	LTE B20	74	LTE B39
19	IMT	39	LTE B40	57	LTE B21	75	WCDMA B19
20	HDR 800	40	WCDMA B11	58	LTE B22	76	LTE B41
21	HDR 1900	41	LTE B11	59	LTE B23		

- a. Band values not listed (e.g. 1, 3, 4) are reserved.
 b. Commands using this table are identified in the chapter introduction.

Table 18-2: 3GPP Bands^{a,b}

3GPP Band	Frequency ranges (MHz)		3GPP Band	Frequency ranges (MHz)	
	Tx	Rx		Tx	Rx
1	1920–1980	2110–2170	30	2305–2315	2350–2360
2	1850–1910	1930–1990	31	452.5–457.5	462.5–467.5
3	1710–1785	1805–1880	32	n/a	1452–1496
4	1710–1755	2110–2155	33	1900–1920	
5	824–849	869–894	34	2010–2025	
6	830–840	875–885	35	1850–1910	
7	2500–2570	2620–2690	36	1930–1990	
8	880–915	925–960	37	1910–1930	
9	1749.9–1784.9	1844.9–1879.9	38	2570–2620	
10	1710–1770	2110–2170	39	1880–1920	
11	1427.9–1447.9	1475.9–1495.9	40	2300–2400	
12	699–716	729–746	41	2496–2690	
13	777–787	746–756	42	3400–3600	
14	788–798	758–768	43	3600–3800	
15	Reserved	Reserved	44	703–803	
16	Reserved	Reserved	45	1447–1467	
17	704–716	734–746	46	5150–5925	
18	815–830	860–875	47	5855–5925	
19	830–845	875–890	48	3550–3700	
20	832–862	791–821	49	3550–3700	
21	1447.9–1462.9	1495.9–1510.9	50	1432–1517	
22	Reserved	Reserved	51	1427–1432	
23	2000–2020	2180–2200	52	3300–3400	
24	1626.5–1660.5	1525–1559	53-64	Reserved	Reserved
25	1850–1915	1930–1995	65	1920–2010	2110–2200
26	814–849	859–894	66	1710–1780	2110–2200
27	807–824	852–869	67-70	Reserved	Reserved
28	703–748	758–803	71	663–698	617–652
29	n/a	717–728			

- a. For CDMA bands, use these equivalents: BC0 (Band 5), BC1 (Band 2), BC10 (Band 6).
b. Commands using this table are identified in the chapter introduction.

>> 19: ASCII Table

Table 19-1: ASCII Values

Char	Dec	Hex	Char	Dec	Hex	Char	Dec	Hex	Char	Dec	Hex
NUL	0	00	SP	32	20	@	64	40	'	96	60
SOH	1	01	!	33	21	A	65	41	a	97	61
STX	2	02	"	34	22	B	66	42	b	98	62
ETX	3	03	#	35	23	C	67	43	c	99	63
EOT	4	04	\$	36	24	D	68	44	d	100	94
ENQ	5	05	%	37	25	E	69	45	e	101	95
ACK	6	06	&	38	26	F	70	46	f	102	96
BEL	7	07	'	39	27	G	71	47	g	103	97
BS	8	08	(40	28	H	72	48	h	104	98
HT	9	09)	41	29	I	73	49	i	105	99
LF	10	0A	*	42	2A	J	74	4A	j	106	6A
VT	11	0B	+	43	2B	K	75	4B	k	107	6B
FF	12	0C	,	44	2C	L	76	4C	l	108	6C
CR	13	0D	-	45	2D	M	77	4D	m	109	6D
SO	14	0E	.	46	2E	N	78	4E	n	110	6E
SI	15	0F	/	47	2F	O	79	4F	o	111	6F
DLE	16	10	0	48	30	P	80	50	p	112	70
XON	17	11	1	49	31	Q	81	51	q	113	71
DC2	18	12	2	50	32	R	82	52	r	114	72
XOFF	19	13	3	51	33	S	83	53	s	115	73
DC4	20	14	4	52	34	T	84	54	t	116	74
NAK	21	15	5	53	35	U	85	55	u	117	75
SYN	22	16	6	54	36	V	86	56	v	118	76
ETB	23	17	7	55	37	W	87	57	w	119	77
CAN	24	18	8	56	38	X	88	58	x	120	78
EM	25	19	9	57	39	Y	89	59	y	121	79
SUB	26	1A	:	58	3A	Z	90	5A	z	122	7A
ESC	27	1B	;	59	3B	[91	5B	{	123	7B
FS	28	1C	<	60	3C	\	92	5C	 	124	7C
GS	29	1D	=	61	3D]	93	5D	}	125	7D
RS	30	1E	>	62	3E	^	94	5E	~	126	7E
US	31	1F	?	63	3F	_	95	5F	DEL	127	7F

>> Index (AT commands)

Symbols

+++ , switch from data mode to command mode, 27, 279

A

A, answer incoming call, 280
A/, re-issue last AT command, 280
!ADC, read ADC value, 28
!ANTSEL, set/query external antenna select configuration, 29
!AVCFG, bind audio profile to device+physical interface, 221
!AVDEF, reset audio parameters in NV to default values, 223
!AVRXG, query/set decoder gain, 223
!AVSETPROFILE, select audio profile for CS calls, 224
!AVSTG, configure AFE side tone gain, 224
!AVTXG, query/set encoder gain, 225

B

!BAND, set/query frequency bands, 31
!BCFWUPDATESTATUS, report status of last firmware update attempt, 142
!BCRESETTYPE, report module reset type and cause, 143
!BOOTHOLD, reset modem and wait for f/w download, 33
!BSGPIO, query/set GPIO signal level/direction, 34

C

&C, set data carrier detected, 279
C, ITU T v.24 circuit 109 carrier detect signal behavior command, 283
+CACM, accumulated call meter, 283
+CACSP, voice group or voice broadcast call state attribute presentation, 283
+CAEMLPP, eMLPP priority registration and interrogation, 283
+CAHLD, leave an ongoing voice group or voice broadcast call, 283
+CAJOIN, accept incoming voice group or voice broadcast call, 283
+CALA, alarm, 283
+CALCC, list current voice group and voice broadcast call, 283
+CALD, delete alarm, 283
+CALM, alert sound mode, 283
+CAMM, accumulated call meter maximum, 283
+CANCHEV, NCH support indication, 283
+CAOC, advice of charge, 283
+CAPD, postpone or dismiss an alarm, 283
+CAPTT, talker access for voice group call, 283
+CAREJ, reject incoming voice group or voice broadcast call, 283
+CAULEV, voice group call uplink status presentation, 283
+CBC, battery charge, 283
+CBM, cell broadcast message directly displayed, 281
+CBMI, cell broadcast message stored in memory at specified location, 281
+CBST, select bearer service type, 283
+CBST, select circuit-switched bearer, 36
+CCCM, current call meter value, 283
+CCFC, call forwarding number and conditions, 283
+CCID, eUICC profile switched (unsolicited notification), 201
+CCID, return SIM card's ICCID, 201

+CCLK, clock, 283
+CCUG, closed user group, 283
+CCWA, call waiting, 283
+CCWE, call meter maximum event, 283
+CDIP, called line identification presentation, 283
+CDIS, display control, 284
+CDS, SMS status report after sending a SMS, 281
+CDSI, incoming SMS status report, 281
+CEER, extended error report, 284
+CEREG, EPS network registration, 284
+CESQ, extended signal quality, 37
+CFUN, set phone functionality, 284
+CGACT, PDP context activate or deactivate, 39, 284
+CGANS, manual response to network request for PDP context activation, 284
+CGATT, PS attach or detach, 284
+CGAUTH, PDP connection authentication parameters, set/report, 40
+CGAUTO, automatic response to network request for PDP context activation, 284
+CGCLASS, GPRS mobile station class, 284
+CGCLOSP, configure local octet stream PAD parameters, 284
+CGCMOD, PDP context modify, 284
+CGCONTRDP, PDP context read dynamic parameters, 284
+CGDATA, enter data state, 284
+CGDCONT, define PDP context, 41, 284
+CGDSCONT, define secondary PDP context, 284
+CGEQMIN, 3G QoS profile (minimum acceptable), 284
+CGEQNEG, 3G QoS profile (negotiated), 284
+CGEQNEG, Define EPS Quality of Service, 284
+CGEQREQ, 3G QoS profile (requested), 284
+CGEREP, packet domain event reporting, 284
+CGEV, GPRS network event indication, 284
+CGIEV, indicator event, 285
+CGMI, request manufacturer identification, 284
+CGMM, request model identification, 284
+CGMR, request revision identification, 284
+CGPADDR, show PDP address, 284
+CGQMIN, QoS profile (minimum acceptable), 285
+CGQREQ, QoS profile (requested), 285
+CGREG, GPRS network registration status, 285
+CGSCONTRDP, Secondary PDP context read dynamic parameters, 285
+CGSMS, select service for MO SMS messages, 285
+CGSN, request product serial number identification, 285
+CGTFT, traffic flow template, 285
+CGTFTTRDP, traffic flow template read dynamic parameters, 285
+CHLD, call-related supplementary services, 285
+CHSA, HSCSD non-transparent asymmetry configuration, 285
+CHSC, HSCSD current call parameters, 285
+CHSD, HSCSD device parameters, 285
+CHSR, HSCSD parameters report, 285
+CHST, HSCSD transparent call configuration, 285
+CHSU, HSCSD automatic user initiated upgrading, 285
+CHUP, hangup call, 285
+CIMI, request international mobile subscriber identity, 285
+CIND, indicator control, 285
+CKEV, key press or release event, 285
+CKPD, keypad control, 285
+CLAC, list all available AT commands, 285
+CLAE, language event, 285
+CLAN, set language, 285

- +CLCC, list current calls, 285
- +CLCK, facility lock, 285
- +CLIP, calling line identification presentation, 285
- +CLIR, calling line identification restriction, 285
- +CLVL, set audio profile Rx volume, 225
- +CLVL, sets/returns internal loudspeaker volume, 285
- +CMAR, master reset, 285
- +CME ERROR, mobile termination error result code, 286
- +CMEC, mobile termination control mode, 286
- +CMEE, enable/disable CMEE error reporting, 42
- +CMEE, report mobile termination error, 286
- +CMER, mobile termination event reporting, 286
- +CMGC, send command, 281
- +CMGD, delete message, 281
- +CMGF, message format, 281
- +CMGL, list messages, 282
- +CMGR, read message, 282
- +CMGS, send message, 282
- +CMGW, write message to memory, 282
- +CMMS, more messages to send, 282
- +CMOD, call mode, 286
- +CMS ERROR, SMS error (mobile or network error), 282
- +CMSS, send message from storage, 282
- +CMT, incoming message directly displayed, 282
- +CMTI, incoming message stored at specific memory location, 282
- +CMUT, enables/disables uplink voice muting, 286
- +CMUX, configure muxing protocol channel, 43
- +CMUX, multiplexing mode, 286
- +CNMA, new message acknowledgement to ME, 282
- +CNMI, new message indications to TE, 282
- +CNUM, subscriber number, 286
- +COLP, connected line identification presentation, 286
- +COPN, read operator names, 286
- +COPS, operator selection, 286
- +CPAS, phone activity status, 286
- +CPBR, read phonebook entries, 286
- +CPBS, select phonebook memory storage, 286
- +CPBW, write phonebook entry, 286
- +CPFB, find phonebook entries, 286
- +CPIN, enter PIN, 286
- +CPLS, Preferred PLMN list selection, 286
- +CPMS, preferred message storage, 282
- +CPOL, preferred operator list, 286
- +CPROT, enter protocol mode, 286
- +CPSMS, configure Power Saving Mode (PSM), 45
- +CPUC, price per unit and currency table, 286
- +CPWC, power class, 286
- +CPWD, change password, 286
- +CPWROFF, power off, 46
- +CR, service reporting control, 286
- +CRC, cellular result code, 286
- +CREG, network registration, 287
- +CRES, restore settings, 282
- +CRING, incoming call type, 287
- +CRLP, radio link protocol, 287
- +CRMP, ring melody playback, 287
- +CRSL, ringer sound level, 287
- +CRSM, restricted SIM access, 287
- +CSAS, save settings, 282
- +CSCA, service center address, 282
- +CSCB, select cell broadcast message type, 282
- +CSCC, secure control command, 287
- +CSCS, select TE character set, 287
- +CSDF, settings date format, 287
- +CSDH, show text mode parameters, 282
- +CSGT, set greeting text, 287
- +CSIL, silence command, 287
- +CSIM, generic SIM access, 287
- +CSMP, set text mode parameters, 282
- +CSMS, select message service, 282
- +CSNS, single numbering scheme, 287
- +CSPN, display SIM card service provider's name, 202
- +CSQ, display signal quality, 46
- +CSQ, signal quality, 287
- +CSQ, RSSI change across threshold (unsolicited notification), 47
- +CSSN, supplementary service notifications, 287
- +CSTA, select type of address, 287
- +CSTF, settings time format, 287
- +CSVM, set voice mail number, 287
- +CTFR, call deflection, 287
- +CTZR, time zone reporting, 287
- +CTZU, automatic time zone update, 287
- +CUSD, unstructured supplementary service data, 287
- !CUSTOM, customization settings, 48
 - BANDSELEN, enable/disable band selection, 48
 - BOOTQUIETDISABLE, enable/disable Linux kernel messages during boot, 48
 - BOOTUARTDLOADEN, enable/disable F/W download over UART on bootloader, 48
 - CFUNPERSISTEN, AT+CFUN setting persists across power cycle?, 49
 - CSDDISABLE, Enable/disable CSD call, 49
 - CSVOICEREJECT, enable/disable CS voice rejection, 49
 - DGENABLE, enable/disable Dying Gasp feature, 49
 - DHCPRELAYENABLE, enable/disable DHCP relay feature, 49
 - EXITSPYMODEENABLE, enable/"exit spymode", 49
 - EXTGPSLNAEN, Enable/disable EXT_GPS_LNA_EN, 49
 - EXTUIMSWITCHEN, Enable/disable fast SIM switch via external switch, 49
 - FASTBOOTEN, Enable/disable fast boot, 50
 - FASTNUMEN, Enable/disable fast enumeration, 50
 - FLOWNOTIDISABLE, Enable/disable QMI notification events, 50
 - GPIOARENABLE, Control SAR backoff by GPIOs or by AT commands, 50
 - GPSENABLE, Enable/disable GPS, 50
 - GPSLPM, enable GPS in low power mode, 50
 - GPSREFLOC, enable GPS location reporting, 50
 - GPSEL, select antenna for GPS, 51
 - ICMPINTSRVDIS, enable/disable internal ICMP service, 51
 - IMCONFIG, image switching configuration, 51
 - IMSWITCHHIDE, multi-image management, 51
 - IPCHANNELRATEEN, Enable/disable IP channel rate calculation, 51
 - IPV6ENABLE, Enable/disable IPv6 support, 51
 - JAMENABLE, JAM detection enable/disable, 51
 - LTECOEXUARTENABLE, Wi-Fi/LTE Coex control enable/disable, 51
 - NETWORKNAMEFMT, set display format for network pro-

vider name, 52
 OSAENABLE, Enable/disable OSA, 52
 PCSCDISABLE, set PCSC functionality, 52
 POWERFAULTENABLE, Enable/disable power fault, 52
 QMIDETACHEN, enable/disable QMI NAS detach, 52
 SIMHOTSWAPDIS, Configure SIM hotswap feature, 52
 SIMLPM, set default low power mode SIM power state, 52
 SINGLEAPNSWITCH, device behaviour when APN details change, customize, 52
 SNTPEN, enable SNTP system time support, 53
 STKUIEN, enable SIM toolkit UI, 53
 TXONINDICATION, enable/disable TX_ON indication, 53
 UAULOADDISABLE, disable firmware download, 53
 UIM2ENABLE, enable/disable UIM2 slot support, 53
 UIMAUTOSWITCH, enable/disable automatic SIM switching, 53
 USBSERIALENABLE, include serial number in USB descriptor?, 54
 WAKEHOSTEN, enable/disable host wake-up via SMS/incoming data packet, 54
 +CV120, v.120 rate adaption protocol, 287
 +CVHU, voice hangup control, 287
 +CVIB, vibrator mode, 287

D

&D, set DTR function mode, 279
 D, dial, 280
 D, ITU T V.25ter dial command, 287
 D'99"<n>#, set up packet data call based on profile ID #<n>, 287
 D'99#, set up packet call based on profile ID #1, 287
 D<<MEM>>N>, originate call to phone number in memory, 280
 D<<N>, originate call to phone number in current memory, 280
 D<<STR>, originate call to phone number corresponding to a/n field, 280
 IDACGPSCTON, return CGPS C/N and frequency, 149
 IDACGPSMASKON, set CGPS log mask, 149
 IDACGPSSTANDALONE, enter/exit Stand Alone (SA) RF mode, 150
 IDACGPSTESTMODE, start/stop CGPS diagnostic task, 150
 IDAFTMACT, put modem into FTM mode, 9, 146, 151
 IDAFTMDEACT, put modem into online mode, 151
 IDALGAVGAGC, return averaged AGC in LTE mode, 154
 IDAGAVGRSSI, return averaged RSSI, 152
 IDAGSRXBURST, set GSM receiver to burst mode, 152
 IDAGSTXFRAME, set GSM Tx frame structure, 153
 IDALSNSVAL, configure LTE Net Sig value, 155
 IDALSPARANGE, set PA range (LTE mode), 155
 IDALSRXBW, set Rx bandwidth (LTE mode), 156
 IDALSTXBW, set Tx bandwidth (LTE mode), 156
 IDALSTXMOD, set LTE Tx modulation type, 157
 IDALSTXPWR, set Tx power level, 158
 IDALSWAVEFORM, set Tx waveform (LTE mode), 159
 IDASBAND, set frequency band, 9, 146, 160
 IDASCALSTATE, Enter/exit modem calibration state, 161
 IDASCHAN, set modem channel (frequency), 162
 IDASLNAGAIN, set LNA gain state, 163
 IDASPDM, set PDM value, 164
 IDASTXOFF, turn Tx PA off, 164
 IDASTXON, turn Tx PA on, 165
 IDAWGAVGAGC, return averaged Rx AGC (WCDMA), 165
 IDAWGAVGAGC, return Rx AGC (WCDMA), 166

!DAWSCONFIGRX, configure receiver (WCDMA), 167
 !DAWSPARANGE, set PA range state machine, 168
 !DAWSSCHAIN, enable secondary receive chain, 168
 !DAWSTXCW, select transmitter waveform, 169
 !DAWSTXPWR, set Tx power level, 169
 DL, redial last phone number used, 280
 +DR, V42bis compression report, 279
 +DS, V42bis data compress, 279

E

E, set command echo mode, 280
 !ENTERCND, enable protected command access, 9, 22, 23
 !ERR, display diagnostic information, 144

F

&F, set current parameters to defaults, 279

G

+GCAP, Request complete TA capabilities list, 279
 !GCCLR, clear crash dump data, 144
 !GCDUMP, display crash dump data, 144
 !GCFEN, enable/disable GCF testing mode, 54
 +GMI, request manufacturer identification, 280
 +GMM, request TA model identification, 280
 +GMR, request TA revision identification, 11, 280
 !GNSSCONFIG, configure satellite constellations support, 174
 +GOI, request global object identification, 280
 !GPSAUTOSTART, configure GPS auto-start features, 175
 !GPSCLRASSIST, clear selected GPS assistance data, 176
 !GPSOLDSTART, clear all GPS assistance data, 176, 177
 !GPSEND, end active position fix session, 177, 197
 !GPSFIX, initiate GPS position fix, 178, 190, 197, 198
 !GPSIDREN, enable/disable "Info for DR" feature, 179
 !GPSLOC, return last know modem location, 178, 180, 191
 !GPSMOMETHOD, set/report GPS MO method, 181
 !GPSMTLRSETTINGS, query/set MT location request settings, 182
 !GPSNMEACONFIG, enable/disable NMEA reporting, 183
 !GPSNMEASENTENCE, set/get NMEA sentence type, 184, 185
 !GPSSATINFO, request satellite information, 186
 !GPSSTATUS, request position fix session status, 178, 187, 191, 197
 !GPSSUPLURL, query/set SUPL server URL, 188
 !GPSSUPLVER, query/set SUPL server version, 189
 !GPSTRACK, initiate multiple-fix tracking session, 190, 197
 !GPSTRANSSEC, control GPS transport security, 191
 !GPSXTRADATAENABLE, query/set GPS XTRA settings, 192
 !GPSXTRADATAURL, query/set GPS XTRA data server URL, 193
 !GPSXTRASTATUS, current XTRA status, 194
 !GPSXTRATIME, inject GPS or UTC time information to XTRA, 195
 !GPSXTRATIMEENABLE, query/set GPS XTRA time settings, 196
 !GPSXTRATIMEURL, query/set GPS XTRA SNTP server URL, 197
 +GSN, request TA serial number identification, 280
 !GSTATUS, return operational status, 55

H

H, disconnect existing connections, 280
!HWID, read hardware ID, 63

I

I, display device information, 64
I, display product identification information, 280
!ICCID, return SIM card's ICCID, 202
+ICF, set TE-TA control character framing, 280
!IDSDEBUGPRINT, enable/disable debug printing, 207
+IFC, set TE-TA local data flow control, 280
+ILRR, set TE-TA local rate reporting mode, 280
!IMAGE, manage firmware images, 66
!IMPREF, query/set Image management preferences, 68
!IMSTESTMODE, enable/disable IMS test mode, 208
+IPR, set fixed local rate, 280

K

&K, flow control, 68, 279
+KCCINFO, enable/disable camped cell information notifications, 69
+KCCINFO (notification), camped cell parameter change, 70
+KCELL, display detected cell details, 71
+KCGPADDR, display PDP context addresses, 245
+KCNX_IND, connection attempt status (unsolicited notification), 246
+KCNXCFG, configure GPS connection, 247
+KCNXDOWN, PDP connection, bring down, 249
+KCNXPROFILE, query/set default PDP context, 249
+KCNXTIMER, configure TCP/UDP connection timer, 250
+KCNXUP, PDP
 connection, bring up, 251
+KGSN, query serial number and software version, 74
+KHTTPCFG, configure HTTP connection, 252
+KHTTPCLOSE, close HTTP connection, 253
+KHTTPDEL, delete configured HTTP session, 254
+KHTTPGET, get HTTP server information, 255
+KIPOPT, configure general protocol options, 256
+KMCLASS, set 2G multislot class, 75
+KPATTERN, set/query custom 'end of data/file' pattern, 258
+KSSLCRYPTO, cipher suite configuration, 259
+KSSCLFG, SSL configuration, 261
+KRFMUTE, enable/disable RAT Tx muting, 210
+KRFMUTE, mute mode notification, 211
+KSIMDET, enable/disable SIM detection notifications, 76
+KSIMSEL, select external SIM interface, 203
+KSLEEP, configure sleep mode entry based on UART1 DTR, 77
+KSRAT, query/set current RAT, 78
+KSREP, start-up reporting, enable/disable, 79
+KSUP, module startup status (unsolicited notification), 79
+KTCP_DATA (notification), incoming data through TCP connection, 259
+KTCP_IND (notification), TCP connection
 status notification, 259
+KTCP_SRVREQ (notification), incoming client connection request, 260
+KTCPCFG, configure TCP connection, 262
+KTCPCLOSE, close current TCP connection, 264

+KTCPCNX, start TCP connection, 265
+KTCPDEL, delete configured TCP session, 266
+KTCPRCV, receive data through TCP connection, 267
+KTCPSEND, send data through TCP connection, 268
+KTCPSTART, start TCP connection, 269
+KTCPSTAT, get TCP socket status, 270
+KUDP_DATA (notification), incoming data, 271
+KUDP_IND (notification), UDP status, 271
+KUDPCFG, configure UDP connection, 272
+KUDPCLOSE, close current UDP connection, 274
+KUDPDEL, delete configured UDP session, 274
+KUDPCV, receive data through UDP connection, 275
+KUDPSND, send data through UDP connection, 276
+KURCCFG, enable/disable protocol notifications, 277

L

L, set monitor speaker loudness, 280
!LEDTEST, test LED, 170

M

M, set monitor speaker mode, 280
!MAPUART, map services to UART, 80
!MAXPWR, query/set maximum Tx power for specific band, 212
!MUXMODE, configure CMUX mode, 81

N

!NETNUM, query/set number of supported network interfaces, 81
!NVBACKUP, backup NV data, 82

O

O, switch from command mode to data mode, 280

P

P, select pulse dialing, 280
!PACKAGE, return package version string, 82
!PATEMP, return current PA temperature information, 83
!PATEMP, PA temperature state change (unsolicited notification), 83
!PCINFO, return power control status information, 84
!PCTEMP, return current temperature information, 85
!PCTEMP, PMIC temperature state change (unsolicited notification), 85
!PCTEMPLIMITS, query/set temperature state limits, 86
!PCVOLT, return current power supply voltage information, 87
!PCVOLT, PMIC voltage state change (unsolicited notification), 87
!PCVOLTLIMITS, query/set power supply voltage state limits, 88
!POWERDOWN, power down the system, 88
!POWERMODE, set module power saving mode, 89
!POWERWAKE, configure ULPM/PSM wakeup sources, 90
!PRIID, query PRI part number and revision, 91
*PSRDBS, select operating bands, 92
*PSSTKI, configure AT interface's SIM toolkit support, enable/disable, 116

Q

Q, set result code presentation mode, 280

R

!RESET, reset the modem, 93
 !RMARESET, restore device to original settings, 171
 +RSCP, display, 94
 !RXDEN, enable/disable WCDMA Rx diversity, 145

S

&S, set DSR signal, 279
 S0, set number of rings before auto-answer, 280
 S10, set disconnect delay after indicating absence of data carrier, 280
 S11, query/set DTMF dialing speed, 95, 281
 S3, set command line termination character, 280
 S4, set response formatting character, 281
 S5, set command line editing character, 281
 S6, set pause before blind dialing, 281
 S7, set number of seconds to wait for connection completion, 281
 S8, set number of seconds to wait when comma dial modifier used, 281
 !SARBACKOFF, query/set offset from max Tx power, 214
 !SARGPIO, set external GPIO for SAR control, 217
 !SARINTGPIOMODE, query/set default pull mode for SAR GPIOs, 218
 !SARSTATE, query/set SAR backoff state, 218
 !SARSTATEDFLT, query/set default SAR backoff state, 219
 !SCACT, activate/deactivate data connection, 96
 !SCUMMTU, set/report mtu size, 97
 !SDINFO, display SD card status, 206
 !SELACQ, select RAT acquisition order, 98
 !SELCIOT, set Cellular IOT (CIOT) preferences, 99
 !SELMODE, query/set current service domain, 100
 !SELRAT, query/set current RAT, 101
 !SELSNR, set LTE-NB1 band scan configuration, 103
 !SETCND, set AT command password, 23
 +SIM (notification), SIM inserted/removed, 103
 !SKU, read module SKU, 104
 !STKC, report last unsolicited proactive SIM command notification, 117
 !STKC notification, unsolicited proactive SIM command notification, 118
 !STKCR, respond to proactive SIM command, 119
 !STKGC, get (retrieve) data from last unsolicited proactive SIM command, 124
 !STKMS, inform SIM of menu item selection or get help, 136
 !STKN notification, response to MO call/SMS control request, 137
 !STKPD, select host-supported STK features, 139

T

&T, auto tests, 279
 T, select tone dialing, 281

U

!UIMS, select UIM interface, 204
 !USBCOMP, query/set USB interface configuration, 105
 !USBINFO, return information from active USB descriptor, 106
 !USBPID, query/set USB descriptor product ID, 107

V

&V, return AT configuration parameters, 279
 V, set result code format mode, 281
 +VTD, tone duration, 287
 +VTS, DTMF and arbitrary tone generation, 288
 +VTS, send DTMF tone, 226

W

&W, Store parameter to user-defined profile, 279
 +WDSC, configure AirVantage Management Services, 234
 +WDSE, display last AirVantage Management Services error, 236
 +WDSG, display AirVantage Management Services status, 237
 +WDSI, activate/deactivate AirVantage Management Services unsolicited notifications, 238
 +WDSI, AirVantage Management Services event, unsolicited notification, 239
 +WDSR, reply to AirVantage server request, 241
 +WDSS, AirVantage Management Services session configure/connect, 242
 +WEXTCLK, enable/disable user clock mode, 228
 +WFWUPD, download/install firmware package, 108, 109
 +WIOCFG, configure external GPIOs, 229
 +WJAM, jamming event unsolicited notification, 110
 +WJAMTHRESH, jamming detection threshold, set/report, 111
 +WRID, set/query Ring Indicator duration value, 231
 +WS46, PCCA STD 101 select wireless network, 288
 +WUSLMSK, unsolicited notifications, enable/disable, 112
 +WWAKESET, set/query Wake event mask setting, 232

X

X, set connect result code format and call monitoring, 281

Z

Z, set all current parameters to user-defined profile, 281

Symbols

"exit spymode", enable/disable, [49](#)
+++, [9](#)
+++, switch from data mode to command mode, [27](#)

Numerics

3GPP
27.005 commands, list, [281](#)
27.007 commands, list, [283](#)

A

ADC
read, [28](#)

AGC
averaged Rx value (LTE mode), return, [154](#)
averaged Rx value (WCDMA), return, [165](#)
read Rx AGC in dBm for CDMA and WCDMA modes, [208](#)
Rx value (WCDMA), return, [166](#)

AirVantage
Management Services
configure, [234](#)
error, display most recent, [236](#)
session, configure/connect, [242](#)
status, display, [237](#)
unsolicited notifications, activate, [238](#)
Management Services, unsolicited notifications, [239](#)

Server
reply to server request, [241](#)

antenna
select configuration, external, [29](#)

ASCII table, [291](#)

AT
interface
SIM toolkit support, configure, [116](#)

AT commands
3GPP 27.005 commands, list, [281](#)
3GPP 27.007 commands, list, [283](#)
GPS command error codes, [197](#), [198](#)
guard timing, escape sequence, [9](#)
ITU-T V.250 commands, list, [279](#)
password commands, [18](#), [19](#), [21](#), [24](#), [220](#), [227](#), [233](#)
password protected, access, [22](#)
password, changing, [23](#)
timing, entry, [9](#)

audio parameters
reset (in NV) to default values, [223](#)

audio profile
bind to device+physical interface, [221](#)
CS calls, select, [224](#)

B

backup
NV data, [82](#)

band
current GSM, return, [55](#)
current WCDMA, return, [55](#)
set, [160](#)

band scan configuration, LTE-NB1, [103](#)

band selection, enable/disable, [48](#)

bands
available, [31](#)
current, [31](#)
select operating, [92](#)
set, [31](#)

bandwidth
LTE, set Rx, [156](#)
LTE, set Tx, [156](#)

boot and hold. See bootloader.

bootloader
wait for firmware update, [33](#)

bootup time, return, [55](#)

burst mode
GSM receiver enable/disable, [152](#)

C

calibration state, modem, [161](#)

call
CSD, enable/disable, [49](#)
camped cell information notifications, enable/disable, [69](#)
camped cell parameter change notification, [70](#)
capabilities, display, [64](#)

cell
details, display, [71](#)

+CFUN persistence, customization, [49](#)

CGPS
C/N, return, [149](#)
diagnostic task, start/stop, [150](#)
frequency, return, [149](#)
IQ log mask, set, [149](#)

channel
set, [162](#)

channel number
current GSM, return, [55](#)
current WCDMA, return, [55](#)

circuit-switched bearer, select, [36](#)

CMEE
error reporting, configure, [42](#)

CMUX mode
configure, [81](#)

Coex enable/disable
Wi-/Fi/LTE, [51](#)

command access password, [9](#)

command mode
switch from data mode, [27](#)

connection
status notification, [246](#)

crash data
display, [144](#)

crash dump data, clear, [144](#)

CS
voice reject, enable/disable, [49](#)

CS calls
select audio profile, [224](#)

CSD
call, enable/disable, [49](#)

customization
modem functions, [48](#)

D

- data connection, activate/deactivate, [96](#)
- data mode
 - switch from command mode, [27](#)
- debug
 - printing, enable/disable, [207](#)
- decoder gain, query/set, [223](#)
- device behaviour when APN details change, customize, [52](#)
- device information, display, [64](#)
- DHCP
 - relay feature, enable/disable, [49](#)
- diagnostic
 - commands, list, [141](#)
 - information, display, [144](#)
- diversity, receive, enable/disable, [145](#)
- document
 - format conventions, [20](#)
- DTMF dialing speed, query/set, [95](#)
- DTMF tone
 - send, [226](#)
- Dying Gasp, enable/disable, [49](#)

E

- encoder gain, query/set, [225](#)
- end of data/file pattern, set, [258](#)
- EOF pattern, set, [258](#)
- error conditions, display log, [144](#)
- ERROR reporting, configure, [42](#)
- escape sequence guard time, [9](#)
- EXT_GPS_LNA_EN, enable/disable, [49](#)

F

- factory test mode. See FTM.
- fast boot, enable/disable, [50](#)
- file system versions, display, [64](#)
- firmware
 - download, disable, [53](#)
 - update, wait in bootloader mode, [33](#)
- firmware download
 - enable/disable over UART on bootloader, [48](#)
- firmware images
 - manage, [66](#)
- firmware package, download/stinstall, [108](#), [109](#)
- firmware update, status of last attempt, [142](#)
- firmware, upgrading, [11](#)
- flow control, [68](#)
- format
 - documentation conventions, [20](#)
- frequency
 - band, set, [160](#)
 - channel, set, [162](#)
- frequency bands. See bands.
- FSN
 - display, [64](#)
- FTM
 - activate FTM modem mode, [151](#)

G

- gain
 - decoder, query/set, [223](#)
 - encoder, query/set, [225](#)
- GCF
 - testing mode, enable/ disable, [54](#)
- GMM state, return, [55](#)
- GNSS
 - CGPS diagnostic task, start/stop, [150](#)
 - select satellite systems, [174](#)
- Gobi Image Management
 - preferences, set, [68](#)
- GPIO
 - SAR control, select pin, [217](#)
 - SAR interrupt, pull mode (default), [218](#)
 - signal level/direction, query/set, [34](#)
- GPIO, configure, [229](#)

GPS

- "Info for DR" feature, enable/disable, 179
 - accuracy, configure, 175
 - almanac data, clear, 176
 - altitude, last fix, 180
 - antenna to use, select, 51
 - assistance data
 - clear all, 177
 - clear specific, 176
 - AT command error codes, 197, 198
 - auto-start features, configure, 175
 - command list, 16, 17, 172
 - connection, configure, 247
 - ephemeris data, clear, 176
 - fix period, configure, 175
 - fix session
 - end, 177
 - initiate, 178
 - status, report, 187
 - fix type
 - configure, 175
 - last fix, 180
 - fix wait time, configure, 175
 - heading, last fix, 180
 - horizontal estimated positional error, last fix, 180
 - ionosphere data, clear, 176
 - latitude, last fix, 180
 - location details, most recent, 180
 - location request settings, query/set, 182
 - location uncertainty angle, last fix, 180
 - longitude, last fix, 180
 - low power mode, enable/disable, 50
 - MO method, query/set, 181
 - multiple fix (tracking) session, initiate, 190
 - position data, clear, 176
 - reference location reporting, enable/disable, 50
 - satellite information, request, 186
 - Stand Alone (SA) RF mode, enter/exit, 150
 - SUPL server URL, query/set, 188
 - SUPL server version, query/set, 189
 - time reference, clear, 176
 - time, last fix, 180
 - tracking (multiple fix) session, initiate, 190
 - transport security, enable/disable, 191
 - uncertainty, last fix, 180
 - velocity, last fix, 180
 - XTRA
 - data configuration settings, query/set, 192
 - data injection status, report, 194
 - data server URLs, query/set, 193
 - data, enable/disable, 192
 - SNTP server URLs, query/set, 197
 - time information, query/set, 196
 - time injection operation, 195
 - time injection status, report, 194
- GSM
- Algorithm and Authenticate, enable/disable, 52
 - receiver burst mode, enable/disable, 152
 - Tx slots, configure, 153
- guard time, AT escape sequence, 9

H

- hardware ID, read, 63
- Host wake-up method, enable/disable, 54
- HTTP
 - connection
 - close, 253
 - configure, 252
 - delete, 254
 - server information, get, 255

I

- ICCID, display, 201, 202
- ICMP, enable/disable, 51
- ID
 - hardware, read, 63
- image switching configuration, 51
- images, firmware
 - manage, 66
- IMEI
 - display, 64
- IMEISV, display, 64
- IoT preferences, cellular, set, 99
- IP
 - channel rate calculation, enable/disable, 51
- IQ log mask, CGPS, 149
- ITU-T V.250 commands, list, 279

J

- JAM detection, enable/disable, 51
- jamming
 - detection threshold, set/report, 111
 - events, unsolicited notification, 110

L

- LED
 - test, 170
- Legato version, display, 64
- Linux kernel boot-time messages, enable/disable, 48
- Linux version, display, 64
- LK version, display, 64
- LNA gain state
 - set, 163
- Low Noise Amplifier. See LNA.
- LPM
 - SIM, default state, 52
- LTE
 - averaged AGC, return, 154
 - bandwidth, set Rx, 156
 - bandwidth, set Tx, 156
 - modulation type, set, 157
 - Net Sig value, configure, 155
 - PA range, set, 155
 - Tx power level, set, 158
 - Tx waveform, set, 159
- LTE-NB1 band scan configuration, 103

M

manufacturer, display, [64](#)
memory management
 command list, [171](#)
MM
 state and substate, return, [55](#)
MO method, GPS, [181](#)
mode acquired by modem, return, [55](#)
mode, configure for testing, [146](#)
model, display, [64](#)
modem
 calibration state, enter/exit, [161](#)
 channel, set, [162](#)
 customizations, [48](#)
 frequency band, set, [160](#)
 FTM mode
 activate, [151](#)
 mode, return, [55](#)
 operational status, return, [55](#)
 PRI part number and revision, query, [91](#)
 reset, [93](#)
 reset, wait for firmware update, [33](#)
 temperature
 limits, query/set, [86](#)
 voltage limits, query/set, [88](#)
 modulation type, set (LTE), [157](#)
 module reset, type/cause, display, [143](#)
 mtu size, set/report, [97](#)
 multiplexing
 configure control channel, [43](#)
 multislot class (2G), set, [75](#)
 mute
 RAT Tx, [210](#), [211](#)

N

Net Sig value, configure, [155](#)
network interfaces, supported quantity, [81](#)
network provider name, display format, [52](#)
NMEA reporting, enable/disable, [183](#)
NMEA sentence type, get/set, [184](#), [185](#)
notification, unsolicited
 MO call/SMS control request response notification, [137](#)
 report last proactive SIM command, [117](#), [118](#)
notifications, enable/disable, [277](#)
NV
 backup, [82](#)

O

OMA-DM
 command list, [207](#), [209](#)
OSA, enable/disable, [52](#)

P

PA
 range state machine, WCDMA, [168](#)
PA range, set, [155](#)

PA temperature
 current, return, [83](#)
 state, return, [83](#)
package, return string from modem, [82](#)
PAD
 command list, [17](#)
password
 changing, [23](#)
 commands, list, [18](#), [19](#), [21](#), [24](#), [220](#), [227](#), [233](#)
 protected commands, access, [22](#)
pattern, end of data/file, set, [258](#)
PCSC, enable/disable, [52](#)
PDM, adjust, [164](#)
PDP
 connection authentication parameters, set/report, [39](#), [40](#)
 connection, bring down, [249](#)
 connection, bring up, [251](#)
 context addresses, display, [245](#)
 context default, query/set, [249](#)
 context, define, [41](#)
power
 control status details, return, [84](#)
 off, [46](#)
 offset from max Tx, set/query, [214](#)
 PSM, configure, [45](#)
 Tx (max), set/query, [212](#)
power amplifier
 Tx, turn off, [164](#)
 Tx, turn on, [165](#)
power down system, [88](#)
power fault customization, enable/disable, [52](#)
power level set, Tx (LTE), [158](#)
Power Saving Mode
 see PSM, [45](#)
power saving mode, set, [89](#)
PRI, part number and revision, query, [91](#)
product ID, set in USB descriptor, [107](#)
protocol options, configure, [256](#)
PS state, return, [55](#)
PSM
 configure, [45](#)
 wake up sources, configure, [90](#)

Q

QMI NAS Detach, enable/disable, [52](#)
QMI notification events, enable/disable, [50](#)

R

RAT
 current, query/set, [78](#), [101](#)
 Tx, muting, [210](#), [211](#)
RAT acquisition order, select, [98](#)
receive chain (WCDMA)
 secondary, enable/disable, [168](#)
receive diversity, enable/disable, [145](#)
receiver, configure, [167](#)
reference documents, location, [10](#)
reset modem, [33](#), [93](#)
restore device to original settings, [171](#)
result codes, displaying in document, [10](#)

Ring Indicator, duration set/query, 231
 root FS version, display, 64
 RSCP, display, 94
 RSSI
 change across threshold, unsolicited notification, 47
 GSM receiver burst mode, enable/disable, 152
 value
 display averaged value, 152
 rssi
 display, 46
 Rx
 AGC reading (WCDMA), return, 166
 averaged AGC reading (LTE mode), return, 154
 averaged AGC reading (WCDMA), return, 165
 configure receiver, 167

S

SAR backoff control method, 50
 SAR backoff state
 current, query/set, 218
 default, query/set, 219
 scripts
 testing, command timing, 9
 SD card, status, 206
 serial number, query, 74
 service
 domain, query/set, 100
 side tone gain, configure, 224
 signal quality, display, 46
 signal quality, extended, 37
 SIM
 default state in low power mode, 52
 detection notifications, enable/disable, 76
 fast switch via external switch, enable/disable, 49
 ICCID, display, 201, 202
 inserted/removed notification, 103
 select external interface, 203
 service provider's name, display, 202
 SIM hotswap, configure, 52
 SIM toolkit
 AT interface support, configure, 116
 host-supported features, select, 139
 menu item, indicated selection or request help, 136
 MO call/SMS control request response notification, 137
 SIM command
 get (retrieve) data, 124
 respond, 119
 SIM command notification
 report last unsolicited, 117, 118
 SIM Toolkit. See STK.
 SKU, read, 104
 sleep mode, configure, 77
 slots, Tx, configure for GSM, 153
 SNTP, enable/disable, 53
 software version, query, 74
 start-up reporting, enable/disable, 79
 startup state, unsolicited notification, 79
 STK
 UI, enable/disable, 53
 system
 power down, 88

T

TCP
 connection
 close, 264
 configure, 262
 delete, 266
 incoming client request notification, 260
 incoming data notification, 259
 receive data, 267
 send data, 268
 start, 265, 269
 status notification, 259
 connection timer, configure, 250
 general options, configure, 256
 socket status, get, 270
 temperature
 current, return, 85
 limits, query/set, 86
 PA state change, unsolicited notification, 83
 PMIC state change, unsolicited notification, 85
 return, 55
 state, return, 85
 temperature, PA
 state, return, 83
 temperature,PA
 current, return, 83
 test
 scripts, command timing, 9
 testing
 command list, 147
 configure modem mode, 146
 timer
 TCP/UDP connection, configure, 250
 timing
 AT command entry, 9
 AT guard time, 9
 test script commands, 9
 transmitter waveform type, selection, 169
 Tx
 power amplifier
 turn off, 164
 turn on, 165
 power level, set, 169
 power level, set (LTE), 158
 slots, configure for GSM, 153
 Tx waveform, set, 159
 TX_ON indication, enable/disable, 53

U

UART
 map services to, 80

UDP

- connection
 - receive data, [275](#)
- connection
 - close, [274](#)
 - configure, [272](#)
 - delete, [274](#)
 - incoming data notification, [271](#)
 - send data, [276](#)
 - status notification, [271](#)
- connection timer, configure, [250](#)
- general options, configure, [256](#)

UIM

- automatic switching, enable/disable, [53](#)
- interface, select, [204](#)

UIM2

- slot support, enable/disable, [53](#)

ULPM

- wakeup sources, configure, [90](#)

unlock protected commands, [22](#)

unsolicited notification

- PA temperature state change, [83](#)
- PMIC temperature state change, [85](#)
- PMIC voltage state change, [87](#)
- RSSI, change across threshold, [47](#)
- startup state, [79](#)

unsolicited notifications, enable/disable, [112](#)

URC

- enable/disable, [277](#)

USB

- descriptor—product ID, query/set, [107](#)
- interface configuration, query/set, [105](#)

USB descriptor information, display, [106](#)

USB descriptor, include serial number, [54](#)

user clock mode, enable/disable, [228](#)

user FS, display, [64](#)

V

voice reject (CS), enable/disable, [49](#)

voltage

- actual, return, [87](#)
- PMIC, state change, unsolicited notification, [87](#)
- raw reading, return, [87](#)
- state, return, [87](#)

voltage limits, query/set, [88](#)

volume

- audio profile Rx, set, [225](#)

W

WAKE

- event mask setting, set/query, [232](#)

wake

- via SMS/incoming data packet, enable/disable, [54](#)

wakeup sources, configure, [90](#)

waveform type selection, transmitter, [169](#)

WCDMA

- PA range state machine, set, [168](#)
- receive chain, secondary, enable/disable, [168](#)
- receive diversity, enable/disable, [145](#)

Y

Yocto version, display, [64](#)